




SERVICE AND PARTS MANUAL

3072RT / 3772RT 3772RT HD



ART_2497

Serial Number Range
3072RT: 9201000 - Present
3772RT / 3772RT HD: 9301000 - Present

Part # 91220 R1
March 2008

Revision History:

March 2008

Pages	Reason for update
Page V Page VI	Introduction Update Specifications Table Update Illustration
Page 2-3 Page 2-11	Service Section 2 Update illustration: Deutsch Connectors Add illustrations and update text: Continuity Checks
Page 4-11	Service Section 4 Update Step 3:Setting Counterbalance Valves
Page 5-2 Page 5-3 Page 5-15 Page 5-16	Service Section 5 Update text: Hydraulic Schematic - bold table heads Update illustration: Hydraulic Schematic Update illustration: Outrigger Electric Schematic Update illustration: Generator Option Schematic
Page 1-8 Page 1-9	Parts Section 1 Update illustration: Base Control Box Update parts list to identify key switch and related components
Page 4-2 Page 4-3	Parts Section 4 Update illustration: Rear Axle Assembly Update parts list to identify valve shields and related components
Page 6-2 Page 6-3 Page 6-8 Page 6-9 Page 6-20 Page 6-22 Page 6-23 Page 6-24 Page 6-25 Page 6-26 Page 6-27 Page 6-28 Page 6-29 Page 6-30 Page 6-31 Page 6-32 Page 6-33 Page 6-34 Page 6-35	Parts Section 6 Update illustration: Base Assembly Update parts list to identify Power to Platform Bracket Update illustration: Control Module Update parts list to identify Hole Plug Update illustration: Engine, Dual Fuel Update illustration: Engine, Dual Fuel Update parts list to identify new part numbers Update illustration: Engine, Diesel Update parts list to identify new part numbers Update illustration: Engine, Diesel Update parts list to identify new part numbers New illustration: Harnesses Update parts list to identify new part numbers Update illustration: Outrigger Install Update parts list to identify Power to Platform Bracket New Illustration: Generator Option, Dual Fuel Update parts list to identify new part numbers New Illustration: Generator Option, Diesel Update parts list to identify new part numbers
Page 7-4 Page 7-5 Page 7-6 Page 7-7 Page 7-8 Page 7-9 Page 7-10 Page 7-11	Parts Section 7 Update illustration: 3072RT Sides Update parts list Update illustration: 3072RT Ends Update parts list Update illustration: 3772RT / 3772RT HD Sides Update parts list Update illustration: 3772RT / 3772RT HD Ends Update parts list



Aerial Platform Sales Corp.

1775 Park Street, Suite 77 • Selma, CA 93662 USA
Ph: 1-800-387-4575 • 559-891-2488 • Fax: 559-891-2448
E-mail: info@mecawp.com • Web: www.mecawp.com

Table of Contents

Service Sections

INTRODUCTION	I
General Safety Tips	III
Hydraulic System	IV
Electrical System	IV
Total System	IV
Machine Specifications	V
Primary Machine Components	VII
LUBRICATION	VIII

SECTION 1:

HYDRAULIC SYSTEM	1-1
Hydraulic System - General	1-2
Hydraulic Fluid	1-3
Hydraulic Fluid Reservoir	1-6
Hydraulic Pump	1-7
Wheel Drive	1-7
Parking Brake and Towing Circuit	1-14
Emergency Systems And Procedures	1-15
Steering Circuit	1-16
Platform Lift Circuit	1-18
Optional Outriggers	1-20
Cylinder Repair	1-21
Hydraulic Manifold	1-24

Table of Contents

SECTION 2:

ELECTRICAL SYSTEM	2-1
Electrical System - General	2-2
Deutsch Connectors	2-3
Battery	2-4
Battery Preventative Maintenance:	2-5
Battery Replacement	2-6
Alarms and Switches	2-7
Tilt Alarm	2-8
Relays	2-9
Limit Switch	2-10
Optional Outriggers Switches	2-10
Continuity Checks	2-11

SECTION 3:

MECHANICAL COMPONENTS	3-1
Torque Specifications	3-2
Mechanical Components	3-3
Base/ Undercarriage	3-3
Raising the Machine	3-3
Tires	3-4
Drive Motors	3-5
Steer Cylinder	3-6
Hoses and Cables	3-7
Platform Removal	3-7
Lift Cylinder Removal and Installation	3-8
Scissor Beam Assembly	3-8
Engine Maintenance	3-9
Diesel Engine	3-9
Gasoline and Dual Fuel Engine	3-12
Outrigger Function	3-14
Outrigger Calibration	3-15
GP106 Outrigger Control Module Troubleshooting	3-17
Outrigger Module GP106 LED Flash Codes	3-18

Table of Contents

SECTION 4:

TROUBLESHOOTING	4-1
Troubleshooting	4-3
General Troubleshooting Tips	4-3
Common Causes of Hydraulic System Malfunctions:	4-3
Hydraulic Pressure Adjustment Procedures	4-9
Proportional Speed Adjustment	4-12
Controls and Switches	4-14

SECTION 5:

SCHEMATICS	5-1
Hydraulic Schematic	5-2
Main Hydraulic Manifold	5-4
Optional Outriggers Hydraulic Manifold	5-5
Electric Schematics	5-6
Circuit Board	5-8
Controls	5-10
Engine	5-13
Optional Outriggers	5-15
Optional Generator	5-16



Table of Contents

Parts Sections

SECTION 1: CONTROL BOXES

SECTION 2: PLATFORM AND RAILS

SECTION 3: SCISSORS

SECTION 4: AXLES

SECTION 5: HYDRAULICS

SECTION 6: BASE

SECTION 7: DECALS

INTRODUCTION

This manual consists of Service and Parts illustrations sections.

The Service Section of this manual is designed to provide you, the customer, with the instructions needed to properly maintain the MEC self-propelled scissors lift. When used in conjunction with the illustrated parts section and the Operators Manual (provided separately), this manual will assist you in making necessary adjustments, repairs, identifying, and ordering the correct replacement parts.

All parts represented here are manufactured and supplied in accordance with MEC's quality standards.

We recommend that you use Genuine MEC parts to insure proper OPERATION and reliable PERFORMANCE.

To obtain maximum benefits from your MEC scissors lift, always follow the proper operating and maintenance procedures. Only trained authorized personnel should be allowed to operate or service this machine. Service personnel should read and study the Operator's, Service and Parts Manuals in order to gain a thorough understanding of the unit prior to making any repairs.

To help you recognize important safety information, we have identified warnings and instructions that directly impact on safety with the following signals:



“DANGER” INDICATES AN IMMINENTLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY. THIS SIGNAL WORD IS LIMITED TO THE MOST EXTREME SITUATIONS.



“WARNING” INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



“CAUTION” INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, MAY RESULT IN MINOR OR MODERATE INJURY. IT MAY ALSO BE USED TO ALERT AGAINST UNSAFE PRACTICES. “CAUTION” IS USED FOR PROPERTY-DAMAGE ONLY ACCIDENTS.

NOTE: The best method to protect yourself and others from injury or death is to use common sense. If you are unsure of any operation, don't start until you are satisfied that it is safe to proceed and have discussed the situation with your supervisor.

Service personnel and machine operators must understand and comply with all warnings and instructional decals on the body of the machine, at the ground controls, and platform control console.



MODIFICATIONS OF THIS MACHINE FROM THE ORIGINAL DESIGN AND SPECIFICATIONS WITHOUT WRITTEN PERMISSION FROM MEC ARE STRICTLY FORBIDDEN. A MODIFICATION MAY COMPROMISE THE SAFETY OF THE MACHINE, SUBJECTING OPERATOR(S) TO SERIOUS INJURY OR DEATH.

MEC's policies and procedures demonstrate our commitment to Quality and our relentless ongoing efforts towards Continuous Improvement, due to which product specifications are subject to change without notice.

Any procedures not found within this manual must be evaluated by the individual to assure oneself that they are "proper and safe."

Your MEC Scissors Lift has been designed, built, and tested to provide many years of safe, dependable service. Only trained, authorized personnel should be allowed to operate or service the machine.

MEC, As Manufacturer, Has No Direct Control Over Machine Application And Operation. Proper Safety Practices Are The Responsibility Of The User And All Operating Personnel.

If There Is A Question On Application And/Or Operation Contact:



Aerial Platform Sales Corp.

1775 Park Street, Suite 77 • Selma, CA 93662 USA

Ph: 1-800-387-4575 • 559-891-2488 • Fax: 559-891-2448

www.mecawp.com



GENERAL SAFETY TIPS

Regular inspection and conscientious maintenance is the key to efficient economical operation of your scissors lift. It will help to assure that your equipment will perform satisfactorily with a minimum of service and repair.



The actual operating environment of the machine governs the inspection schedule. Correct lubrication is an essential part of the preventative maintenance to minimize wear on working parts and ensure against premature failure. By maintaining correct lubrication, the possibility of mechanical failure and resulting downtime is reduced to a minimum.



NEVER PERFORM SERVICE ON THE MACHINE (WITH THE PLATFORM ELEVATED) WITHOUT FIRST BLOCKING THE BEAMS (SCISSORS) ASSEMBLY IN PLACE USING THE MAINTENANCE LOCK!

- Block scissors assembly using Maintenance Lock if machine is in the elevated/extended position.
- Never leave hydraulic components or hoses open. They must be protected from contamination (including rain) at all times.
- Never open a hydraulic system when there are contaminants in the air.
- Always clean the surrounding area before opening hydraulic systems.
- Use only recommended lubricants. Improper lubricants or incompatible lubricants may be as harmful as no lubrication.
- Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.

Maintenance Lock In Position



Hydraulic System



HYDRAULIC FLUID UNDER PRESSURE CAN PENETRATE AND BURN SKIN, DAMAGE EYES, AND MAY CAUSE SERIOUS INJURY, BLINDNESS, AND EVEN DEATH. CORRECT LEAKS IMMEDIATELY.



Hydraulic fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.

Electrical System



Prevent damage to battery and/or electrical system;

- **Always disconnect the negative battery cable first.**
- **Always connect the positive battery cable first.**

If contact is made between the positive side of the battery and a metal surface on the machine when the negative cable is installed a spark will occur. This can cause damage to the electrical system, battery explosion, and personal injury.

Total System



Engine coolant level must be checked only after engine has cooled. If radiator cap is removed while the coolant is at normal operating temperature, pressure within the coolant system will force hot liquid out through the filler opening and possibly cause severe scalding.

Failure to perform preventive maintenance at recommended intervals may result in the unit being operated with a defect that could result in injury or death of the operator.


Immediately report to your supervisor any Defect or malfunction. Any defect shall be repaired prior to continued use of the scissors lift.

Inspection and maintenance should be performed by qualified personnel familiar with the equipment.

MACHINE SPECIFICATIONS

	3072RT		3772RT		3772RT HD	
Working Height*	36.0 ft*	11.14 m*	43 ft*	13.28 m*	43 ft*	13.28 m*
Platform Height	30.0 ft	9.14 m	37 ft	11.28 m	37 ft	11.28 m
Platform Entry Height	54 in	1.4 m	61 in	1.5 m	61 in	1.5 m
Stowed Height						
Rails Up	108.5 in	2.75 m	105.75 in	2.62 m	105.75 in	2.62 m
Rails Folded Down	78.5 in	1.99 m	74 in	1.88 m	74 in	1.88 m
Maximum Number of Occupants	3	3	3	3	3	3
Lift Capacity (Evenly Distributed)	1,000 lb	454 kg	750 lb	340 kg	1,000 lb	454 kg
Roll-out Deck Capacity	400 lb	181 kg	400 lb	181 kg	400 lb	181 kg
Platform Dimensions						
With Roll-Out Deck Extended	158 in	4.01 m	158 in	4.01 m	158 in	4.01 m
With Roll-Out Deck Retracted	110 in	2.79 m	110 in	2.79 m	110 in	2.79 m
Deck Width	60 in	1.52 m	60 in	1.52 m	60 in	1.52 m
Guardrail Height	43.5 in	1.10 m	43.5 in	1.10 m	43.5 in	1.10 m
Toeboard Height	6.0 in	15.0 cm	6.0 in	15.0 cm	6.0 in	15.0 cm
Roll-out Deck Length	48 in	1.22 m	48 in	1.22 m	48 in	1.22 m
Overall Length	117.25 ft	2.98 m	117.25 ft	2.98 m	140 in	3.56 m
Overall Width	72 in	1.83 m	72 in	1.83 m	73.25 in	1.86 m
Wheel Base	86.0 in	2.18 m	86.0 in	2.18 m	86.0 in	2.18 m
Wheel Track	60.5 in	1.54 m	60.5 in	1.54 m	60.5 in	1.54 m
Turning Radius						
Inside	73.25 in	1.86 m	73.25 in	1.86 m	73.25 in	1.86 m
Outside	14 ft 2.5 in	4.33 m	14 ft 2.5 in	4.33 m	14 ft 2.5 in	4.33 m
Ground Clearance	9.5 in	24 cm	9.5 in	24 cm	9.5 in	24 cm
Machine Weight** (Unloaded) (Approx.)	7,062 lb**	3203 kg**	7,975 lb**	3589 kg**	8,585 lb**	3863 kg**
Drive System (Proportional)	2 Wheel Drive Standard, 4 Wheel Drive Option					
Drive Speed (Platform Elevated)	0 – 0.4 mph	0 – 0.6 km/h	0 – 0.4 mph	0 – 0.6 km/h	0 – 0.4 mph	0 – 0.6 km/h
Drive Speed (Platform Lowered)	0 – 4.0 mph	0 – 6.4 km/hr	0 – 4.0 mph	0 – 6.4 km/hr	0 – 4.0 mph	0 – 6.4 km/hr
Lift/Lower Speed (Approx.)	26 sec / 28 sec	26 sec / 28 sec	28 sec / 31 sec	28 sec / 31 sec	28 sec / 31 sec	28 sec / 31 sec
Gradeability	45% / 24.2°	45% / 24.2°	40% / 21.5°	40% / 21.5°	40% / 21.5°	40% / 21.5°
Ground Pressure/Wheel (Maximum)	91 psi	6.4 kg/cm ²	97 psi	6.8 kg/cm ²	100 psi	7.0 kg/cm ²
Tire Size-Standard	26.0-12.0-380		26.0-12.0-380		26.0-12.0-380	
Tire Pressure, 12 Ply Pneumatic	60 psi	4.14 bar	60 psi	4.14 bar	60 psi	4.14 bar
12 Ply Foam-Filled (Option)	Foam-Filled	Foam-Filled	Foam-Filled	Foam-Filled	Foam-Filled	Foam-Filled
Wheel Load	2,722 lb	1235 kg	2,921 lb	1325 kg	2,996 lb	1359 kg
Wheel Lug Nut Torque	75-85 ft/lb	102-115 Nm	75-85 ft/lb	102-115 Nm	75-85 ft/lb	102-115 Nm
Hydraulic Pressure						
Main System	2800 psi	193 bar	3000 psi	207 bar	3000 psi	207 bar
Lift System	2500 psi	172 bar	2500 psi	172 bar	2500 psi	172 bar
Steer	1500 psi	103 bar	1500 psi	103 bar	1500 psi	103 bar
Hydraulic Fluid Capacity	23 GAL	87 liters	23 GAL	87 liters	23 GAL	87 liters
Fuel Capacity	15 GAL	57 liters	15 GAL	57 liters	15 GAL	57 liters
Power System – Voltage	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC	12 Volts DC
Alternator (Lighting Coil)	40 Amp	40 Amp	40 Amp	40 Amp	40 Amp	40 Amp
Engine Availability	Standard	Kubota DF752E, 22 HP (16.4 kW), Dual Fuel, Liquid Cooled				
Option		Kubota D905E, 20 HP (14.9kW), Diesel, Liquid Cooled				
Meets requirements of ANSI A92.6-2006 Section 4.						
*Working height adds 6 feet (2 m) to platform height.						
**Weight may increase with certain options or country standards.						






PRIMARY MACHINE COMPONENTS

Component	Service Section	Parts Section	Component	Service Section	Parts Section
Platform Assembly			Control Module		
Upper Controls	2 4 5	1 2	Lower Controls	2 3 4 5	1 6
Deck and Rails	3	2	Hydraulic Manifold	1 3 4 5	5 6
Chain Closure		2	Parking Brake Release	1	
Optional Gate		2	Emergency Lowering	1	
Rollout Deck		2	Fuel Tank		6
Control Terminal Strip		1	Fuel Shutoff		6
Horn (optional)	2	1	Power to Platform		6
Lift Assembly			Tilt Sensor	2 3 4 5	6
Beams	intro	3	Battery & Disconnect	2 3 4 5	6
Maintenance Lock	intro	3	Outrigger Manifold	1 3 4 5	5 6
Lift Cylinders	1 3 4 5	3 5	Outrigger Control Module (Outrigger Option)	2 5	6
Limit Switch	2 4	3	AC Generator (Option)	5	5 6
Base Assembly			Relays		
Front Drive Motors	intro 1 3 4 5	4 5 6	Platform Power	2 4 5	1
R Drive Motors w/Brakes	intro 1 3 4 5	4 5 6	Torque Speed	2 4 5	6
Steering Components	1 3	3 5 6	Throttle	2 4 5	6
Steering Components	1 3 4 5	3 5 6	Preheat	2 4 5	6
Wheels & Tires	intro 3	6	Outrigger (Option)	3 4 5	6
Hubs	intro	6	AC Generator (Option)	5	6
Slide Block	intro	6			
Emergency Lowering	1				
Hoses & Cables	1 2 3	5 6			
Outrigger (Option)	1 3 4 5	5 6			
LPG (Option)	3	6			
Power Module					
Engine	3 4 5	6			
Hydraulic Pump	1 3 4 5	6			
Hydraulic reservoir	intro 1	6			
Hydraulic Filter	intro 1	6			



LUBRICATION

NO.	ITEM	SPECIFICATION	FREQUENCY
1	Hydraulic Reservoir	Fill To The Middle Of The Sight Gauge With Platform In The Stowed Position. Mobile 424. Do not substitute with lower grade oils as pump damage may result.	Check Daily. Change Yearly Or Every 1,000 Hours, Whichever Occurs First.
2	Hydraulic Filter	Filter Element	Change Every Six Months Or 500 Hours, Whichever Occurs First For Normal Usage. Change Every Three Months Or 300 Hours, Whichever Occurs First For Severe Usage.
3	Front Hubs Steering Pivots	Lithium N.L.G. #2 EP Purge Old Grease	Monthly or Every 25 Hours, Whichever Occurs First
4	Slide Block	Lithium N.L.G. #2 EP Purge Old Grease	Monthly or Every 25 Hours, Whichever Occurs First
5	Fixed	Lithium N.L.G. #2 EP Purge Old Grease	Monthly or Every 25 Hours, Whichever Occurs First



A large red graphic consisting of two curved, overlapping shapes that form a partial circle around the central text.

SECTION 1: HYDRAULIC SYSTEM

- Hydraulic System - General 1-2
- Hydraulic Fluid 1-3
- Hydraulic Fluid Reservoir 1-6
- Hydraulic Pump 1-7
- Wheel Drive 1-7
- Parking Brake and Towing Circuit 1-14
- Emergency Systems And Procedures 1-15
- Steering Circuit 1-16
- Platform Lift Circuit 1-18
- Optional Outriggers 1-20
- Cylinder Repair 1-21
- Hydraulic Manifold 1-24



HYDRAULIC SYSTEM - GENERAL

The hydraulic system is an open center, open- loop type. Generally in this type of system, hydraulic fluid is provided by a variable displacement, pressure compensated, piston type pump which is directly coupled to the engine. As the engine turns, the hydraulic pump drains oil from the reservoir and pumps this fluid to the valve packages.

If no function is selected to perform, the pump remains on standby and no fluid is pumped through the manifold. Each function has a maximum pressure control limit set by pressure relief valve.

Hydraulic integrated circuit, generally known as the manifold system (valve type) is designed to control all or part of machine functions by integrating various hydraulic cartridge valves into a manifold to provide directional, pressure, flow, and load control.

HYDRAULIC FLUID

Handling Precautions



PERSONS IN REGULAR CONTACT WITH MINERAL-BASED HYDRAULIC FLUID NEED TO BE AWARE OF THE IMPORTANCE OF THOROUGH HYGIENE, AND THE PROPER METHODS FOR HANDLING MINERAL OILS IN ORDER TO AVOID POTENTIAL HAZARDS TO HEALTH.

If mineral- based hydraulic fluid is **SPLASHED INTO THE EYES**, it must be **WASHED OUT THOROUGHLY** using abundant quantities of water. If irritation persists, medical advice should be sought.



HYDRAULIC FLUID UNDER PRESSURE CAN PENETRATE AND BURN SKIN, DAMAGE EYES, AND MAY CAUSE SERIOUS INJURY OR BLINDNESS.

FLUID LEAKS UNDER PRESSURE MAY NOT ALWAYS BE VISIBLE.

Fluid Recommendations

MEC recommends the use of **Mobil 424** hydraulic fluid. Do not substitute with lower grade oils as pump damage may result.

Hydraulic Fluid Analysis

Use the following as a guide to determine when analysis of the hydraulic fluid is necessary:

- Anytime the hydraulic pump is replaced.
- If fluid discoloration is noticed in the hydraulic reservoir sight gauge tube.
- If after the first 50 hours of operation, the hydraulic filter element is plugged.
- Anytime the hydraulic filter element shows signs of metal contamination.
- Once every six (6) months, under normal operating conditions.
- Every three (3) months, in extremely dusty or dirty operating conditions.

The hydraulic fluid analysis must be done by a qualified laboratory. Always provide the following information with the test sample.

- Type of hydraulic fluid (see lubrication chart for recommended hydraulic fluid and/or your records).
- Model and Serial number of machine from which sample was taken.
- Purpose of analysis: pump failure, discoloration, etc.
- Type of analysis: complete to show additive breakdown, acid buildup, viscosity, type and percent of contaminants; also, comparison to new fluid and recommendations.

Following the above guidelines will prevent premature failure of pumps, cylinder seals, drive motors, and unnecessary downtime.

If system flushing and replacement of fluid is recommended, refer to the flushing procedure.

System Flushing Procedure

1. With platform fully down, drain hydraulic fluid from hydraulic reservoir into a clean, empty container. Use an oil filter cart so the fluid may be reused if analysis is good.
2. When the hydraulic reservoir is empty, remove suction strainer and hoses.
3. Remove the bypass filter and hose.
4. Flush the hoses with clean hydraulic fluid.
5. Discard old bypass filter element and replace.
6. Flush out the tank with hoses removed from the hydraulic reservoir.
7. Reinstall all hoses removed in the previous steps.
8. Fill hydraulic reservoir with filtered, fresh hydraulic fluid (refer to Lubrication Chart).
9. Loosen output hose fittings at pump to flood with hydraulic fluid. Tighten fittings.
10. Start up the machine. Briefly operate all functions. Two or three lift cycles may be necessary to purge all air from lift cylinder(s).
11. When the above procedures have been completed, fill hydraulic reservoir to full mark on sight gauge.
12. Check all leaks and correct as necessary. Machine is now ready to be placed back in operation.

NOTE: AVOID MIXING PETROLEUM AND SYNTHETIC BASE OILS. IT IS NOT ADVISABLE TO MIX OILS OF DIFFERENT BRANDS OR TYPES, EXCEPT AS RECOMMENDED.



HYDRAULIC FLUID RESERVOIR

This consists of the tank, a filler cap with breather, a drain plug, a sight gauge, and a bypass filter with a 10 micron filter element.


- Check tank for signs of leakage, every week.

Hydraulic Reservoir Assembly

All machines are produced with a filter. It is a 10 micron spin-on, bypassing filter. When the filter is clogged, hydraulic flow bypasses the filter element. The filter element must be changed every six (6) months or 500 hours. Extremely dirty conditions may require that the filter be replaced more often.



BEWARE OF HOT OIL. CONTACT WITH HOT OIL MAY CAUSE SEVERE BURNS.



HYDRAULIC PUMP

Note: Refer to *Hydraulic Manifold* and *Relief Pressure Adjustment Procedure*.
Refer to *Section 3* for Remove and Replace instructions.

An internal combustion engine drives a variable displacement axial piston pump. Flow is proportional to drive speed and displacement. The pump is not serviceable. A faulty pump must be replaced.

WHEEL DRIVE

Note: Refer to *Section 3* for Remove and Replace instructions.

There are four (4) hydraulic, fixed-displacement gear wheel motors to provide power to all four wheels [two (2) front and two (2) rear].

Dynamic Braking Circuit

The two rear wheel motors have integral brakes that are spring held. Hydraulic pressure developed in the drive circuit, during drive mode, releases the brakes. A fixed orifice in the brake circuit controls the deceleration rate and initiates a smooth stop.



Front Wheel Motors (DT-701)

Housing and Shaft Disassembly

1. Remove all shaft related components from the shaft. Secure the motor housing in a vise.
 - Remove the retaining ring from the groove in the pilot of the housing.
 - Remove the spacer from the housing.
 - Remove the shaft from the housing.
 - Remove the bearing, thrust bearing, and two (2) thrust washers from the shaft.
2. Being careful not to drop bearing rollers,
 - pry out the shaft seal, backup seal, and dust seal from the bearing assembly.

NOTE: It is not necessary to remove the metal backup ring from the bearing to service the motor.

- remove the high pressure seal from the groove in the pilot of the housing.
 - discard shaft seal, backup seal and high pressure seal.
3. Clean all parts in an oil-based solvent and dry using compressed air.

Housing and Shaft Assembly

1. Apply a light coating of oil to all new seals prior to installation.
 - Install the high pressure seal into the groove in the pilot of the housing.
2. Place the shaft on a clean, flat surface with the output end facing up.
 - Place the first thrust washer, thrust bearing and second thrust washer over the shaft.
 - Using plastic installation sleeve, place the shaft seal over the shaft with the lip facing down.
 - Repeat for the backup seal, making sure the lip faces down.
 - If the metal backup ring came out in *Step 2* above, place it over the shaft with the large O.D. facing down.
 - Lightly grease the bearing and place it over the shaft with the large O.D. facing down.
 - Use an arbor press to carefully press the bearing down to press the seal assembly into the bearing.
3. Place the shaft assembly into the housing.
 - Place the dust seal over the shaft with the lip facing up.
 - Place the bearing spacer and retaining snap ring over the shaft.

NOTE: It may be necessary to lightly tap the snap ring and bearing spacer to allow the retaining ring to seat properly.

- Replace all shaft related components (i.e. keys, wire rings, nuts).

Motor Section Disassembly

1. Make a "V" shaped set of alignment marks on the endcover and housing to aid in the reassembly process.
 - Clamp the motor housing in a vise with the shaft facing down.
2. Remove the seven (7) bolts that hold the motor assembly together.
 - Carefully remove the endcover - *be aware that the piston and spring may fall out.*


- Carefully remove the piston from the endcover and set it aside.
 - Remove and discard the O-ring seal and backup seal.
 - Remove the spring and set it aside.
3. Lift commutator container and commutator from the motor and set aside.
 - Place commutator on a flat, clean surface with the seal facing up.
 - Gently tap on the seal with a small screwdriver until the opposite side of the seal lifts from the groove. Remove the seal and discard.
 4. Remove the manifold, rotor set, and divider plate. Remove all seals and discard.

CAUTION: Do not allow rollers to drop from the rotor assembly when removing the rotor from the motor.

- Remove the drive link from the motor and set aside.
5. Clean all parts in an oil-based solvent and dry using compressed air. Apply a light coating of oil to all new seals prior to installation.

Motor Section Assembly

1. Install the drive link into the end of the shaft with the tapered end facing up.
 - Place the rear housing seal in the groove in the housing.
 - Place the divider plate onto the housing.
 - Place body seals in grooves in both sides of the rotor.
 - Place the rotor onto the housing with the side of the rotor with chamfer in splines facing the housing.
 - Place the manifold over the rotor with the seal-groove side up.
 - Install the manifold seal
2. Install the commutator seal into the commutator with the metal side facing up.
 - Use finger pressure to press the seal down flush with the surface of the commutator.
 - Place the commutator onto the manifold and then place the commutator onto the protruding end of the drive link. Make sure that the seal side is facing up.
3. Install the remaining body seal in the groove on the endcover.
 - Install the piston spring into the endcover, then the white backup seal followed by the O-Ring seal.
 - Line up the alignment pin with the hole in the endcover and press the piston into the endcover.
 - While holding the piston in place, lower the endcover assembly onto the motor. Align the "V" shaped marks that were made on the housing and endcover before disassembly.
4. Install the seven (7) assembly bolts.
 - Tighten bolts in sequence (see illustration)
 - Pre-torque to 10 ft. lbs. (13,6 Nm).
 - Final torque to 50 ft. lbs (67,8 Nm).



DT701 Series Motor Components

- | | | |
|-------------------------|--------------------------|-------------------------|
| 1. * Dust Seal | 12. Retaining Snap Ring | 23. Commutator Assembly |
| 2. * High Pressure Seal | 13. Bearing Spacer | 24. Endcover Piston |
| 3. * Metal Backup Shim | 14. 1.5" Bearing | 25. Piston Spring |
| 4. * Backup Seal | 15. Thrust Washers (2) | 26. Endcover |
| 5. * Shaft Seal | 16. Thrust Bearing | 27. I.D. Tag Assembly |
| 6. * Housing Seal | 17. Housing | 28. Assembly Bolts (7) |
| 7. * Body Seals (3) | 18. Rear Housing Bearing | 29. Shaft |
| 8. * Manifold Seal | 19. Drive Link | 30. Shaft Key |
| 9. * Commutator Seal | 20. Divider Plate | 31. Shaft Nut |
| 10. * O-Ring Seal | 21. Rotor Assembly | |
| 11. * Backup Seal | 22. Manifold | |

* Contained in seal kit



Rear Wheel Motors with Brakes (DT-710)

Disassembly

1. Make a "V" shaped set of alignment marks on the endcover and housing to aid in the reassembly process.
 - Clamp the motor housing in a vise with the shaft facing down.
2. Remove the seven (7) bolts that hold the motor assembly together.
 - Carefully remove the endcover - *be aware that the piston and spring may fall out.*
- Carefully remove the piston from the endcover and set it aside.
 - Remove and discard the O-ring seal and backup seal.
 - Remove the spring and set it aside.
3. Lift commutator container and commutator from the motor and set aside.
 - Place commutator on a flat, clean surface with the seal facing up.
 - Gently tap on the seal with a small screwdriver until the opposite side of the seal lifts from the groove. Remove the seal and discard.
4. Remove the manifold, rotor set, and divider plate. Remove all seals and discard.

CAUTION: Do not allow rollers to drop from the rotor assembly when removing the rotor from the motor.

- Remove the drive link from the motor and set aside.
5. Clean all parts in an oil-based solvent and dry using compressed air.

Assembly


1. Apply a light coating of oil to all new seals prior to installation.
2. Place the housing on a clean, flat surface with the output end facing up.
 - Install the dust seal with the lip on the seal facing up.
 - Clamp the housing in a vise with the pilot on the housing facing down.
 - Install the metal backup shim into the bore.
 - Install the backup seal into the housing bore with the lip on the seal facing up.
 - Install the shaft seal into the housing bore with the lip on the seal facing up.
 - Refer to illustration for seal orientation.
3. Install the bearing shims (not shown in illustration) in housing.
 - Install housing bearing.
 - Install the shaft being careful not to cut seal lip with the shaft keyway.
4. Locate the thick disk stamping and set it aside.
 - Install one (1) disk stamping into the housing. Make sure that lugs or splines engage those in the housing.
 - Install one (1) friction disk engaging splines on the disk with those on the shaft.
 - Alternate disk stampings and friction disks until all disks except the thick disk stamping are installed.
 - Install the thick disk stamping on top of the disk assembly.



5. Install the small O-Ring seal and large O-Ring seal into corresponding grooves in the piston.
 - Install small seal and large seal in corresponding grooves over the O-Ring seals.
 - Thoroughly coat the seals and sealing surfaces of the housing with clean oil.
 - Install the piston into the housing with the large O.D. side facing up.
 - Evenly press the piston down. Be careful not to pinch the seals.

IMPORTANT: If the disks and disk stampings are going to be replaced, the stack up on the new disks must be between .620 and .630 (15,7mm and 16mm) (see illustration).

6. Install spring on top of the piston.
 - Install O-Ring seal in groove in the rear surface of the housing.
 - Install the rear shaft bearing. Make sure that the snap ring that retains the bearing rolls faces out.
 - Place the rear housing onto the front housing and line up bolt holes.
 - Hold the motor assembly together, remove from the vise and place in an arbor press.
 - Press down on the rear housing until it contacts the front housing and lock the press
 - Install eight (8) capscrews and torque to 45 ft. lbs. (61 Nm).
7. Install the drive link into the end of the shaft with the tapered end facing up.
 - Place the body seals in the grooves in both sides of the rotor.
 - Place the rotor onto the housing with the side of the rotor with the chamfer in the splines facing the housing.
 - Place the manifold over the rotor with the seal groove side up.
 - install the manifold seal.
8. Install the commutator seal into the commutator with the metal side facing out.
 - Use finger pressure to press the seal down flush with the surface of the commutator.
 - Place the commutator onto the manifold and then place the commutator onto the protruding end of the drive link. Make sure that the seal side is facing up.
9. Install the remaining body seal in the groove on the endcover.
 - Install the piston spring into the endcover, then the white backup seal followed by the O-Ring seal.
 - Line up the alignment pin with the hole in the endcover and press the piston into the endcover.
 - While holding the piston in place, lower the endcover assembly onto the motor. Align the "V" shaped marks that were made on the housing and endcover before disassembly.
10. Install the seven (7) assembly bolts.
 - Tighten bolts in sequence (see illustration)
 - Pre-torque to 10 ft. lbs (13,6 Nm).
 - Final torque to 50 ft. lbs (67,8 Nm).



DT710 BRAKE MOTOR COMPONENTS

- | | |
|------------------------------|-------------------------|
| 1. Dust Seal | 20. Piston |
| 2. Metal Backup Shim | 21. Springs (25) |
| 3. Backup Seal | 22. Spacer Shims (1-3) |
| 4. Shaft Seal | 23. Rear Housing |
| 5. Small Piston O-Ring Seal | 24. Capscrews (8) |
| 6. Small Piston Seal | 25. Drive Link Spacer |
| 7. Large Piston O-Ring Seal | 26. Drive Link |
| 8. Large Piston Seal | 27. Rotor Assembly |
| 9. O-Ring Seal | 28. Manifold |
| 10. Body Seals (3) | 29. Commutator Assembly |
| 11. Manifold Seal | 30. Endcover Piston |
| 12. Commutator Seal | 31. Piston Spring |
| 13. O-Ring Seal | 32. Endcover |
| 14. Backup Seal | 33. I.D. Tag Assembly |
| 15. Housing | 34. Assembly Bolts (7) |
| 16. Shaft Bearing | 35. Shaft |
| 17. Friction Disks (10) | 36. Shaft Key |
| 18. Disk Stampings (9) | 37. Shaft Nut |
| 19. Thick Disk Stampings (2) | |



PARKING BRAKE AND TOWING CIRCUIT

Note: Refer to *Parts Section 5* for hose routing.


Machine can be winched or moved short distances in case of power failure at speeds not to exceed 5 MPH (8.05 kph).



PRIOR TO MANUALLY RELEASING BRAKES, INSURE WHEELS ARE CHOCKED TO PREVENT MACHINE FROM MOVING.

Release Brakes Before Towing:

- Push in the manual Brake Release valve located on the main manifold.
- Using the hand pump on the manifold, pump valve until pressure is built.
- Machine is now ready for towing.



AFTER RELEASING THE BRAKES, THERE IS NOTHING TO STOP THE MACHINE'S TRAVEL. MACHINE WILL ROLL FREELY ON SLOPES. BE ON GUARD AGAINST RUNAWAY.

To Reset Brakes:

- Brakes will reset when drive function is activated, or reset manually by pulling out the manual brake release valve.

EMERGENCY SYSTEMS AND PROCEDURES



IF THE CONTROL SYSTEM FAILS WHILE THE PLATFORM IS ELEVATED, HAVE AN EXPERIENCED OPERATOR USE THE EMERGENCY LOWERING PROCEDURE TO SAFELY LOWER THE PLATFORM.


DO NOT ATTEMPT TO CLIMB DOWN BEAMS (SCISSORS) ASSEMBLY.



BEFORE LOWERING PLATFORM, RETRACT THE DECK EXTENSION.

Emergency Lowering - 3072RT


Emergency Down system is used to lower the platform in case of power or valve failure. To lower the platform, pull the red "T" handle located at the rear of the machine. Lowering stops when you release the "T" handle.



Emergency Lowering - 3772RT

The Emergency Down System is used to lower the platform in case of power or valve failure. To lower the platform, perform the following steps:

1. Push down on the toggle switch and hold it to lower the platform to the desired height.
2. Once the platform is fully lowered, release the toggle switch to close the valve




STEERING CIRCUIT

Note: Refer to *Hydraulic Manifold* and *Relief Pressure Adjustment Procedure*.
Refer to *Section 3* for Remove and Replace instructions.
Refer to *Parts Section 5* for hose routing.

The steering system consists of the following components:


- The wheel motor housings have pivots on the top and bottom, and are mechanically linked together via a tie-rod.
- Steering is accomplished hydraulically by using two (2) double-acting cylinders, and a 4-way 3-position solenoid-operated, hydraulic directional control cartridge valve.
- Maximum steering pressure is limited by the relief valve (refer to *Relief Pressure Adjustment Procedure*).



Steer Cylinder

Note: Refer to *Cylinder Repair*.
Refer to *Section 3* for Remove and Replace instructions.
Refer to the *Parts Manual, Section 5* for parts list.

There are two (2) cylinders utilized in the steering system. These cylinders are a double acting type which requires oil flow to operate the cylinder rod in both directions. Directing oil forces the piston to travel towards the rod end of the barrel, extending the cylinder rod. By directing oil to the rod side of the cylinder the piston will be forced in the opposite direction and the cylinder rod will retract.



PLATFORM LIFT CIRCUIT

Note: Refer to *Hydraulic Manifold* and *Relief Pressure Adjustment Procedure*.
Refer to *Section 3* for Remove and Replace instructions.

- The lift system uses the hydraulic pump to obtain proportional lifting function controlled by the lift valve and proportional valve.
- Lowering is single speed controlled by the holding valves on the lift cylinder(s) and regulated by a fixed orifice located on the lift cylinder(s).
- Platform capacity is limited by a hydraulic relief valve in the lift circuit. (Refer to Machine Specifications or the Hydraulic Schematic for proper setting).

Lift Cylinder

Note: Refer to *Cylinder Repair*.

3072RT

One (1) single acting type hydraulic cylinder.


The cylinder has an integrated 2-position, 2-way solenoid operated platform lower valve for holding the platform in position. The valve is also externally actuated via a cable for manually lowering the platform.


3772RT

Two (2) single acting type hydraulic cylinders.

Each cylinder has an integrated 2-position, 2-way solenoid operated platform lower valve for holding the platform in position. The valves are also externally actuated via a toggle switch for manually lowering the platform.

The normally closed holding valve prevents retraction of the cylinder rod should a hydraulic line rupture or a leak develop between the cylinder and its related control valve.





OPTIONAL OUTRIGGERS


Note: Refer to *Section 3* for detailed description and troubleshooting.
Refer to *Cylinder Repair*.

Outrigger Hydraulic Manifold

The Optional outrigger manifold is located in the Control Module behind the Lower Control Box.

Cylinders



Four (4) double acting type hydraulic cylinders.



CYLINDER REPAIR



CYLINDERS ARE HEAVY. SUPPORT CYLINDERS BEFORE REMOVING HARDWARE THAT SECURES THE CYLINDER TO THE MACHINE.



Removal

Note: Refer to *Section 3* for Remove and Replace instructions, and the *Parts Manual* for a list of hardware specific to the cylinder being repaired.

1. Tag hoses for proper reassembly.
2. Disconnect hoses and IMMEDIATELY cap the openings to prevent contamination.
3. Remove cylinder from the machine as described in *Section 3*.

Preparation



Take care not to damage rod surface and guard against dirt or other foreign objects entering system.

1. Drain all oil from cylinder.
2. Clean all dirt and grit from outside of cylinder.
3. Insert cylinder into vise.

Cylinder Disassembly

1. Remove the head from the cylinder body.
2. Remove the shaft assembly from the barrel, pulling in a straight line, so as not to scar the internal parts.
3. Insert shaft into a **soft jawed** vise so that the head and piston can be removed. Be sure the shaft and vise are both clean before using.
4. Remove nut at the end of the shaft and pull head and piston off of the rod.
5. Remove all seals from the head and piston using a non-sharp seal tool. These tools are available from various seal suppliers.
9. Clean all oil and debris off of the head, piston, shaft, collar and barrel using solvent, rags, and an air hose.
10. Inspect parts for scratches, pits or polishing. Check seal groves and sealing surfaces.
 - a. Scratches or pits deep enough to catch the fingernail are unacceptable; replace the cylinder.
 - b. Polishing is a sign of uneven loading. Check for roundness. If a polished surface is not round within .007 in. (0,18 mm) replace the cylinder.

Cylinder Assembly

CAUTION:

- To insure a quality repair, cylinder parts must be thoroughly cleaned, dry, and free of solvents, and assembly must be performed in a clean area free of dust and contamination.
- To avoid cutting the seals, do not use sharp edged tools during seal replacement. After installing seals allow at least one hour for the seals to restore to their original shape before assembling the cylinder.
- Torque all hardware according to the *Hydraulic Components Torque Table* unless otherwise specified.

1. Lubricate all components with clean hydraulic fluid.
2. Install new seal kit components. Install all seals on the head and piston using the non-sharp seal tool.
3. Place a small amount of oil on the inside seals of the head and reinstall it on the shaft, by slipping head over the piston end of the shaft being very careful not to damage the inside seals.
4. Place a small amount of oil on the inside seals of the piston and reinstall it on the shaft by slowly twisting the piston on over the threads of the shaft being very careful not to damage the inside seals.
5. Reinstall the shaft nut; torque 1 ½" nut to 160 ft.-lbs.
6. Grease the outside seals of the head and piston.
7. Reinstall the shaft into the barrel of the cylinder and push in until groove of the head lines up with the slot in the barrel.
17. Reinstall the cylinder retainer. Installation is reverse of removal.
18. Cycle the cylinder using air to check for proper operation.

NOTE: It is very important to keep all parts clean when working with hydraulic cylinders, even one small piece of dirt or grit can damage the cylinder.

HYDRAULIC MANIFOLD

- Note:** Refer to *Section 3* for Remove and Replace instructions, and the *Parts Section* for a list of hardware.
Tag all components as they are removed so as not to confuse their location during reassembly.

Hydraulic Manifold Removal

1. Disconnect the negative battery terminal.
2. Tag and disconnect the solenoid valve leads.
3. Tag and disconnect hydraulic hoses, and IMMEDIATELY cap the openings to prevent contamination.
4. Remove the bolts that hold the manifold to the mounting bracket.
5. Remove the manifold block.

Disassembly

1. Remove coils from solenoid valves.
2. Remove valves.
3. Remove fittings, plugs, springs, balls, and orifices.

Cleaning and Inspection

1. Wash the manifold in cleaning solvent to remove built-up contaminants, then blow out all passages with clean compressed air.
2. Inspect the manifold for cracks, thread damage and scoring where O-rings seal against internal and external surfaces.
3. Wash and dry each component and check for thread damage, torn or cracked O-rings, and proper operation.
4. Replace defective parts and O-rings.



Assembly

Note: Lubricate all O-rings before installation to prevent damage to the O-ring. Seat balls in manifold block by lightly tapping on the ball with a brass drift punch.

1. Install fittings, plugs, springs, balls, and orifices. Use one drop of Loctite #424 or equivalent thread locker on each screw-in orifice.
2. Install valves.

Installation

1. Attach manifold assembly to mounting plate with mounting bolts.
2. Connect solenoid leads (as previously tagged).
3. Connect hydraulic hoses (as previously tagged). Be certain to tighten hoses.
4. Connect the battery.
5. Operate each hydraulic function and check for proper operation and leaks.
6. Adjust valve pressures.





A large, stylized red graphic consisting of two curved, overlapping shapes that form a partial circle, framing the central text.

SECTION 2: ELECTRICAL SYSTEM

- Electrical System - General 2-2**
- Deutsch Connectors 2-3**
- Battery 2-4**
 - Battery Preventative Maintenance: 2-5
 - Battery Replacement 2-6
- Alarms and Switches 2-7**
 - Tilt Alarm 2-8
 - Relays 2-9
- Limit Switch 2-10**
- Optional Outriggers Switches 2-10**
- Continuity Checks 2-11**



ELECTRICAL SYSTEM - GENERAL

The electrical control system consists of a base control station and a platform control station.

Base Control Station

The base control station will operate all functions except steering and drive.

Platform Control Station

The platform control station will operate all functions including drive/steer and lift/lower. Momentary bidirectional rocker switch on the drive controller handle (joystick) provides the steering function. The control system for operation of drive/steer and lift/lower are electric-over-hydraulic type. The drive system is a proportional system controlled by position and direction of the upper control box controller handle (joystick).

DEUTSCH CONNECTORS

Deutsch connectors used on MEC equipment is designed so that individual parts may be replaced without replacing the entire component. Special tools and detailed instructions are provided in Deutsch Connector field kits.

Male Plug Connector

- Use the flat end of the Removal Tool or a flat blade screwdriver to pry the locking wedge from the connector, taking care not to damage the Sealing Gasket.
- Inspect and replace damaged parts.
- Replace or re-crimp wires and contacts.

Female receptacle Connector

- Use the notched end of the removal tool or a wire hook to pull the locking wedge from the connector
- Replace worn or damaged parts
- Replace or re-crimp wires and contacts.

Locking Fingers


- Remove the locking wedge as outlined above.
- Using the removal tool or a flat blade screwdriver, push the Locking Fingers aside to release the contact.
- Pull the wire and contact out of the connector.

Heavy Duty Plug

- Slide the removal tool along the wire to be replaced and push into the connector to release the contact.
- Pull the wire and contact out of the plug.

Crimping

- Strip 1/4 in. (6mm) insulation from the wire.
- Insert the contact into the crimping tool and insert the stripped wire into the contact making sure no wires are outside the contact barrel.
- Close the handles of the crimping tool, then release the handles to remove the crimped contact.



BATTERY



CHARGING BATTERIES CREATE EXPLOSIVE HYDROGEN GAS. KEEP SPARKS, FLAMES AND SMOKING MATERIALS AWAY FROM BATTERIES.

ALWAYS WEAR SAFETY GLASSES WHEN WORKING WITH BATTERIES.

BATTERY FLUID IS CORROSIVE. THOROUGHLY RINSE SPILLED FLUID WITH CLEAN WATER.

REPLACE WITH MANUFACTURER APPROVED BATTERIES.

BEFORE DISCONNECTING THE BATTERY NEGATIVE (-) LEAD, MAKE SURE THAT ALL SWITCHES ARE OFF. IF ON, A SPARK WILL OCCUR AT THE GROUND TERMINAL THAT COULD IGNITE HYDROGEN GAS OR FUEL VAPORS.

A 12 volt battery supplies the electrical power required to operate the electrical circuits.

Battery Maintenance (in storage)

Follow these procedures for maintenance of battery on a machine not in use:

- Keep battery clean. Electrolyte of batteries should be checked regularly and kept at proper level.
- Never stack one battery directly on top of another because post or container damage can result. If batteries are stored individually, place supporting boards between layers. Rotate stock so that the oldest batteries are used first.
- Batteries should be kept fully charged. A battery, while in storage, should be recharged to full charge at recommended intervals.

A battery fully (100%) charged at 80°F (26.6°C)

- drops to 65% at 32°F (0°C)
- drops to 40% at 0°F (-32°C)

Recommended Intervals

If Stored At:	Recharge:
Below 40°F (4°C)	None required
Above 60°F (15°C)	Every month
40°-60°F (4°-15°C)	Every 2 months

Battery Maintenance (in use)

Check battery and surrounding area for signs of damage or corrosion.

Check battery terminals for:

- Corrosion: Regularly clean connections and apply a nonmetallic grease or protective spray to retard corrosion.
- Loose connections: Be sure all cable connections are tightly secured, and that good contact is made with terminals.
- Broken or frayed cables: Be sure all connections are good and that no loose or broken wires are exposed. Replace as necessary.

Check battery electrolyte level. Replenish the electrolyte, if necessary. Remove vent caps before filling, and USE ONLY DISTILLED WATER. DO NOT OVERFILL. Fill to level indicator (or ½ inch over the top of separators, if there is no level indicator). Fill after charging to prevent overflow of acid due to expansion. Do not use a hose to add water to batteries.

Allowing the electrolyte level to drop below the top of the separators will lead to shortened battery life.

Excessive water usage can indicate that a battery has been overcharged, has been subjected to excessively high temperatures, or is nearing the end of its service life.

Battery Preventative Maintenance:

Every 15 hours (after battery has been charged), spot-check the specific gravity of two or more cells. A fully charged battery should indicate 1.28 specific gravity. If low readings are noted, check the following:

- Check terminals for corrosion, loose connections and broken or frayed cables.
- Check all cells with a hydrometer for variance in specific gravity. A variation of 0.03 points or more between cells is a cause for concern. Mark the low cells.

Recheck specific gravity of all cells after recharging. Wash the top of the battery, making sure all vents are in place. Do not allow cleaning water or other foreign matter to enter the cells. Use a solution of bicarbonate soda (5 tsp. of baking soda per quart of warm water) and water to wash the battery if there is an accumulation of acid.

Battery Specific Gravity and Voltage Table

	SPECIFIC GRAVITY		VOLTS DC	
		EACH CELL	PER CELL	12V BATTERY
Fully Charged		1.280	2.10	12.60
Fully Discharged		1.130	1.75	10.50

Battery Replacement

To remove battery, follow these procedures.



BEFORE REMOVING THE BATTERY FROM THE MACHINE, TURN OFF THE SELECTOR/ KEY SWITCH. THERE SHOULD BE NO POWER.

Battery is located in the Control Module of the machine.

Always disconnect the negative battery cable first.

Remove bolts holding battery. Lift the battery from the compartment. Put the battery to the side and dispose of properly.



Prevent damage to battery and/or electrical system;

- **Always disconnect the negative battery cable first.**
- **Always connect the positive battery cable first.**

To install battery, reverse the process by positioning the battery in the compartment securely with hold down bolts. Connect battery cables. Always connect the positive cable first.

ALARMS AND SWITCHES

Emergency Stop Button

There are two red emergency stop buttons: one located on the platform control console and the other on the base control panel. This stop button, when in the “OUT” (ON) position, provides power to the desired control station. Also, the stop button, in the event of an emergency can be used to turn off the power by pushing “IN” (OFF). All functions stop immediately when depressed.

Turn the button clockwise to reset.

NOTE: As a safety feature, selecting and operating the base controls will override the platform controls, except the platform emergency stop button. The base control emergency stop button will stop all machine operations, even if the selector switch is switched to platform controls.



Selector Switch

Machine can be operated from the base/ground or platform controls. Activation of one or the other is achieved with this switch.

With the platform controls selected, from the base control panel, if the platform up/lower function is operated there should be NO movement. Similarly with the base controls selected, from the platform control console if any machine function is operated, there should be NO movement.

Diagnostic LED's

There are Diagnostic LED's located on the Printed Circuit Board inside the Base Control box. Each LED represents a function. When the LED is ON the function is ENERGIZED. Refer to the *DIAGNOSTIC LED'S* label to identify the LED function.



Tilt Alarm


The tilt sensor is located in the Control Module.

Tilt Alarm Audible

An audible warning is activated once machine is in the raised position and reaches an unsafe angle; all functions are disabled in this condition except Platform Lower.

Tilt Alarm Test

This can be tested by manually tipping the sensor. This “Push-To-Test” feature enables tilt alarm to be tested without losing its adjustment. Individually push down on each of the three fastened corners of the tilt alarm. There should be enough travel to cause the alarm to sound as each corner is pressed. (There is approximately a three second delay). If the alarm does not sound, the flange nuts have been tightened too far. Loosen the nut on the 90° corners and repeat this test procedure.



Tilt Alarm Sensor Adjustment

- Before attempting to adjust the alarm, park the machine on a firm, flat, level surface. Use of an inclinometer is recommended to ensure front and rear of base is level.
- Adjust the three flange nuts until the bubble on top of the sensor is centered.
- Check that the electrical connections are correct and secured tight.

Master Disconnect Switch

Battery disconnect is provided in the Control Module to facilitate servicing and also to prevent unauthorized use of vehicle by using a padlock (to provide security).

Movement Alarm - Light (optional)

This light is activated as soon as the platform control console joystick (controller) lever is moved off the center “Neutral” position.




THE MOVEMENT ALARM IS PROVIDED FOR YOUR PROTECTION, AND PROTECTION OF PERSONS WORKING IN THE IMMEDIATE AREA. DISABLING THIS IMPORTANT SAFETY DEVICE MAY RESULT IN SERIOUS INJURY OR DEATH.

Relays

There are relays located inside the control module and inside the Upper Controls. (Refer to the Section 5 for relay functions and interconnect).


Upper Control Power Relay

Purpose: Cuts power to Upper Controls when Lower Controls are selected.



Torque/Speed Relay

Purpose: Disperses power to Torque Solenoid Valve when high speed or low speed is selected.




Outrigger Relay (option)

Purpose: Cuts power to Lift circuits until Outriggers are fully deployed and in firm contact with the ground.

Throttle Relay

Purpose: The electric throttle solenoid receives its power through the Throttle Relay.



Glow Plug Relay

Purpose: The diesel engine glow plug receives its power through the Glow Plug Relay.

LIMIT SWITCH

The Limit Switch indicates Platform Height above approximately 10 feet (3m). The switch operates in conjunction with the circuit board located in the lower control box and the proportional circuit board located in the upper control box.

Lower Controls Circuit Board


When the platform is elevated above 10 feet (3m) the limit switch is activated, causing the circuit board to;

- enable tilt sensor cutout operation
- lockout outrigger operation.

Upper Controls Proportional Circuit Board

When the platform is elevated above 10 feet (3m) the limit switch is activated, causing the proportional circuit board to;

- enable elevated drive speed.



OPTIONAL OUTRIGGERS SWITCHES


If the machine is equipped with outriggers, each of the four (4) outriggers has a Stowed Switch and a Pressure Switch.

Outrigger Stowed Switch

- Indicates full retraction of the outrigger cylinder.
- **Drive Function:** The machine will drive when the Outrigger Stowed Switch on all four (4) outriggers is engaged. If one (1) or more Outrigger Stowed Switch is open (not engaged) the machine *will not drive*.
- **Lift Function:** If one (1) or more Outrigger Stowed Switch is open (not engaged) the machine *will not lift* unless all four (4) outriggers are fully deployed.

Outrigger Pressure Switch

- Indicates full deployment of the outrigger.
- **Lift Function:** When deployment begins the Outrigger Stowed Switches open and lift function is disabled. When all four (4) outriggers reach full deployment the Outrigger Pressure Switches close (engage) and lift function is restored.



CONTINUITY CHECKS

Check Toggle Switch:

- Disconnect wires and connect one probe of ohm meter to the connection on toggle switch and other probe on other connection.
- When toggle is open, there should be no reading, and when closed there should be a low reading.

Check Selector Switch


- Disconnect wires and connect one probe to common of switch and the other to normally open terminal.
- With the switch flipped, there should be a low resistance.

Check Emergency Stop Button

- Disconnect wires and connect one probe of ohm meter to connection on button and other probe on other connection.
- There should be no reading with the button pressed and a low resistance with it reset.


Check Relay Operation (refer to illustration)

- With the #85 terminal grounded, apply voltage to #86 terminal connection.
- Confirm normally closed (#87A) contacts are opening. Continuity with #30 will be broken.
- Confirm normally open (#87) contacts are closing. Continuity with #30 will be made.




Check Limit Switch Operation (refer to illustration)

- Loosen cover screw and lift cover from switch.
- Mark and disconnect wires.
- With one probe of ohm meter to "A" and other probe to "B", release the plunger.
 - Low resistance should be seen. Same result should be seen between "C" and "D".
- With one probe of ohm meter to "A" and other probe to "B", depress the plunger.
 - High resistance should be seen. Same result should be seen between "C" and "D".
- "E" and "F" should show opposite results as seen on previous tests though there may not be any circuits on these terminals.







SECTION 3: MECHANICAL COMPONENTS

Torque Specifications	3-2
Mechanical Components	3-3
Base/ Undercarriage	3-3
Raising the Machine	3-3
Tires	3-4
Drive Motors	3-5
Steer Cylinder	3-6
Hoses and Cables	3-7
Platform Removal	3-7
Lift Cylinder Removal and Installation	3-8
Scissor Beam Assembly	3-8
Engine Maintenance	3-9
Diesel Engine	3-9
Gasoline and Dual Fuel Engine	3-12
Outrigger Function	3-14
Outrigger Calibration	3-15
GP106 Outrigger Control Module Troubleshooting	3-17
Outrigger Module GP106 LED Flash Codes	3-18



TORQUE SPECIFICATIONS

Fasteners

Use the following values to apply torque unless a specific torque value is called out for the part being used.

AMERICAN STANDARD CAP SCREWS								METRIC CAP SCREWS									
SAE GRADE	5				8				METRIC GRADE	8.8				10.9			
CAP SCREW SIZE - inches -									CAP SCREW SIZE - millimeters -	 				 			
	TORQUE				TORQUE					TORQUE				TORQUE			
	FT. LBS		Nm		FT. LBS		Nm			FT. LBS		Nm		FT. LBS		Nm	
	MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX		MIN	MAX	MIN	MAX	MIN	MAX	MIN	MAX
1/4 - 20	6.25	7.25	8.5	10	8.25	9.5	11	13	M6 X 1.00	6	8	8	11	9	11	12	15
1/4 - 28	8	9	11	12	10.5	12	14	16	M8 X 1.25	16	20	21.5	27	23	27	31	36.5
5/16 - 18	14	15	19	20	18.5	20	25	27	M10 X 1.50	29	35	39	47	42	52	57	70
5/16 - 24	17.5	19	23	26	23	25	31	34	M12 X 1.75	52	62	70	84	75	91	102	123
3/8 - 16	26	28	35	38	35	37	47.5	50	M14 X 2.00	85	103	115	139	120	146	163	198
3/8 - 24	31	34	42	46	41	45	55.5	61	M16 X 2.50	130	158	176	214	176	216	238	293
7/16 - 14	41	45	55.5	61	55	60	74.5	81	M18 X 2.50	172	210	233	284	240	294	325	398
7/16 - 20	51	55	69	74.5	68	75	92	102	M20 X 2.50	247	301	335	408	343	426	465	577
1/2 - 13	65	72	88	97.5	86	96	116	130	M22 X 2.50	332	404	450	547	472	576	639	780
1/2 - 20	76	84	103	114	102	112	138	152	M24 X 3.00	423	517	573	700	599	732	812	992
9/16 - 12	95	105	129	142	127	140	172	190	M27 X 3.00	637	779	863	1055	898	1098	1217	1488
9/16 - 18	111	123	150	167	148	164	200	222	M3 X 3.00	872	1066	1181	1444	1224	1496	1658	2027
5/8 - 11	126	139	171	188	168	185	228	251									
5/8 - 18	152	168	206	228	203	224	275	304									
3/4 - 10	238	262	322	255	318	350	431	474									
3/4 - 16	274	302	371	409	365	402	495	544									
7/8 - 9	350	386	474	523	466	515	631	698									
7/8 - 14	407	448	551	607	543	597	736	809									
1 - 8	537	592	728	802	716	790	970	1070									
1 - 14	670	740	908	1003	894	987	1211	1137									

Torque values apply to fasteners as received from the supplier, dry or when lubricated with normal engine oil. If special graphite grease, molydisulphide grease, or other extreme pressure lubricants are used, these torque values *do not apply*.

Hydraulic Components

Use the following values to apply torque to hydraulic components. Always lubricate threads with clean hydraulic oil prior to installation.

TYPE: SAE PORT SERIES	CARTRIDGE POPPET		FITTINGS		HOSES	
	FT. LBS	Nm	FT. LBS	Nm	FT. LBS	Nm
#4	N/A	N/A	N/A	N/A	135 - 145	15 - 16
#6	N/A	N/A	10 - 20	14 - 27	215 - 245	24 - 28
#8	25 - 30	31 - 41	25 - 30	34 - 41	430 - 470	49 - 53
#10	35 - 40	47 - 54	35 - 40	47 - 54	680 - 750	77 - 85
#12	85 - 90	115 - 122	85 - 90	115 - 122	950 - 1050	107 - 119
#16	130 - 140	176 - 190	130 - 140	176 - 190	1300 - 1368	147 - 155

MECHANICAL COMPONENTS

Following is a description of the major mechanical components of the scissor lift.

Base/ Undercarriage



When steam cleaning the base/ undercarriage, cover electrical components to prevent water penetration.

Steam clean the base as necessary, and inspect all welds and brackets . Check for cylinder pins that turn in their mounting , which will indicate sheared retaining pins.

Raising the Machine



THE USE OF SUBSTANDARD LIFTING DEVICES AND/OR JACK STANDS MAY CAUSE THE MACHINE TO FALL RESULTING IN DEATH OR SERIOUS PERSONAL INJURY.

The following are needed to safely raise and support the machine;

- a jack with a lifting capacity of two (2) tons or more.
- jack stands with a rating of one (1) ton or more.

To raise the machine

1. Move machine to a firm level surface capable of supporting the weight of the machine.
2. Chock tires on one end of machine and raise the other end of machine.
3. If wheel is to be removed, loosen but **do not remove** lugs before raising the machine.
4. Position a jack at the end of the machine to be lifted, under a solid lifting point in the center of the frame.
5. Raise the machine and place two (2) suitable jack stands under solid support points at the outer ends of the frame.
6. Lower the machine to rest on the jack stands and inspect for stability.

To lower the machine

1. Tighten lugs to proper torque (refer to machine specifications).
2. Raise machine slightly and remove jack stands.
3. Lower the machine and remove the jack.
4. Remove chocks.

Tires

Inspect for cuts, chunking, side-wall damage, or abnormal wear. Any tire faults **MUST BE CORRECTED** before further machine operation. Refer to Parts Manual Section for replacement tires.



FAILURE TO USE APPROVED PARTS MAY CAUSE DEATH OR SERIOUS PERSONAL INJURY.

NOTE: Replace tires with the correct tires to maintain the rating of this equipment.

Changing Tires



FOAM FILLED TIRES ARE EXTREMELY HEAVY. CARE MUST BE TAKEN TO AVOID PERSONAL INJURY.



Always block the wheels before raising the machine.

When a tire change is necessary, follow these tips:

1. Chock tires on one end of machine and raise the other end of machine (see *Raising the Machine*).
2. Remove lug nuts and pull wheel off.
3. Install the replacement wheel.
4. Fasten lug nuts and tighten to proper torque. (Refer to machine specifications)
5. Lower the machine and remove the chocks.

Drive Motors

There are two (2) hydraulic motors on the front axle and two (2) drive motor brakes on the rear drive axle. These can be damaged or leaks may occur; repair or replace as necessary.


CAUTION:

- Clean all fittings before disconnecting hoses.
- Tag hoses for proper reassembly.
- Plug all openings to prevent contamination.

Front Drive Motors

Remove

1. Raise and support the front end of machine (see *Raising the Machine*).
2. Remove the wheel and tire assembly to access drive motor.
3. Remove the hub from the drive motor shaft.
4. Disconnect the cylinder end and tie-rod from the motor housing.
5. Turn the motor housing to gain access to the motor and hose assemblies.
6. Disconnect hose assemblies from drive motor.
7. Remove the cap screws and remove the drive motor.




Replace

Installation is reverse of removal.

Rear Drive Motor with Brakes

Remove

1. Raise and support the rear end of machine (see *Raising the Machine*).
2. Remove the wheel and tire assembly to access drive motor.
3. Disconnect hose assemblies from drive motor.
4. Remove the relief valve.
5. Remove the cap screws and remove the drive motor from the housing.



Replace

Installation is reverse of removal.



Steer Cylinder

There are two (2) double acting type steer cylinders on this machine. During operation, cylinder(s) should not leak, but a slight damping at the rod seal is acceptable. The pins should be checked for wear.


To replace steer cylinder:

- CAUTION:**
- Clean all fittings before disconnecting hoses.
 - Tag hoses for proper reassembly.
 - Plug all openings to prevent contamination.

1. Raise and support the front end of machine (see *Raising the Machine*).
1. Disconnect hydraulic hoses and cap them.
2. Remove the nut and bolt holding the steer cylinder to the motor mounting bracket.
3. Remove the pin and cotter pin holding the steer cylinder to the steer axle cross member (tie-rod).
4. Carefully lift off the steer cylinder.
5. Position the new steer cylinder and install pin and cotter pin to hold cylinder to the steer axle cross member.
6. Install nut and bolt to hold cylinder to motor mounting bracket.
7. Connect hydraulic hoses.
8. To purge air from cylinder;
 - place a suitable container beneath the hose connections to catch spilled oil,
 - loosen hose fittings slightly,
 - actuate steer function,
 - when all air is purged, tighten hose connections.

Steer Cylinder Seal Replacement

Refer to *Section 1* for seal replacement instructions.



Hoses and Cables

Note: Refer to *Parts Section 5* for detailed hydraulic hose diagrams.


Inspect all hoses and electrical cables for security and damage. Hoses and cables should be examined for rubbing and chafing.

Check for leaks at fittings. Replace any damaged hose or cable.

1. Tag hoses for proper reassembly.
2. Disconnect hoses and IMMEDIATELY cap the openings to prevent contamination.
3. Torque hose fittings according to the Hydraulic Torque Specification Table.

Platform Removal

1. Raise platform about three (3) feet (1.0 m) and block the arms in the raised position. Also, connect overhead crane by appropriate lifting device to platform.
2. Disconnect all platform wires.
3. Remove the bolts from both platform brackets at the rear of the machine.
4. Slide platform and roll out deck off the machine.



EV108

Lift Cylinder Removal and Installation

Note: Refer to *Section 1* for seal replacement instructions.
Refer to *Parts Section 3* for detailed parts list and illustration.

CAUTION:

- Clean all fittings before disconnecting hoses.
- Tag hoses for proper reassembly.
- Plug all openings to prevent contamination.

1. Raise the scissor arm assembly and support using the maintenance lock.
2. Disconnect hoses and wires and cables to the lift cylinder(s).
3. Use a suitable lifting device to support the lift cylinder.
4. Remove retaining pins and rod end pin.
5. Lift the cylinder from the scissor assembly using a suitable lifting device.

CAUTION: Attach the lifting device to the cylinder body. Lifting by the rod end will cause the cylinder to extend.

Scissor Beam Assembly


Note: Refer to *Parts Section 3* for detailed parts list and illustration.

Clean the beams once a year or as necessary and inspect along the beam's surface, especially weld and brackets.

Scissor Beam Removal

1. Remove the platform and lift cylinder(s).
2. Attach a suitable lifting device to the scissor assembly.
3. Lift the scissor assembly

Installation is reverse of removal.



ENGINE MAINTENANCE

Diesel Engine



**Always wear protective eye-wear when working with fuel and oil.
Engine should be OFF when replacing filter elements.**

For complete service information consult the engine manual that came with the machine.


Oil and Oil Filter- Diesel

Dispose of used oil and filters properly.

1. Use a suitable container to catch drained oil. Remove the drain plug. After oil has drained, replace the drain plug.
2. Remove the old filter and wipe the filter seal contact surface with a clean towel. Coat the seal on the new filter with clean oil, then install and tighten by hand.
3. Fill engine with 10w-30 motor oil until the dipstick indicates FULL. Capacity is 5.4 US quarts (5,1 l).
4. Recheck dipstick after running engine. Fill as necessary.

Air Filter Element- Diesel


1. Remove the hoses from the canister.
2. Loosen the bracket and remove the canister.
3. Remove the wing-bolt, remove old filter and replace with a new filter. Replace and tighten the wing-bolt.
Do not run the engine with the air filter element removed.
4. Replace the canister and attach the hoses. Tighten the canister bracket and hose clamps.



Throttle Solenoid Adjustment - Diesel

IMPORTANT: This final adjustment must be made after all other throttle speed adjustments. The solenoid must be free to retract fully in order to turn OFF the High Amperage Pull Circuit. Improper adjustment will result in solenoid failure and may damage the electrical system.

1. With the engine OFF, manually retract the solenoid by grasping the piston, just ahead of the boot, and pull to the fully retracted position.
2. With the solenoid piston fully retracted measure the distance between the High Speed Stop Screw and the Throttle linkage using a .020 feeler gauge.
3. Adjust clearance at the Throttle Solenoid linkage only. *Do not adjust the High Speed Stop Screw.*
 - Disconnect the linkage at the clevis and turn the clevis to lengthen or shorten as necessary.
 - Reconnect the clevis and measure again. Repeat until the measurement is correct.



Gasoline and Dual Fuel Engine



**Always wear protective eye-wear when working with fuel and oil.
Engine should be OFF when replacing filter elements.**

For complete service information consult the engine manual that came with the machine.


Oil and Oil Filter - Gasoline and Dual Fuel

Dispose of used oil and filters properly.

1. Use a suitable container to catch drained oil. Remove the drain plug. After oil has drained, replace the drain plug.
2. Remove the old filter. Coat the seal on the new filter with clean oil, then install and tighten by hand.
3. Fill engine with 10w-30 motor oil until the dipstick indicates FULL. Capacity is 3.4 US quarts (3,25 l).
4. Recheck dipstick after running engine. Fill as necessary.

Fuel Filter - Gasoline

1. Turn OFF valve at fuel tank.
2. Loosen the hose clamps on the fuel lines and slide them away from the in-line fuel filter.
3. Remove the in-line fuel filter from the fuel lines.
4. Install a new in-line fuel filter.
 - There is an arrow, indicating direction of flow, on the body of the in-line fuel filter. Make sure that the arrow points **from** the fuel tank and **to** the engine.
5. Reposition and tighten the hose clamps.
6. Open valve at fuel tank and check for leaks.



Air Filter Element - Gasoline and Dual Fuel

1. Unlock the catches holding the filter canister cover.
2. Remove the wing-nut from the filter assembly and remove the filter element.
3. Inspect the canister for debris and clean as necessary.
4. Install a new filter element and tighten the wing-nut.
5. Replace the canister cover and lock the catches.


Engine Adjustment - Gasoline and Dual Fuel

The following adjustment points are sealed by the factory and cannot be adjusted.

- Carburetor Pilot Screw
- LPG Main Pressure Adjustment Screw
- LPG Idle Pressure Adjustment Screw
- Distributor Ignition Timing Adjustment Screw

Choke Adjustment - Gasoline and Dual Fuel

1. Loosen the Choke Adjustment Screw until the linkage rod can move freely.
2. Manually retract the Choke Solenoid Piston until it stops.
3. While holding the solenoid fully retracted, close the choke plate until it stops in the fully closed position.
4. Allow the choke plate to open slightly and tighten the Choke Adjustment Screw.
5. Check Choke Solenoid operation to ensure that the choke plate travel does not prevent the Choke Solenoid from retracting fully.



Idle Speed Adjustment - Gasoline and Dual Fuel

1. Bring the engine to operating temperature.
2. With the engine at idle, adjust the Throttle Stop Screw until the engine RPM is 1350 ± 50 .

High Speed Adjustment - Gasoline and Dual Fuel

1. Bring the engine to operating temperature.
2. Loosen the adjusting nuts on the Throttle Solenoid.
3. Have an assistant press the Throttle Button on the Lower Controls panel.
4. Adjust the nuts on the Throttle Solenoid Piston until the engine RPM is 3850 ± 50 .
5. Tighten the nuts to secure the adjustment.

OUTRIGGER FUNCTION

The outriggers on the RT series MEC Scissor Lifts are a One-Touch Activation system. To deploy the outriggers, simply push the outrigger toggle switch down until the outriggers level the unit and the engine returns to idle. You are now ready to lift the platform. The outrigger control module is a “smart” unit, which will level the unit in all but extreme terrain so you don’t have to attempt to level it yourself.


Operational Characteristics

- To deploy the outriggers, push the Outrigger Switch down and hold until the engine returns to idle. The unit will self-level.
- The outrigger legs can not be operated individually.
- The outriggers system will not operate when the platform is elevated above approximately 10 feet (3m)
- Travel is locked out when the outriggers are deployed. A Drive Indicator Light, above the outrigger switch, will illuminate when the outriggers are fully retracted.
- The engine will not return to idle when the outriggers are fully retracted. The drive indicator light is your signal that the outriggers are fully retracted.
- If the slope of the terrain is in excess of the outrigger’s leveling capabilities, the outrigger control system will continue to attempt to level and the engine will not return to idle. In this case, if the platform remains outside of the pre-described tilt sensor parameters, the unit will not elevate above 6 feet (2m) and the alarm will sound, indicating the out-of-level situation.
- The outrigger system uses a Top-out limit switch and a Pressure switch on each leg to monitor their respective positions.
- Each outrigger leg uses a Retract valve and an Extend valve to control cylinder stroke. These are located under the protective cover atop the outrigger leg.
- A 4-way, 3-position valve, on the outrigger hydraulic manifold controls the direction of oil flow to the outrigger legs.
- The GP106 Outrigger Control Module controls all outrigger valve and interlock duties as well as sensing unit level.
- Diagnosis of the GP106 Outrigger Control Module is possible by counting the number of flashes from the red LED and referring to *Outrigger Module GP106 LED Flash Codes* at the end of this section. Diagnosis and calibration of the outrigger module can also be done through the use of the EZ-Cal scan tool MEC part # 90888. (See GP106 troubleshooting in this section)
- If the GP106 Outrigger Control Module is ever replaced or removed or if you suspect that it requires calibration, you must use the EZ-Cal scan tool and the following directions to calibrate the outrigger module.

Outrigger Calibration

Before attempting the calibration procedure, move the machine to an area that is level as measured by a spirit level or other leveling device. An EZ-Cal hand-held device (MEC part # 90888) is required to carry out all calibration procedures on the GP106 Outrigger Control Module.

SYMBOL	KEY FUNCTIONS
 	ESC/ENTER BUTTONS To move back and forth between menu and sub-menu
 	LEFT/RIGHT BUTTONS Select menus and setting to be adjusted
 	UP/DOWN BUTTONS Adjust setting values



Outrigger Tilt Sensor Calibration

The integral tilt sensor of the GP106 Outrigger Control Module must be calibrated to compensate for variations due to installation and vehicle construction. This procedure must be done if the control module is ever repositioned or replaced.

- a. Drive machine to level ground.
- b. Plug EZ-Cal into connector P1 on the control module.
Display reads HELP: PRESS ENTER.
- c. Press right arrow to ACCESS LEVEL 3, Press Enter.
Display reads CODE 0000.
- d. Press up and right arrows to enter code 1775, Press Enter.
Display reads ACCESS LEVEL 2.
- e. Right arrow to MACHINE SETUP, Press Enter.
Display reads CHANGE DEFAULTS.
- f. Right arrow to CALIBRATE LEVEL, Press Enter.
Display reads CALIBRATE LEVEL: YES:ENTER,NO:ESC.
- g. Press Enter. Display reads TILT 0.0',0.0'
- h. Press ESC, ESC
- i. Disconnect EZ-Cal from the outrigger control module.

Outrigger calibration is now complete.

GP106 Outrigger Control Module Troubleshooting

When the **EZ-Cal** hand-held device is connected to the **GP106** control module, the first menu available is “HELP” – just press the **ENTER** button to see a message describing the current status of the **GP106**; this can be very helpful in diagnosing problems with the system.

When an **EZ-Cal** is unavailable, an LED on the **GP106** flashes to provide limited diagnostics

The following messages might be displayed:

EVERYTHING OK

The **GP106** detects no problems.

If problems are being experienced with the system, use the **DIAGNOSTICS** menus to check for wiring problems.

B+ SUPPLY TOO LOW

The **GP106** is designed for use on 12V and 24V battery powered vehicles; it cannot operate with a supply below about 9V.

The “BATTERY” voltage can be checked in the “SYSTEM” menu (available in the “DIAGNOSTICS” menu).

CANNOT LEVEL: BAD TILT SENSOR

Ensure that the **GP106** is correctly installed – if it is wrongly oriented, its integral tilt sensor will be unable to measure vehicle tilt correctly.

CHECK OUTRIGGERS SUPPLY (P4-9)

An auto-level or auto-retract signal has been detected by the **GP106** (on P2-5 or P2-6) but there is no supply on P4-9 to power the outrigger legs.

OUTRIGGERS MANUALLY CONTROLLED

The outrigger system cannot be manually controlled, but this message may appear. It indicates a wiring problem to terminal P2-2.

OUTRIGGERS CANNOT BE MOVED

The outrigger system will be unable to operate if the machine is on a steep slope greater than ten (10) degrees.

RELEASE OUTRIGGER DEMAND!

The **GP106** is waiting for an active signal on P2-5 or P2-6 to be released (due to activating a switch when power is applied, or in conjunction with manual use of the outriggers, or activating both switches together).

VEHICLE TILTED

Either the “X” or “Y” tilt (measured by the **GP106** integral tilt sensor) exceeds three degrees. This does not affect operation of outriggers.

OUTRIGGER WIRING FAULT

The system has detected voltage on P2-2 but voltage is not present on P2-5 or P2-6. Check wiring to P2-5/6.



Outrigger Module GP106 LED Flash Codes

The **GP106** has a built-in LED to provide simple diagnostics when no **EZ-Cal** is available. Please note that the use of an EZ-Cal provides significantly better diagnostics through the HELP messages listed previously.

LED on steady

This indicates power to, and no fault with, the **GP106**

LED off always

This indicates no power to the **GP106**

LED flash code 1

Wiring Fault. Check connection to P2-2.

LED flash code 2

This indicates a fault with the switch inputs to the **GP106**. Check wiring to connector P2.

LED flash code 3

This indicates a fault with the “stable” output of the **GP106** – a short to the supply has been detected. Check wiring from pin P2-8

LED flash code 4

This indicates that the outriggers cannot be operated because the machine is on a slope greater than ten (10) degrees. Move machine to a different location.

LED flash code 5

This indicates a fault with the “stable” output of the **GP106** – a short to 0V (ground) has been detected. Check wiring from pin P2-8

LED flash code 6

This indicates a fault with the “auto” inputs of the **GP106** – check the wiring to pins P2-5 & P2-6

LED flash code 7

This indicates a fault with the supply to the **GP106** – check battery supply at least 8V on pins P2-12 & P4-9

LED flash code 8

This indicates that the machine is not level. It is not a fault and will not affect operation of outriggers.

LED flash code 9

This indicates that the **GP106** is performing startup tests.


A large, stylized red graphic consisting of two curved, overlapping shapes that form a circle. The text "SECTION 4: TROUBLESHOOTING" is centered within this graphic.

SECTION 4: TROUBLESHOOTING


Troubleshooting 4-3
 General Troubleshooting Tips 4-3
 Common Causes of Hydraulic System Malfunctions: 4-3
Hydraulic Pressure Adjustment Procedures 4-9
Proportional Speed Adjustment.....4-12
Controls and Switches4-14



HYDRAULIC MANIFOLD



DIAGNOSTIC LEDs



TROUBLESHOOTING

The 3072RT and 3772RT are designed for ease of diagnostics. There is a terminal strip located under the work platform for checking signals to and from Upper Controls. There are also LED's located in the Lower Controls box to indicate outputs from the circuit board.

Diagnostic Example: if the lift LED does not illuminate when attempting to lift, either the main power is not on, or board is not receiving a signal for lift. If LED is illuminated but machine does not lift, there would be an electrical problem between the Circuit board and the valve, or a hydraulic problem. The main valve block is equipped with a quick disconnect gauge port to help diagnose the hydraulic system.

General Troubleshooting Tips

Before investigating a malfunction, check the following items:

- Check that battery switch is turned on.
- Check that battery connections are secure and battery is fully charged.
- Check that the emergency stop button is released (UP/OUT position).
- Check that the hydraulic fluid is at the correct level.
- Check that the circuit breaker is in the "ON" position (not tripped).

Common Causes of Hydraulic System Malfunctions:

- Incompatible hydraulic fluids mixed, destroying the additives and causing varnish build up, resulting in the valves sticking.
- Water in the hydraulic fluid due to a damp climate.
- Improper hydraulic fluid used. Viscosity too high in cold climates. Viscosity too low in warm climates.
- Hydraulic oil contaminated with debris - filter change interval neglected.

NOTE: Mobil Fluid 424 Hydraulic Oil, is a multiple viscosity oil that is light enough for cold climates and resists thinning in warm climates. Only Mobil Fluid 424 or equivalent must be used. Substituting with a lower grade oil will result in pump failure.

Following is a step by step basic troubleshooting guide.

NOTE: Contamination always causes failure in any hydraulic system. It is very important to be careful not to introduce any contamination into hydraulic system during the assembly procedures. Please make sure all ports and cavities of the manifold and cylinders are properly covered/plugged during maintenance activities.

PROBLEM	PROBABLE CAUSE	REMEDY/SOLUTION	
General Power Issue			
No operation from upper or Upper Control station	Main battery switch turned off	Located left of Lower Controls box	
	Emergency switch pushed in or Ignition switch turned off	Upper or lower Emergency Stop switch will cut all power as will the Ignition switch in the Platform Controls box	
	Dead Battery	Charge battery	
	Blown fuse	Sealed unit just below Lower Controls box	
	Circuit breaker tripped	Reset - Located in Lower Controls box panel	
	Damaged Upper Controls box harness	Inspect from harness plug to terminal strip under platform	Test/replace. Located inside Lower Controls box
		Replace circuit board in Lower Controls box	
	Failed 25 AMP diode	Replace circuit board in Lower Controls box	
Failed Power Relay on Circuit board			
Functions from Upper Controls but not from Upper Controls	Faulty relay, located in Upper Controls box	Check power on wire 101 from Key switch Check power on wire 101A from relay to Joystick plug	
	Interlock switch (Joystick)	Check power to RED wire (power to switch) and power to PURPLE wire (power out of switch) at Joystick plug	
Lift/Lower			
Platform will not Raise	Excessive weight on Platform	Reduce weight to within platform capacity	
	Lift Relief valve out of adjustment	Adjust relief valve to rated capacity	
	Lift Valve SV-1 not energized	Check lift circuit from Upper Controls box to SV-1 valve	
	Lowering valve SV-5 stuck open (located at base of lift cylinder CYL-1)	Check and remove contamination, E-Down cable damaged or replace valve	
	Level Sensor out of level (platform elevated above 6')	Reposition machine to firm level surface, Check Level Sensor function	
	Main system pressure inadequate	Check pump output pressure (see <i>Hydraulic Pump Adjustment</i> in this section)	
	Proportional control out of adjustment (High Range Adjustment)	See section on <i>Proportional Controller Adjustment</i> in this section	
Platform will not lower or lowers slowly	Maintenance Lock in maintenance position	Return Maintenance Lock to the stowed position	
	Lowering valve not energized	Check lowering circuit from Upper Controls box to Lowering valve SV-5	
	Lowering valve not shifting	Clean debris, replace	
	Lowering orifice (ORF-3) plugged	Clean orifice	
Lowers but not completely (3772RT only)	Down valve on one cylinder inoperative	Check valve coils	
Emergency lowering not working	E-Down cable broken or frayed (3072)	Replace E-Down cable	
	Lowering valve not shifting	Clean debris, replace	
	Lowering orifice (ORF-3) plugged	Clean orifice	
3772RT ONLY	E-Down battery discharged	Charge, check charge diode & connections	
	Valve coil failed on either cylinder	Test, replace	
Lowers but not completely	Down valve on one cylinder inoperative	Check valve coils, wiring	

continued...



PROBLEM	PROBABLE CAUSE	REMEDY/SOLUTION
Drive		
No drive function	Valve SVD1 not energizing	Check forward/reverse LEDs lighting up at circuit board inside Lower Controls box Check connections at valve Check voltage at valve Check ground to valve Check valve for proper functioning
	brakes not releasing	Check OD1 brake orifice for contamination
	Proportional Control out of adjustment (High Speed adjustment)	See <i>Proportional Controller Adjustment</i> in this section
(with outriggers option)	Outriggers lowered	Check Drive Enable light - raise outriggers
	Outrigger Retracted switch/s inoperative	Check enable light on Platform Controls box Check outrigger switches located on top of each outrigger jack for continuity
No drive elevated	Proportional Control out of adjustment (Low Range adjustment)	See <i>Proportional Controller Adjustment</i> in this section
	Jumper - axle float bypass missing from circuit board, Lower Controls box	Forward Reverse LEDs not lighting up at Lower Controls circuit board? Install jumper wire.
(with outriggers option)	Outriggers lowered	Check Drive Enable light - raise outriggers
	Unit out of level	Lower and reposition the machine. Check Level Sensor malfunction
Slow drive with Platform stowed	High torque enabled	Check Speed/Torque switch in Platform Controls Box
	Limit switch not functioning	Limit switch at left-rear of base Check continuity between wire 2 TAN/ORG and wire 20 RED/WHT. Continuity = platform stowed.
	Upper Controls circuit board running in slow speed mode	12 volts to "R" terminal on circuit board in Platform Controls box = High Range
	Proportional Control out of adjustment (Low Range adjustment)	See <i>Proportional Controller Adjustment</i> in this section
	Engine not running to full potential	Check engine operation as per engine manufacturer guidelines
	Wheel motor/s not functioning correctly	Inspect wheel motors for excessive bypass
	RV3 or RV4 not adjusted correctly	Check and adjust relief valves
Drive in one direction only	Rev-Up or FWD-Down micro-switch failure	Check micro-switches on Joystick controller for function or adjustment
	Drive valve SVD1 not energizing in one direction	Check 12 volts to appropriate coil, check coil, check valve function
	Counterbalance valve CBV1 or CBV2 not functioning correctly	Swap Counterbalance valves to see if functioning direction changes.
No low speed (high torque mode)	Speed/Torque selector switch inoperative	Check for 12 volts on terminals 2 & 3 of Speed/Torque switch in Platform Controls box with drive enabled
	Valve SV3 not functioning	Check for 12 volts and ground to valve Check for faulty valve spool
	EP1 poppet valve not functioning	Check or replace valve

continued...



PROBLEM	PROBABLE CAUSE	REMEDY/SOLUTION
Drive		
No Mid Speed	SV3 or SV4 powered and/or shifted	These valves should not have 12 volts, in mid-speed, check valve function
	Speed/Torque selector switch malfunction	Should not have power at terminals 1 & 3 of Speed/Torque switch in Platform Controls box with drive enabled
No High Speed	Speed/Torque selector switch inoperative	Check for 12 volts on all terminals of Speed/Torque switch in Platform Controls box with drive enabled
	Faulty diode block DB1	Test DB-1 in Platform Controls box.
	Valve SV4 not functioning	Check voltage and ground to valve check for faulty valve spool
	EP2 poppet valve not functioning	Check or replace valve
Multi-Function		
No drive or Lift function from Upper Controls with steer operational	PWM circuit board in Platform Controls box not functioning correctly	Check battery + and - terminals at board. Check PWM output at A terminal. Check connections between A terminal and Proportional valve.
	Proportional valve malfunction	Check, for 1 AMP at valve during full Joystick stroke. Replace Proportional valve SP-1
	EC1 pressure compensation valve not functioning	Check, replace valve EC1
No steering With Drive operational	SV2 not functioning	Check voltage and ground to valve Check for faulty SV2 valve
	Faulty lift/drive selector switch	Check power on wire #25A on switch
	Faulty steer switch	Check switch in Joystick handle
	Steering Cylinder/s internal leakage	Check for internal leakage - repair
	RV1 steer relief valve not functioning	Check adjustment or replace

continued...

PROBLEM	PROBABLE CAUSE	REMEDY/SOLUTION
Diesel Engine		
Starter inoperative	Battery Cables loose or corroded	Clean, tighten cables
	Key switch not functioning	Check power to wire #20 at Key switch while cranking
	Starter not functioning	Check power to YEL/RED #220 wire at starter, Check ground cable to engine bell housing
	Circuit board relay failed	Check input on plug A pin-17, ORG/RED wire #20 on Lower Controls circuit board Check output on plug B pin-1, YEL/RED wire #220 on Lower Controls circuit board. <i>12 volts in - 0 volts out = replace circuit board</i>
No Engine start: Starter operates	Low diesel fuel level	Fill diesel tank, (see <i>Section 3</i> for Fuel Priming instructions)
	Fuel valve closed - located at fuel tank	Open valve
	Air in injector lines	See <i>Section 3</i> for Fuel Priming instructions
	Fuel filter clogged	Replace fuel filter
	Run solenoid not activating	Check power at WHT/BLK wire #320 from starter to run solenoid while cranking (WHT/BLK pull in, GRN/WHT hold wire)
	Glow plugs inoperative	See " <i>Glow Plugs Inoperative</i> " in this section
Engine starts but dies when starter disengaged	Faulty oil pressure switch	Check switch and wiring
	Faulty Fuel solenoid	Check 12 volts on GRN/WHT wire #116 - Replace Fuel Solenoid
Dual Fuel Engine - Gas		
Starter inoperative	Battery Cables loose or corroded	Clean, tighten cables
	Key switch not functioning	Check power to wire #20 at Key switch while cranking
	Starter not functioning	Check power to YEL/RED #220 wire at starter, Check ground cable to engine bell housing
	Circuit board relay failed	Check input on plug A pin-17, ORG/RED wire #20 on Lower Controls circuit board Check output on plug B pin-1, YEL/RED wire #220 on Lower Controls circuit board. <i>12 volts in - 0 volts out = replace circuit board</i>
No Engine start: Starter operates	Low gas level	Fill gas tank
	Fuel valve closed - located at fuel tank	Open valve
	Clogged Fuel Filter	Replace fuel filter, located on fuel hose below engine
	Faulty fuel selector switch	Check power to BLK/WHT wire #23 while cranking engine
	Faulty fuel shut off solenoid	Check power and ground at gas solenoid, Check solenoid operation located in float bowl
	Faulty fuel pump	Check power and ground at fuel pump during engine crank. Check fuel pump operation
<i>continued...</i>		




PROBLEM	PROBABLE CAUSE	REMEDY/SOLUTION
Dual Fuel Engine - LP		
Starter inoperative	Battery Cables loose or corroded	Clean, tighten cables
	Key switch not functioning	Check power to wire #20 at Key switch while cranking
	Starter not functioning	Check power to YEL/RED #220 wire at starter, Check ground cable to engine bell housing
	Circuit board relay failed	Check input on plug A pin-17, ORG/RED wire #20 on Lower Controls circuit board Check output on plug B pin-1, YEL/RED wire #220 on Lower Controls circuit board. <i>12 volts in - 0 volts out = replace circuit board</i>
No Engine start: Starter operates	Propane tank empty or valve closed	Fill tank - open valve
	Faulty carburetor mounted Propane solenoid	Check power and ground at Proportional solenoid, Check solenoid operation
	Faulty propane shut off solenoid	Check power and ground at Shut-off solenoid, Check solenoid operation
	Faulty fuel selector switch	Check power to BLU/WHT wire #22 while cranking engine
	Clogged Propane Filter Located under the propane tank shelf	Turn Off Propane valve before filter inspection or replacement
Engine runs rough, no power, poor throttle response	Vapor withdrawal tank installed	Replace tank with Liquid withdrawal type
	Low engine coolant level	Check, add coolant.
	Clogged Propane Filter Located under the propane tank shelf	Turn Off Propane valve before filter inspection or replacement
	Propane regulator malfunction	Replace Propane Regulator
Throttle, Choke & Glow Plugs		
Throttle does not operate	Misadjusted Throttle Solenoid (misadjusted throttle solenoid will result in the failure of the solenoid) maladjusted	Adjust throttle linkage NOTE: throttle linkage adjustment is critical on diesel engine)
	Throttle Solenoid failure	Check + and - to solenoid while operating Throttle
	Throttle Relay (located on side of engine)	Test for 12 volts on RED wire #00 and ORG wire # 225 while throttle is requested <i>Power on these wires should = 12 volts on ORG/BLK wire 325</i>
	Failed diode block (Large) located in Upper Controls box	Test and/or replace diode block Check for Throttle LED on Upper Control board
Throttle does not remain energized	Failed Throttle solenoid	Replace Throttle Solenoid
Choke does not operate	Choke Solenoid failure	Check + and - to solenoid while operating Choke
	Failed Choke switch	Try Choke switch on opposite control panel Check for Choke LED on Lower Controls circuit board
Glow Plugs inoperative	Failed Glow Plug Switch	Try Glow Plug switch on opposite control panel, Check for LED on Lower Controls circuit board.
	Failed Glow Plug Relay - located on side of engine	Test for 12 volts on RED #00 wire and on ORG/WHT wire #124 while operating glow plugs. <i>Power on these wires should = 12 volts on ORG/BLU wire 224</i>
	Failed glow plugs	Check for 12 volts at glow plugs while operating glow plugs.
<i>end Trouble Table</i>		

HYDRAULIC PRESSURE ADJUSTMENT PROCEDURES

- Before attempting to check and/or adjust pressure relief valves, operate the machine for 15 minutes or long enough to sufficiently warm the hydraulic oil.
- Insert a 0-5000 psi gauge onto the pressure test port on the valve manifold using gauge adapter fitting MEC part no. 8434

Pressure Adjustment Table

MODEL	MAIN		LIFT		STEER		STAND-BY	
3072RT	2800 PSI	193 bar	2500 PSI	172,4 bar	1500 PSI	103,4 bar	500-550 PSI	35-38 bar
3772RT	2800 PSI	193 bar	2500 PSI	172,4 bar	1500 PSI	103,4 bar	500-550 PSI	35-38 bar



Pump Adjustment

The Hydraulic Pump used in this model is a Variable Displacement, Pressure Compensated, Piston type pump. Proper adjustment is critical for normal operation of the machine. The following paragraphs will guide you through the various steps however, you must perform all steps, in their listed sequence, in order to achieve proper adjustment and machine performance.

Main Relief and Standby Adjustments

1. Start engine and operate the unit for 15 minutes or until the hydraulic oil is warm.
2. Insert a 0 – 5000 PSI (0-345BAR) gauge onto the manifold pressure gauge port.
3. Remove the acorn nut from the Main Relief adjustment screw. Loosen the jam nut and turn the screw counterclockwise 3 turns. Tighten the jam nut and install the acorn nut.
4. Remove the acorn nut from the Standby adjustment screw and loosen the jam nut. Turn the screw clockwise 3 turns or until the needle on the gauge stops climbing. At this point the gauge is reading full main relief pressure.
5. Access the Main Relief screw again and adjust it until the gauge settles at 2800 PSI (193.5bar). Tighten the jam nut and install the acorn nut.
6. Check the gauge reading again to ensure the setting did not change.
7. Turn the Standby adjustment screw counterclockwise until the gauge reads 550 PSI (38bar). Tighten the jamb nut and install the acorn nut.
8. Check the gauge reading again to ensure the setting did not change.

Pump Displacement Adjustment

This adjustment is set at the factory and should not be tampered with. The Displacement adjustment controls the maximum amount of oil flow that the pump will produce per revolution. Excessive flow will result in severe engine loading and stalling. Reduced flow will result in slower functions with no engine loading. If you suspect that the setting is incorrect, please call MEC Product Support at (800) 387-4575 for assistance.

Main Relief

See Pump Adjustment Procedure.

Stand-By Pressure

See Pump Adjustment Procedure.

Lift Relief (RV1)

The Lift Relief valve is located on the left-side, center of the valve manifold. It will be necessary to remove the cap from the relief valve if adjustment is necessary. **REMOVING THE CAP WHILE THE ENGINE IS RUNNING WILL RESULT IN OIL LEAKAGE.**

To check Lift Relief valve setting, park the machine on a firm level surface free from overhead obstructions. Using the lift switch on the lower panel, elevate the platform to full elevation. While maintaining the lift command, record the reading on the gauge.

Steering Relief (RV2)

The steering Relief valve is located on the left side, lower of the valve manifold. It will be necessary to remove the cap from the relief valve if adjustment is necessary. REMOVING THE CAP WHILE THE ENGINE IS RUNNING WILL RESULT IN OIL LEAKAGE.

To check Steering Relief valve setting, operate steer in one direction. While maintaining the steer command, record the reading on the gauge.


Lift Cylinder Overpressure Valves (RV4) 3772RT Only

The Lift Cylinder Overpressure valves are located on each of the lift cylinder valve blocks on the 3772RT model only.

Proper valve adjustment is not possible by the consumer. Considering their importance to the safe operation of the machine, they must not be tampered with. If the valve is suspected to be out of adjustment or tampered with, it must be replaced.

Setting Counterbalance Valves

1. Loosen the locknut on one of the valves.
2. Turn the adjustment screw counterclockwise (to the left) until it reaches the internal stop and the screw will turn no further.
3. Turn the adjustment screw clockwise (to the right) $2\frac{3}{4}$ turns.
4. Tighten the locknut while holding the adjustment screw in position to prevent it from rotating.
5. Repeat steps 1 through 4 on the other Counterbalance valve.
6. Adjustment is complete.



PROPORTIONAL SPEED ADJUSTMENT



Proportional Circuit Board Adjustment should only be performed after all other components are deemed to be in proper working order.

There are many factors that may contribute to excessively fast or slow drive speeds. Proportional Circuit Board Adjustment should only be performed after all other components are deemed to be in proper working order and not contributing to abnormal driving speeds. Failure to do so may result in incorrect speeds once the offending component has been repaired.

Circuit Board Setting Test Procedure

Before you begin, ensure there are no overhead obstructions preventing lift to full height. Lay out a course measured at 20 feet (6 meters) long. Ensure there are no obstructions preventing a straight travel over the distance of the course including leading up to and away from the course. Try not to steer while driving the timed course.



High Speed Drive Test:

With the platform fully lowered, drive the machine over the course, crossing the start line at full speed. Record the time it takes for a (predetermined) point on the machine to cross both lines and compare with the chart below using the 'High Range' column figure.

Elevated Speed Drive Test:

Elevate the platform above 12 feet (3.6 meters). Drive the machine over the course, crossing the start line at full speed. Record the time it takes for a (predetermined) point on the machine to cross both lines and compare with the chart below using the 'Low Range' column figure.

Speed Adjustment Table: 20 ft. (6 m) Course


TRIM POT	TRAVEL TIME IN SECONDS
High Range	3.5 to 4.0
Low Range	27 to 33

Adjustment Procedure



Note: Proportional Controller adjustments should only be made when the possibility of unauthorized tampering exists or after the Proportioning Valve or Proportional Circuit board was replaced. Though testing the proportional output should be part of routine maintenance, adjustments should not be necessary as a routine maintenance procedure.

The Trim Pots are located in the Platform Controls box (see illustration).

1. Turn the RAMP trim pot counterclockwise until a clicking noise is heard.
2. Ensure there are no overhead obstructions preventing lift to full height. Select LIFT mode, pull the enable and move the Joystick in reverse slowly to the point that the engine accelerates and hold it at that point. While holding the Joystick in that position, adjust the THRESH trim pot until the platform does NOT lift. Once adjusted, slight additional reverse motion of the Joystick should result in very slow and controlled lift action.
 - **Counterclockwise trim pot adjustment increases the amount of Joystick travel before platform movement.**
 - **Clockwise trim pot adjustment will allow platform movement sooner in the Joystick travel.**
3. If the machine was slow in the High Speed portion of the test, turn the HI RANGE trim pot clockwise until a clicking noise is heard.
4. If the Elevated Speed Drive Test resulted in speeds other than those listed, turn the LO RANGE trim pot clockwise to increase elevated drive speed or counterclockwise to decrease elevated drive speed to the proper speed. Repeat the Elevated Speed Drive Test.
5. The RAMP trim pot controls the smoothness of the motion start-up and linear ramp-up response. Turn the RAMP trim pot clockwise until the slowest machine start-up can be achieved while maintaining good proportional ramp-up through the travel of the Joystick.



CONTROLS AND SWITCHES



A large, stylized red graphic consisting of two curved, overlapping shapes that form a partial circle, framing the central text.

SECTION 5: SCHEMATICS


- Hydraulic Schematic 5-2**
 - Main Hydraulic Manifold 5-4
 - Optional Outriggers Hydraulic Manifold 5-5
- Electric Schematics 5-6**
 - Circuit Board 5-8
 - Controls.....5-10
 - Engine5-13
 - Optional Outriggers5-15
 - Optional Generator5-16




HYDRAULIC SCHEMATIC

Callout	Description
Lift Cylinder Components (3072RT)	
CYL2	Cylinder
MA3	Manifold, Lift Cylinder
SV5	Solenoid Valve - 12V Cable Attach
ORF3	Orifice - 0.073
Lift Cylinder Components (3772RT)	
CYL3	Cylinder, Upper
MA5	Manifold, Lift Cylinder, Upper
SV6	Solenoid Valve - 12V Dual Coil
RV4	Relief Valve - 3200 PSI
ORF4	Orifice - 0.073
CYL4	Cylinder, Lower
MA4	Manifold, Lift Cylinder, Lower
SV6	Solenoid Valve - 12V Dual Coil
RV4	Relief Valve - 3200 PSI
ORF6	Orifice - 0.047
Wheel Motor Components	
LF	Wheel Motor - Left Front
LR	Wheel Motor - Left Rear
RV3	Relief Valve - 3000 PSI - Cross Port Relief
RF	Wheel Motor - Right Front
RR	Wheel Motor - Right Rear
RV3	Relief Valve - 3000 PSI - Cross Port Relief
P1	Pump - Variable Displacement Pressure Compensated
FL1	Return Filter - 10 Micron
CYL1	Cylinder, Steering
Optional Outriggers Components	
CYL5	Outrigger Cylinder
SV7	Solenoid Valve, Poppet N.C.
SV8	Solenoid Valve, Poppet N.C.
SV9	Spool Valve, 4Way - 3 Position


Callout	Description
Manifold Components	
MA1	Manifold, Main Valve Block
SVD1	Spool Valve, Drive, 4 Way - 3 Position
SV1	Spool Valve, Lift, 3 Way
SV2	Spool Valve, Steer, 4 Way - 3 Position
SV3 - SV4	Spool Valve, Series Parallel, 4 Way - 3 Position
SP1	Proportional Valve - 12V
RV1	Relief Valve, Lift - 2500 PSI
RV2	Relief Valve, Steer - 1500 PSI
PD1 - PD2 - PD3	Piloted Spool Valve, 4 Way - 3 Position
EP1 - EP2	Piloted Poppet Valve
MP1	Manual Pull Valve
LS1 - LS2 - LS3	Load Sense Shuttle Check Valve
CBV1 - CBV2	Counter Balance Valve
CL1	Coil, Series 8 - 12V
CL2	Coil, Series 10 - 12V
CL3	Coil, Series 10 E-Coil - 12V
HP1	Hand Pump, Brake Release
FD1 - FD2	Flow Divider / Combiner
EC1	Pressure Compensator
CV1 - CV2	Check Valve, Load Sense
OD1	Orifice Disc, Brake - 0.035
OPL2	Orifice Plug, Steer - 0.080
OPL5 - OPL6	Orifice Plug, Flow Divider Bleed - 0.025
ORF5	Orifice, Decent Control - 0.093




Main Hydraulic Manifold




LEFT




BOTTOM




FRONT



BACK




RIGHT




TOP


Optional Outriggers Hydraulic Manifold




LEFT



FRONT






RIGHT



BOTTOM


ELECTRIC SCHEMATICS







Circuit Board

The Circuit Board schematic is broken into two pages for clarity. The cable connections are shown on this page. Match the numbers to line-up the traces.







ANSI UPPER CONTROLS WITHOUT OUTRIGGER OPTION




LOWER CONTROL BOX





Optional Outriggers



Optional Generator





Table of Contents

Parts Sections

SECTION 1: CONTROL BOXES

UPPER CONTROLS, ANSI	1-3
UPPER CONTROL BOX COVER ASSEMBLY	1-5
UPPER CONTROL JOYSTICK	1-7
BASE CONTROL BOX	1-9

SECTION 2: PLATFORM AND RAILS

PLATFORM ASSEMBLY	2-3
ROLLOUT LOCK PIN ASSEMBLY	2-5
ROLLER ASSEMBLY	2-7
ENTRY CHAIN	2-9
SWING GATE (OPTION)	2-11
CONTROL CABLE/HORN INSTALLATION	2-13
POWER TO PLATFORM	2-15
AIRLINE TO PLATFORM (OPTION)	2-15
LANYARD ATTACHMENT (OPTION)	2-17

SECTION 3: SCISSORS

BEAM ASSEMBLY, 3072RT	3-3
BEAM ASSEMBLY, 3772RT	3-7
LIMIT SWITCH INSTALLATION	3-11

SECTION 4: AXLES

REAR AXLE ASSEMBLY	4-3
FRONT AXLE ASSEMBLY	4-5
WHEEL MOTOR, REAR	4-7
WHEEL MOTOR, FRONT	4-9



Table of Contents

SECTION 5: HYDRAULICS

MANIFOLD ASSEMBLY	5-3
MANIFOLD ASSEMBLY – HARDWARE	5-5
MANIFOLD - OUTRIGGER (OPTION)	5-7
HOSE KIT - AXLES	5-9
HOSE KIT STEERING, BRAKE RELEASE AND AXLE RETURN	5-11
HOSE KIT PUMP AND RETURN	5-13
HOSE KIT OUTRIGGER OPTION	5-15
HOSE KIT - GENERATOR OPTION	5-17
LIFT CYLINDER, 3072RT	5-19
LIFT CYLINDER, LOWER, 3772RT	5-21
LIFT CYLINDER, UPPER, 3772RT	5-23
STEERING CYLINDER	5-25
OUTRIGGER CYLINDER (OPTION)	5-27

SECTION 6: BASE

BASE ASSEMBLY	6-3
BALLAST (COUNTERWEIGHT) INSTALLATION	6-5
MODULES INSTALLATION	6-7
CONTROL MODULE	6-9
POWER MODULE	6-13
POWER MODULE: ENGINE MOUNT - DIESEL	6-17
ENGINE, DUAL FUEL	6-21
ENGINE, DIESEL	6-25
WIRE HARNESS	6-29
OUTRIGGER INSTALLATION	6-31
GENERATOR - OPTION, DUAL FUEL	6-33
GENERATOR - OPTION, DIESEL	6-35


SECTION 7: DECALS

DECAL KIT, UPPER CONTROL BOX	7-3
DECAL KIT, SIDES, 3072RT	7-5
DECAL KIT, ENDS, 3072RT	7-7
DECAL KIT, SIDES, 3772RT	7-9
DECAL KIT, ENDS, 3772RT	7-11
DECALS - ANCHORAGE POINTS OPTION	7-13

A large red graphic consisting of two overlapping, curved shapes that form a partial circle, framing the section title.

SECTION 1: CONTROL BOXES


UPPER CONTROLS, ANSI	1-3
UPPER CONTROL BOX COVER ASSEMBLY	1-5
UPPER CONTROL JOYSTICK	1-7
BASE CONTROL BOX	1-9



ART ControlBox-X72




ITEM	PART NO.	QTY	DESCRIPTION
			UPPER CONTROLS, ANSI
1	91108 16242	- 1	CONTROL BOX ASSEMBLY, ANSI WELDMENT, CONTROL BOX
2	13865	1	BRACKET, CONTROL BOX HOLDER
3	6350	.5FT	TAPE, FOAM
4	6234	1	SWITCH, TOGGLE, LIFT/DRIVE
6	6905	1	SWITCH, TOGGLE, SPEED/TORQUE
7	7800	1	SWITCH, EMERGENCY STOP
8	91159	1	KEYSWITCH
	8082	1	CONTACT BLOCK, NO
	8083	1	CONTACT BLOCK, NC
9	8044	1	SWITCH, HORN BUTTON (OPTION)
10	5630	1	SWITCH, TOGGLE, GENERATOR (OPTION)
11	7423	1	SWITCH, TOGGLE, CHOKE/PREHEAT
12	91186	1	RELAY, TIME DELAY
13	91184	1	WIRE HARNESS, CONTROL BOX
14	91375	1	RELAY, POWER
15	91027	1	DIODE BLOCK, 2 POSITION
17	91107	1	PWM CARD
18	90814	2	SPACER
19	90833	2	SCREW, 6-32 X 3/4"
20	5364	2	NUT, 6-32
21	91028	1	DIODE BLOCK, 4 POSITION
			OUTRIGGER OPTION
22	91294	1	HARNESS, OUTRIGGER CONTROL
23	5694	1	SWITCH, TOGGLE
24	90789	1	LED, GREEN, DRIVE ENABLED
25	16312	1	PLATE, MOUNTING, OUTRIGGER PLUG
26	90833	2	SCREW, 6-32 X 3/4"
27	5364	2	NUT, 6-32
28	91028	1	DIODE BLOCK, 4 POSITION




ART_ASSY13868



ITEM	PART NO.	QTY	DESCRIPTION
			UPPER CONTROL BOX COVER ASSEMBLY
1	13647	1	CONTROL BOX COVER ASSEMBLY CONTROL ARM COVER
2	3772	1	COVER
3	7875	1	GASKET
4	7882	1	O-RING, 7/8" ID X 1 1/8" OD
5	HDW3768	1	WASHER, FLAT
6	7819	1	BEARING, BRONZE, FLANGED
7	8435	1	SPRING, JOYSTICK, CENTERING
8	100/8348	1	PIN, HOLD DOWN
9	HDW7887	1	SCREW, #6-32, 1/2" LG
10	13502	1	BRACKET, CENTERING
11	3763	1	SPACER, STEP
12	13402	1	GEAR, LARGE
13	HDW8531	2	WASHER, FLAT
14	HDW7881	1	WASHER, BEVEL
15	3782	1	CAM. DIRECTIONAL
16	13403	1	PLATE, BOTTOM
17	6917	1	CLAMP, CABLE 1/4"
18	7818	1	BEARING, BRONZE, FLANGED
19	HDW3771	1	WASHER, FLAT
20	5736	1	RING, RETAINING, 1/2"
21	HDW8399	4	SCREW, #4 - 40, 5/8" LG
22	HDW8567	2	WASHER, FLAT
23	8389	1	GEAR, SPUR
24	91522	1	POTENTIOMETER
25	HDW7888	12	SCREW, #10 - 32, 1/2" LG
26	3764	2	PLATE, SPACER
27	8696	2	SWITCH, LIMIT, MICRO V7
28	3765	2	PLATE, STRAP
29	3766	1	PLATE, TOP




ART_JoystickHandle





SECTION 2: PLATFORM AND RAILS


PLATFORM ASSEMBLY	2-3
ROLLOUT LOCK PIN ASSEMBLY	2-5
ROLLER ASSEMBLY	2-7
ENTRY CHAIN	2-9
SWING GATE (OPTION)	2-11
CONTROL CABLE/HORN INSTALLATION	2-13
POWER TO PLATFORM	2-15
AIRLINE TO PLATFORM (OPTION)	2-15
LANYARD ATTACHMENT (OPTION)	2-17



ART_PLATFORM




ITEM	PART NO.	QTY	DESCRIPTION
			PLATFORM ASSEMBLY
1	16222	1	REAR RAIL WELDMENT
2	7805	1	PADDING, RAIL (OPTIONAL)
3	7048	1	COVER, RAIL PADDING (OPTIONAL)
4	HDW7119	2	SCREW, 5/16" - 18, 2 1/4" LG, GR 5
5	HDW5217	4	FLAT WASHER, .343 ID x .688 OD x .063 THK
6	HDW8304	6	NUT, 5/16" - 18
7	HDW7593	6	PIN, WIRE LOCK, SQUARE, 3/8" x 2 1/4" LG
8	16176	1	SIDE RAIL WELDMENT, LH
9	14301	1	SIDE RAIL WELDMENT - EXTENSION
10	16177	1	FRONT RAIL WELDMENT
11	8909	1	MANUAL ENCLOSURE
12	HDW5723	8	SCREW, 1/4" - 20, 1/2" LG
13	HDW8294	4	FLAT WASHER, .328 ID x 1.000 OD x .100 THK
14	HDW8267	4	NUT, 1/4" - 20
15	14415	2	BRACKET, EXTENSION STOP
16	HDW5724	20	SCREW, 5/16" - 18, 3/4" LG, GR 5
17	14152	2	CHANNEL, EXTENSION
18	16202	1	EXTENSION PLATFORM WELDMENT
19	16196	1	MAIN PLATFORM WELDMENT
20	HDW8856	2	SCREW, 1/2"-13, 5" LG
21	HDW8457	2	NUT, 1/2" - 13
22	14313	1	RIGHT SIDE RAIL WELDMENT - EXTENSION
23	HDW8974	1	PIN, WIRE LOCK, SQUARE, 3/8" x 3" LG
24	6823	2	CAP PLUG, 1 1/4"
25	16224	1	SIDE RAIL WELDMENT, RH
26	HDW8279	10	SCREW, 3/8-16, 2 1/2" LG
27	HDW8268	10	NUT, 3/8-16
28	20552	1	COVER, PLATFORM CORD (NOT SHOWN)
29	91284	1	PIN HITCH 3/8" x 4
30	HDW5355	20	WASHER, FLAT, .438 IDx1.00 ODx.078 THK
31	HDW6434	3	SCREW, 3/8-16x2" LG




ART 769 R1







Art Number
Roller Assembly










Art CtnrICableInst





ART_PowerOutlet



ITEM	PART NO.	QTY	DESCRIPTION
			POWER TO PLATFORM
1	90827	1	BOX, RECEPTACLE
2	90828	1	DUPLEX RECEPTACLE COVER
3	HDW5636	1	SCREW #6 - 32 × 0.25"
4	HDW6455	2	SCREW, ¼" - 20, ½" LG
5	HDW8267	2	LOCKNUT ¼" - 20
6	5381	1	RECEPTACLE, DUPLEX
7	8208	1	CONDUIT, 3/8" FLEXIBLE
8	8209	1	FERRULE, 3/8"
9	8479	1	BUSHING, ¾" ID
10	8833	1	CONNECTOR, OUTLET BOX 3/8" CONDUIT
11	16221	1	BRACKET
12	HDW5724	2	SCREW, 5/16-18 × ¾"
13	HDW8304	2	NUT, 5/16-18
	HDW8501	2	CLIP, SELF RETAINING
	7617	*	WIRE, 14 GA
			*3072RT = 50 FT. * 3772RT = 58 FT.
	HDW5217	2	FLAT WASHER 1 1/32" ID
			AIRLINE To PLATFORM (OPTION)
			NOT SHOWN
	5351	1	CABLE TIE
	91399	*	HOSE, 3/8" AIRLINE *3072RT = 49 FT.
			* 3772RT = 57 FT.
	8559	2	CLAMP, HOSE
	HDW91500	2	FITTING, ¼" MALE, MALE HOSE BARB
	5882	2	CABLE CLAMP





WARNING

- LANYARD ANCHORAGE POINTS ARE RECOMMENDED FOR WORK POSITIONING RESTRAINTS ONLY.

USE OF FALL ARREST SYSTEMS ATTACHED TO ANCHORAGE POINTS ON MOBILE EQUIPMENT MAY CAUSE MACHINE TO TIP, RESULTING IN SERIOUS INJURY OR DEATH.

8606



CERTIFIED LANYARD ANCHORAGE POINT








**SECTION 3:
SCISSORS**


BEAM ASSEMBLY, 3072RT 3-3
BEAM ASSEMBLY, 3772RT 3-7
LIMIT SWITCH INSTALLATION3-11



ART 3072BEAMS




ITEM	PART NO.	QTY	DESCRIPTION
			BEAM ASSEMBLY, 3072RT
1	14488	2	BLOCK, SLIDE, PLATFORM
2	40448	1	BEAM, 6 × 8 × .250, TOP SLIDE, W/PINS
3	40084	1	BEAM, 6 × 8 × .313 W/PINS
4	40081	1	BEAM, 6 × 8 × .313 W/PINS
5	40444	1	BEAM, 6 × 8 × .250, BOTTOM FIXED, W/PINS
6	40459	2	LOWER PIVOT, MACHINED CASTING
6A	6669	2	BEARING, 2" × 2"
7	5432	4	GREASE FITTING
8	HDW8457	6	LOCKNUT, ½" - 13, GR B
9	HDW8284	6	SCREW, ½" - 13, 2" LG, GR 8
10	HDW8899	2	RING, RETAINING (NOT SHOWN)
11	14538	2	BRACKET, CYLINDER RETAINING
12	HDW6455	4	SCREW, ¼" - 20, ½" LG
13	14537	2	PIN, CYLINDER MOUNT
17	6701	10	RING, RETAINING, 2"
18	9587	2	WEAR PAD, SLIDE BLOCK, BOTTOM
19	90235	2	WEAR PAD, ANGLE, SLIDE BLOCK TOP
20	40306	2	SLIDE PVT, LWR CAST, MACHINED
	8785	.67 FT	TAPE, DOUBLE COATED
21	7160	2	BEARING, 1 ¾" × 2"
22	40446	1	BEAM, 6 × 8 × .250, BOTTOM SLIDE, W/BEARINGS
23	14990	1	MAINTENANCE LOCK WELDMENT
24	8675	1	BEARING, 2 ¼" × 2" × 1 ½" LG (NOT SHOWN)
25	25429	12	SPACER BLOCK - BEAMS
26	91020	1	LIFT CYLINDER
27	40083	2	BEAM, 6 × 6 × .313
	6669	4	BEARING, 2" × 2" (NOT SHOWN)
28	14806	1	SUPPORT BEAM WELDMENT
29	16283	2	CYLINDER MOUNT
			CONTINUED . . .



↓ DENOTES LOCATION OF HDW13175, TOTAL QUANTITY OF 16

ART 3072BEAMS






↓ DENOTES LOCATION OF HDW13175, TOTAL QUANTITY OF 29

ART 3772BEAMS



ITEM	PART NO.	QTY	DESCRIPTION
			BEAM ASSEMBLY, 3772RT
1	16290	1	BEAM 6 x6 x.188
2	14487	2	BLOCK, SLIDE, PLATFORM
3	HDW5217	8	WASHER, FLAT, .343 ID x .688 OD x .063THK
4	HDW8303	8	SCREW, 5/16" - 18, 2.00" LG
5	HDW8294	8	WASHER, FLAT, .328 ID x 1.000 OD x .100 THK
6	HDW8304	8	NUT, 5/16 - 18
7	40124	1	BEAM 6 x 6 x .250
8	16289	1	BEAM 6 x6 x.188
9	30407	1	PIN 2.00 DIA x 25.90" LG
10	16292	1	BEAM 6 x6 x.375 W/BEARINGS
11	91314	1	LIFT CYLINDER, LOWER
12	25429	16	SPACER BLOCK - BEAMS
13	16285	1	BEAM 6 x6 x.375, BOTTOM FITTED
14	90235	2	WEAR PAD, ANLE, SLIDE BLOCK, TOP
15	40306	2	SLIDE PIVOT LOWER CAST MACHINED
16	7160	2	BEARING, 1 3/4" x 2" - 28DU32
17	5432	4	GREASE FITTING
18	9587	2	WEAR PAD, SLIDE BLOCK, BOTTOM
19	16286	1	BEAM 6 x6 x.188
	6669	2	BEARING, 2.0 x 2.0 - 32DU32
20	40106	1	BEAM 6 x6 x.375
	6669	2	BEARING, 2.0 x 2.0 - 32DU32
21	16284	1	BEAM 6 x6 x.375
	6669	2	BEARING, 2.0 x 2.0 - 32DU32
22	40459	2	CASTING, MACHINED, LOWER PIVOT
23	6669	2	BEARING, 2.0 x 2.0 - 32DU32
24	HDW6491	6	WASHER, FLAT, .562 ID x 1.375 OD x .109 THK
25	HDW8284	6	BOLT, 1/2" - 13, 2.00" LG GR8
26	HDW8457	6	LOCKNUT, 1/2" - 13, GR8
31	30518	1	MAINTENANCE LOCK WELDMENT
32	8675	1	BEARING, 2 1/4" x 2" x 1 1/2" LG (NOT SHOWN)
33	91315	1	LIFT CYLINDER, UPPER
			...CONTINUED






↓ DENOTES LOCATION OF HDW13175, TOTAL QUANTITY OF 29

ART 3772BEAMS





ART_LimitSwitch





A large, stylized red graphic consisting of two overlapping, curved shapes that form a circular frame. The text "SECTION 4: AXLES" is centered within this frame.

SECTION 4: AXLES

REAR AXLE ASSEMBLY 4-3
FRONT AXLE ASSEMBLY 4-5
WHEEL MOTOR, REAR 4-7
WHEEL MOTOR, FRONT 4-9









 ILLUSTRATION No.
 ART_2492

3072RT / 3772RT Rear Axle



ITEM	PART NO.	QTY	DESCRIPTION
			REAR AXLE ASSEMBLY
1	40258	2	MOUNT, MOTOR, REAR AXLE, MACHINED
2	HDW5994	12	WASHER, LOCK, .640 ID X 1.050 OD X .165 THK
3	8283	8	BOLT, 5/8" - 11, 1 1/2" LG
8	90765	4	HOSE PROTECTION (NOT SHOWN)
9	91319	2	WHEEL MOTOR, HYD W/BRAKE
10	HDW5989	12	SCREW, 5/8"-11, 2 1/4" LG, GR 5
11	14773	2	HUB
12	91165	1	WHEEL/TIRE ASSY, RH - 10 PLY - PNEUMATIC
	91167	1	WHEEL/TIRE ASSY, RH - 10 PLY - FOAM - OPTION
	91166	1	WHEEL/TIRE ASSY, LH - 10 PLY - PNEUMATIC
	91168	1	WHEEL/TIRE ASSY, LH - 10 PLY - FOAM - OPTION
	91180	-	WHEEL (SERVICE)
	91181	-	TIRE 26X12.00-380 (SERVICE)
13	HDW9037		NUT, CASTLE, M42 X 3 (SERVICE)
14	HDW6677	12	NUT, LUG, 1/2" - 20, GR 5
15	8925	2	PIN, COTTER, .250 DIA. X 3" LG
16	HDW8984	4	FITTING, MB-MJ-12-8
17	HDW91235	2	FITTING, MB-MJ45-4-5
18	HDW8881	2	FITTING, MB-MJ-4-4
19	91326	2	RELIEF VALVE (IF SOLENOID VALVE USE ITEMS 20 & 21)
20	91464	2	VALVE, N/C POPPET (IF RELIEF VALVE USE ITEM 19)
21	91141	2	COIL 12V DEUTSCH (IF RELIEF VALVE USE ITEM 19)
22	6633	4	NUT, 5/8"-11
23	16349	2	COVER, LOWER, VALVE SHIELD, LEFT AND RIGHT
24	16348	2	COVER, UPPER, VALVE SHIELD, LEFT AND RIGHT






ART FrontAxle




ITEM	PART NO.	QTY	DESCRIPTION
			FRONT AXLE ASSEMBLY
1	HDW5920	2	PIN, COTTER, .12 DIA. X 1" LG
2	HDW90770	2	PIN, CLEVIS, ½ DIA. X 1 3/8" LG
3	91019 90990	2	CYLINDER, STEERING SEAL KIT, STEER CYLINDER (NOT SHOWN)
4	91263	4	HOSE ASSEMBLY ½" (8M3K-8FJX-8FJX90S-37")
5	HDW7326	2	SCREW, 5/8" - 11.4" LG, GR 5
6	HDW9219	4	WASHER, .656 ID X 1.312 OD X .093 THK
7	7292	2	BEARING, SLEEVE, BRONZE
8	HDW8568	6	NUT, 1 1/8" - 18
9	20311	4	WASHER, 1.375 ID X 2.75 OD X .250 THK
11	20312	8	WASHER, THRUST
12	90282	1	HOSE ASSEMBLY 5/16" (NOT SHOWN)
13	HDW7043	8	SCREW, ½"-13, 2.50" LG, GR 8, SOCKET HEAD
14	7300P	2	MOTOR, WHEEL, HYD.
15	90765	8	HOSE PROTECTION (NOT SHOWN)
16	40464	1	MOUNT, WHEEL MOTOR, LH, FRONT (CAST 40463)
	40308	1	MOUNT, WHEEL MOTOR, RH, FRONT (CAST 40367)
17	HDW6633	2	NUT, LOCK, 5/8" - 11, GR 5
18	40334	4	MOUNT, MOTOR W/BEARINGS
18A	9307	4	BEARING, 1.50 X 1.0 DIA
19	9607	2	FITTING, GREASE, 90°
20	HDW5994	16	WASHER, LOCK, .640 ID X 1.050 OD X .165 THK
21	HDW90410	16	SCREW, 5/8" - 11, 2" LG, GR 8, SOCKET HEAD
22	HDW8457	8	NUT, ½"-13, GR8
23	10709	2	HUB
24	91165	1	WHEEL/TIRE ASSY, RH - 10 PLY - PNEUMATIC
-	91167	1	WHEEL/TIRE ASSY, RH - 10 PLY - FOAM - OPTION
-	91166	1	WHEEL/TIRE ASSY, LH - 10 PLY - PNEUMATIC
-	91168	1	WHEEL/TIRE ASSY, LH - 10 PLY - FOAM - OPTION
25	HDW5290	6	PIN, COTTER, .156 DIA. X 1.75" LG
26	HDW6677	12	NUT, LUG, ½" - 20, GR 5
28	14331	1	ROD, TIE STEERING
29	HDW8984	4	FITTING, MB-MJ-12-8
30	HDW91236	2	FITTING, MB-MJ90-4-5



ART_DT710







DT701 Series Motor Components





SECTION 5: HYDRAULICS



MANIFOLD ASSEMBLY	5-3
MANIFOLD ASSEMBLY – HARDWARE	5-5
MANIFOLD - OUTRIGGER (OPTION)	5-7
HOSE KIT - AXLES	5-9
HOSE KIT STEERING, BRAKE RELEASE AND AXLE RETURN	5-11
HOSE KIT PUMP AND RETURN	5-13
HOSE KIT OUTRIGGER OPTION	5-15
HOSE KIT - GENERATOR OPTION	5-17
LIFT CYLINDER, 3072RT	5-19
LIFT CYLINDER, LOWER, 3772RT	5-21
LIFT CYLINDER, UPPER, 3772RT	5-23
STEERING CYLINDER	5-25
OUTRIGGER CYLINDER (OPTION)	5-27





ART_91140-ASSY




ITEM	PART NO.	QTY	DESCRIPTION
			MANIFOLD ASSEMBLY
	91140	-	MANIFOLD ASSEMBLY
1	91141	4	COIL, SERIES 8, 12V
2	91142	1	COIL, SERIES 10, 12V
3	91143	1	COIL, SERIES 10 E-COIL, 12V
4	91144	1	VALVE, DRIVE, 4 WAY 3 POSITION
5	91145	1	VALVE, LIFT SPOOL, 3 WAY
6	91146	1	VALVE, STEER, 4 WAY 3 POSITION
7	91147	2	VALVE, SERIES PARALLEL SPOOL, 4 WAY 3 POSITION
8	91148	1	VALVE, PROPORTIONAL, 12 V
9	91149	1	VALVE, RELIEF, LIFT
10	91150	1	VALVE, RELIEF, STEER
11	91151	3	VALVE, PILOTED SPOOL 4 WAY 3 POSITION
12	91152	2	VALVE, PILOTED POPPET
13	91153	1	VALVE, LOAD SHUTTLE CHECK
14	91154	2	VALVE, LOAD SHUTTLE CHECK
15	91350	2	VALVE, COUNTERBALANCE
16	91353	2	VALVE, CHECK
17	HDW7314	2	PORT PLUG M ¼", O-RING, RBG-4
	HDW7061	2	ADAPTER (W/ OUTRIGGER OPTION)
18	7484	2	PORT PLUG M 0.38" O-RING, RBG-6
	HDW7438	2	ADAPTER (W/ OUTRIGGER OPTION)
19	91351	2	FLOW DIVIDER / COMBINER
20	91355	1	ORIFICE PLUG, STEER
21	91356	2	ORIFICE PLUG, FLOW DIVIDER BLEED
22	91012	1	VALVE, MANUAL — PULL
23	91354	1	ORIFICE DISC
24	91015	1	HAND PUMP, BRAKE RELEASE
25	91352	1	PRESSURE COMPENSATOR






ART_91268ASSY






ART_X72Hoses- Axles






ART_X72Hoses-Steer







ART_X72Hoses- Pump










91020 LIFT CYLINDER WITH BEARINGS

ART 91020



ITEM	PART NO.	QTY	DESCRIPTION
			LIFT CYLINDER, 3072RT
1	91020	1	CYLINDER, LIFT 3072RT
2	90985	1	HOSE ASSEMBLY, 3/8"
3	HDW7601	1	FITTING, ELBOW ADAPTOR
4	90361	1	ORIFICE
5	6669	4	BEARING, 2" ID x 2" LG
6	91051	1	VALVE, 2 WAY, N.C. CABLE ATTACH
7	91141	1	COIL, 12 VOLT, DEUTSCH
8	HDW6727	1	FITTING, PIPE 90°, MALE BARB
9	HDW8152	2	SCREW, 1/4" - 20 x 3/4" LG
11	16062	1	BRACKET, LIFT CYLINDER VALVE GUARD
12	6458	21 FT	HOSE, RETURN LINE
14	7788	1	CLAMP, HOSE
15	91182	1	CABLE, E-DOWN
16	HDW91240	1	NUT, COUPLING 10-32 x 3/4"
	91460	REF	KIT, SEAL-LIFT CYLINDER (SERVICE)
N/A	91069	1	HARNESS, WIRE DOWN, VALVE (NOT SHOWN)







91314 LIFT CYLINDER WITH BEARINGS

ART 91314LiftCyl



ITEM	PART NO.	QTY	DESCRIPTION
			LIFT CYLINDER, LOWER, 3772RT
1	91314	1	CYLINDER, LOWER LIFT, 3772RT
2	9039	1	HOSE ASSEMBLY, LIFT CYLINDER 3/8"
3	HDW7601	1	FITTING, ELBOW 90°, .37JIC × 37 ORING
4	90361	1	ORIFICE
5	90993	4	BEARING, BRONZE, 2" ID × 2" LG
6	91462	1	VALVE, 2 WAY, N.C. POPPET DUAL COIL
8	HDW6727	1	FITTING, PIPE 90°, MALE BARB
9	HDW8152	2	SCREW, 1/4" - 20 × 3/4" LG
11	16062	1	BRACKET, LIFT CYLINDER VALVE GUARD
12	6458	21 FT	HOSE, RETURN LINE
14	7788	1	CLAMP, HOSE, 5/8 MAX
15	90969	1	RELIEF VALVE
16	91141	2	COIL, 12 VOLT, DEUTSCH CONNECTOR W/DIODE
17	HDW90943	1	FITTING, TEE ADAPTOR
18	HDW90945	2	FITTING, FEMALE SWIVEL
	90988	REF	KIT, SEAL-LIFT CYLINDER - LOWER (SERVICE)
N/A	91085	1	HARNESS, WIRE DOWN, VALVE (NOT SHOWN)






91315 LIFT CYLINDER WITH BEARINGS

ART 91315 LiftCyl




ITEM	PART NO.	QTY	DESCRIPTION
			LIFT CYLINDER, UPPER, 3772RT
1	91315	1	CYLINDER, UPPER LIFT, 3772RT
2	91377	1	HOSE ASSEMBLY, LIFT CYLINDER 3/8" × 370"
3	HDW7601	1	FITTING, ELBOW ADAPTOR
4	90439	1	ORIFICE
5	90993	4	BEARING, BRONZE, 2" ID × 2" LG
6	91462	1	VALVE, 2 WAY, N.C. DUAL COIL
8	HDW6727	1	FITTING, PIPE 90°, MALE BARB
9	HDW8152	2	SCREW, 1/4" - 20 × 3/4" LG
11	16062	1	BRACKET, LIFT CYLINDER VALVE GUARD
12	6458	40 FT	HOSE, 5/16", RETURN LINE
14	7788	1	CLAMP, HOSE
15	90969	1	RELIEF VALVE
16	91141	2	COIL, 12 VOLT, DEUTSCH CONNECTOR W/DIODE
	90987	REF	KIT, SEAL-LIFT CYLINDER (SERVICE)
N/A	91086	1	HARNESS, WIRE DOWN, VALVE (NOT SHOWN)





ART_91019-EXP





ART_91278-ASSY






A large red graphic consisting of two overlapping, curved shapes that form a partial circle, framing the section title.

SECTION 6: BASE

BASE ASSEMBLY	6-3
BALLAST (COUNTERWEIGHT) INSTALLATION	6-5
MODULES INSTALLATION	6-7
CONTROL MODULE	6-9
POWER MODULE	6-13
POWER MODULE: ENGINE MOUNT - DIESEL	6-17
ENGINE, DUAL FUEL	6-21
ENGINE, DIESEL	6-25
WIRE HARNESS	6-29
OUTRIGGER INSTALLATION	6-31
GENERATOR - OPTION, DUAL FUEL	6-33
GENERATOR - OPTION, DIESEL	6-35




ART_X72 Base Assy



ITEM	PART NO.	QTY	DESCRIPTION
			BASE ASSEMBLY
1	40159	1	BASE WELDMENT
2	16160	1	LADDER WELDMENT, 3072RT STANDARD
	16293	1	LADDER WELDMENT, 3772RT STANDARD
6	16206	1	COVER, SLIDER PAN
7	14993	2	SUPPORT, MODULE
10	HDW8283	16	SCREW, ½" - 13, 1 ½" LG. GR8
11	HDW8531	4	WASHER, .531 ID × 1.0 OD × .063 THK
12	HDW8457	16	NUT, ½" - 13, GR 5
13	HDW5723	12	SCREW, ¼-12 × ¾"
14	HDW8267	12	NUT, ¼-20
			Serial Number Break 3072RT: 9201083 and up — 3772RT: 9301182 and up
			On previous models, Power to Platform Plug was located in the Control Module (see Page 6-9)
15	16735	1	BRACKET, POWER TO PLATFORM
16	90749	1	POWER TO PLATFORM PLUG
	7617	50'	WIRE (NOT SHOWN)






3072RT


3772RT

ART_X72Ballast






ART_X72CabinetInstall



X72_Control-Cab- ANSI



ITEM	PART NO.	QTY	DESCRIPTION
			CONTROL MODULE
1	16153	1	CONTROL MODULE WELDMENT
2	14896	4	BLOCK, SLIDE, DOOR
3	HDW8273	4	SCREW, ¼-20, 1" LG
4	HDW5217	4	WASHER, .343 ID × .680 OD × .063 THK
5	HDW8267	18	NUT, ¼-20, GR 5
6	16154	1	BRACKET, CROSS SUPPORT
7	HDW5724	4	SCREW, 5/16-18, ¾" LG, GR 5
8	7115	1	HOLE PLUG
			Power to Platform Plug re-located (RT: see Page 6-3 – HD: see Page 6-31)
10	25429	2	PAD
12	91140	1	HYDRAULIC MANIFOLD
13	HDW6433	4	SCREW, 3/8 × 1"
14	HDW7783	4	LOCK WASHER, 3/8
15	16225	1	BRACKET, FUEL TANK
16	HDW5723	18	SCREW, ¼-20 × ¾"
17	16152	1	BULKHEAD
18	HDW8268	5	NUT, 3/8
19	91023	1	FUEL TANK, PLASTIC
20	91091	1	FUEL TANK CAP
	6919	1	FUEL SHUTOFF (NOT SHOWN)
	HDW91279	1	ADAPTER, MALE 1/8 NPT, 5/16 HOSE BARB (NOT SHOWN)
	7788	1	CLAMP (NOT SHOWN)
	6458	72"	HOSE, FUEL LINE (NOT SHOWN)
	HDW91233	1	PLUG (DUAL FUEL) 1/8 NPT, 3/19 HOSE BARB (NOT SHOWN)
	HDW91320	1	ADAPTER (DIESEL)
28	16226	2	BRACKET, CONTROL BOX
29	HDW7888	4	SCREW, 10-32 × ½"
30	91169	1	LOWER CONTROL BOX
	91170	1	HARNESS, MAIN (NOT SHOWN)
32	91375	1	RELAY, SPEED/TORQUE, DRIVE
			CONTINUED ...



X72_Control-Cab- ANSI




ITEM	PART NO.	QTY	DESCRIPTION
			CONTROL MODULE CONTINUED
33	16229	1	BATTERY DISCONNECT BRACKET
34	8841	1	BATTERY DISCONNECT
	9438	1	BATTERY CABLE, RED, 15 INCH LONG (NOT SHOWN)
	9012	1	BATTERY CABLE, RED, 72 INCH LONG (NOT SHOWN)
	9013	1	BATTERY CABLE, BLACK, 72 INCH LONG (NOT SHOWN)
	7172	1	BOOT, BLACK (NOT SHOWN)
	7173	1	BOOT, RED (NOT SHOWN)
40	6854	1	BATTERY, 12VDC
41	2987	2	HOLD DOWN ROD
42	HDW6110	2	WING NUT
43	3436	1	HOLD DOWN BAR
44	91174	1	LEVEL SENSOR
			OUTRIGGER OPTION
45	91280	1	CONTROL MODULE (OUTRIGGER OPTION)
46	HDW90880	4	SCREW, 10-32 × 1"
47	HDW90803	4	NUT, 10-32 NYLOCK
48	91375	1	RELAY (OUTRIGGER OPTION)
49	91268	1	OUTRIGGER MANIFOLD, (OPTION)
50	HDW91332	2	SCREW, 5/16-18 × 3½"
51	HDW8304	2	NUT, 5/15-18
			3772RT EMERGENCY LOWERING
52	16620	1	BATTERY SHELF (3772RT)
53	16619	1	BATTERY BRACKET (3772RT)
54	90898	1	BATTERY, 12VDC (3772RT)
55	25480	1	BRACKET, EMERGENCY DOWN SWITCH (3772RT)
56	HDW90833	2	SCREW, 6-32 × ¾" LG
57	HDW5364	2	NUT, 6-32
58	7423	1	SWITCH, TOGGLE, 1 POLE 2 POS (3772RT)
	91072	1	HARNESS, E-DOWN TO BATTERIES (NOT SHOWN)
	90905	1	HARNESS, E-DOWN W/DIODE (NOT SHOWN)




ITEM	PART NO.	QTY	DESCRIPTION
			POWER MODULE
1	16213	REF	WELDMENT, POWER MODULE
2	16247	1	GUARD, ENGINE MODULE
3	25429	2	PAD
4	40620	2	SPACER, INSULATOR, 1.59" LG
5	14896	4	BLOCK, SLIDE, DOOR
6	14826	1	BRACKET, CROSS SUPPORT
7	HDW8273	4	SCREW, ¼-20, 1" LG
8	HDW5217	4	WASHER, .343 ID × .680 OD × .063 THK
9	HDW8267	4	NUT, ¼-20, GR 5
10	HDW5724	4	SCREW, 5/16-18, ¾" LG, GR 5
			HYDRAULIC TANK INSTALLATION
11	9370	1	LEVEL GUAGE
12	HDW9200	1	PLUG, ¼ NPT
13	HDW6727	2	ELBOW, 90° ¼ NPT – 5/16 BARB
14	HDW7500	1	ELBOW, 90° ¼ NPT – 3/8 JIC
15	91164	1	ELBOW, 90° 1 1/8 NPT – 1 JIC
16	6714	1	FILTER HEAD
17	HDW9268	1	ELBOW, 90° ¾ NPT – ¾ JIC
18	6156	1	FILTER CARTRIDGE
19	9367	1	FILLER/STRAINER






ART_EngineMount DF





ART_EngineMount DSL





ART_X72-LP_INSTALL







ILLUSTRATION No.
ART_2490

Dual Fuel Engine, Kubota DF752



ITEM	PART NO.	QTY	DESCRIPTION
	91035	1	ENGINE, DUAL FUEL ENGINE SUBASSEMBLY, DUAL FUEL
1	91125	1	ENGINE, KUBOTA DF752
2	90239	1	MUFFLER
3	20212	1	CHOKE BRACKET
4	9502	1	CHOKE SOLENOID
5	9498	1	CHOKE LINKAGE
6	20204	1	SPACER
7	HDW91283	1	SCREW, M6-1.0 x 25
8	91133	1	CARBURETOR FLANGE
9	91188	1	INTAKE HOSE
10	21020	1	BRACKET, COMPONENTS
11	91119	1	SOLENOID, THROTTLE
12	91177	1	FUEL PUMP
13	91375	1	RELAY, THROTTLE
14	9252	1	THROTTLE LINKAGE
15	HDW9247	1	SCREW, CAP SOCKET HEAD, ¼-28 x 1.0"
16	HDW91231	2	JAMNUT, ¼-28
17	HDW5723	6	SCREW, ¼-20 x ¾"
18	HDW8267	6	NUT, ¼-20
19	6458	REF	HOSE, FUEL, 5/16
20	7788	5	HOSE CLAMP, 5/16
21	HDW8303	2	SCREW, 5/16-18 x 2
22	HDW8304	2	NUT, 5/16-20
23	91132	1	VALVE, LOCKOFF
24	HDW6894	1	ELBOW, 90° BRASS
25	91197	10 IN	LP HOSE, ½"
26	91198	60 IN	RADIATOR HOSE, 3/8"
27	91232	6	HOSE CLAMP, #8
28	91175	1	OIL PRESSURE SWITCH
29	HDW91187	1	FITTING, 1/8 NPT, M-F
30	90227	1	ALTERNATOR, 40 AMP
			CONTINUED . . .




mecc
 ILLUSTRATION No.
 ART_2490

Dual Fuel Engine, Kubota DF752



ITEM	PART NO.	QTY	DESCRIPTION
			ENGINE, DUAL FUEL (CONTINUED)
31	91129	1	KTR HOUSING KIT, DF752
32	91340	1	HOSE, 2.00" I.D. FLEX
33	7545	2	HOSE CLAMP
34	91376	1	DOWN PIPE (3772RT ONLY)
35	91134	1	EXHAUST PIPE
36	9696	2	MUFFLER HANGER
37	9868	2	MUFFLER CLAMP
38	40620	1	SPACER
39	HDW8279	1	SCREW, 3/8-16 x 2 1/2"
40	HDW8268	1	NUT, 3/8-16
41	91130	1	HUB
42	91160	1	HYDRAULIC PUMP
43	HDW6433	2	SCREW, 3/8-16 x 1"
44	8516	1	OIL FILTER
45	8472	1	RADIATOR
46	9833	1	LPG REGULATOR
47	8514	1	FUEL FILTER
48	7406	REF	HOSE ASSEMBLY, LP
49	91136	1	AIR FILTER ELEMENT
50	91617	1	CARBURETOR ASSEMBLY
51	8365	1	STARTER
52		2	EXHAUST GASKET
53	16372	1	SPACER (3072RT ONLY)
54	91637	4	EXHAUST STUD (3072RT ONLY)






MEC
ILLUSTRATION No.
ART_2491

Engine, Diesel, Kubota D950, X72RT Configuration



ITEM	PART NO.	QTY	DESCRIPTION
	91036		ENGINE, DIESEL ENGINE SUBASSEMBLY, DIESEL
1	91110	1	ENGINE KIT, D905
2	91113	1	RADIATOR KIT
	9831		RADIATOR
3	91111	1	AIR CLEANER KIT
	8667		AIR FILTER ELEMENT
4	91115	1	MUFFLER KIT
	9830		MUFFLER
5	91118	1	EXHAUST PIPE
6	9696	1	MUFFLER HANGER
7	9868	1	MUFFLER CLAMP
8	40620	1	SPACER
9	HDW8279	1	SCREW, 3/8-16 x 2 1/2"
10	HDW8268	1	NUT, 3/8-16
11	91175	1	OIL PRESSURE SWITCH
12	HDW91187	1	FITTING, 1/8 NPT, M-F
13	91116	1	FUEL FILTER ASSEMBLY
	91123		FUEL FILTER ELEMENT
14	6458	8 FT	HOSE, FUEL, 5/16
15	91199	6 FT	HOSE, FUEL, 3/16
16	91114	1	VALVE, CHECK
17	7788	5	HOSE CLAMP
18	91589	1	SOLENOID, THROTTLE
19	16207	1	BRACKET, SOLENOID
20	10695	1	THROTTLE STUD
21	91117	1	CLEVIS
22	HDW91231	2	JAMNUT, 1/4-28
23	HDW5723	2	SCREW, 1/4-20 x 3/4"
24	HDW8267	2	NUT, 1/4-20
25	91112	1	KTR HOUSING KIT, D905
			CONTINUED...





MEC
 ILLUSTRATION No.
 ART_2491

Engine, Diesel, Kubota D950, X72RT Configuration





FIXED CONTROL BOX

REMOVABLE CONTROL BOX



TERMINAL BLOCK ON UNDERSIDE OF PLATFORM DECK



CONTROL MODULE






ILLUSTRATION No. ART_2495

Control Cable and Harnesses, RT Series



ITEM	PART NO.	QTY	DESCRIPTION
			WIRE HARNESS
1	91170	1	HARNESS, MAIN (ANSI) [CONTROL MODULE]
2	91185	1	CONTROL CABLE, 3072RT
2	91321	1	CONTROL CABLE, 3772RT
3	91184	1	HARNESS, CONTROL BOX [INSIDE UPPER CONTROL BOX]
4	91294	1	CABLE, OUTRIGGER [UPPER CONTROL BOX]
5	91295	1	CABLE, OUTRIGGER [DECK TO CONTROL BOX]
6	91296	1	HARNESS, OUTRIGGER [CONTROL MODULE TO DECK]
7	91171	1	HARNESS, ENGINE, INTERMEDIATE
7	91543	1	HARNESS, ENGINE INTERMEDIATE, GENERATOR OPTION [CONTROL MODULE TO ENGINE MODULE]
8	91172	1	HARNESS, ENGINE, DUAL FUEL [ENGINE MODULE]
8	91173	1	HARNESS, ENGINE, DIESEL [ENGINE MODULE]
9	91189	1	CABLE, UPPER CONTROLS, REMOVABLE
10	91557	1	CABLE, UPPER CONTROLS, FIXED
11	91595	1	HARNESS, LOWER CONTROLS [INSIDE CONTROL BOX]
12		1	JOYSTICK CONTROL [INSIDE UPPER CONTROL BOX]
13	90905	1	HARNESS, E-DOWN WITH DIODE (3772RT)
14	91378		HARNESS, E-DOWN TO BATTERY (3772RT)
15	9438	1	BATTERY CABLE, RED, 15 INCHES LONG
16	9013	1	BATTERY CABLE, BLACK, 72 INCHES LONG
17	9012	1	BATTERY CABLE, RED, 72 INCHES LONG
NS	91276	1	HARNESS, OUTRIGGER [CONTROL MODULE TO OUTRIGGERS]
NS	91069	1	HARNESS, LIFT CYLINDER DOWN VALVE (3072RT) [CONTROL MODULE TO LIFT CYLINDER]
NS	91085	1	HARNESS, LOWER LIFT CYLINDER DOWN VALVE (3772RT) [CONTROL MODULE TO LIFT CYLINDER]
NS	91086	1	HARNESS, UPPER LIFT CYLINDER DOWN VALVE (3772RT) [CONTROL MODULE TO LIFT CYLINDER]




ART_OutRigInst



ITEM	PART NO.	QTY	DESCRIPTION
			OUTRIGGER INSTALLATION
1	16279	1	WELDMENT, OUTRIGGER MOUNT, REAR
2	HDW7938	16	SCREW, 5/8-11 x 3" LG
3	HDW6633	16	LOCKNUT, 5/8-11
4	21168	4	WELDMENT, OUTER OUTRIGGER
5	HDW7052	8	SCREW, 1/2-13 x 3 1/2" LG
6	HDW8498	4	SCREW, 1/2-13 x 4"
7	HDW8457	20	NUT, 1/2-13
8	16258	1	LADDER, 3072RT W/OUTRIGGERS
	16294	1	LADDER , 3772RT W/OUTRIGGERS
9	16278	1	WELDMENT, OUTRIGGER MOUNT, FRONT
10	21170	4	COVER, OUTRIGGER CYLINDER
11	HDW6455	20	SCREW, 1/4-20 x 1/2"
12	HDW91328	4	SHOULDER SCREW, 5/8 x 4.75"
13	91278	4	CYLINDER, OUTRIGGER
14	90663	64	SPACER
15	10335	4	TUBE, INNER OUTRIGGER
16	HDW5916	4	SCREW, 1/2-13 x 4.0"
17	20998	4	BRACKET PIVOT
18	HDW91395	4	CLEVIS PIN, 5/8 x 5.0"
19	HDW9219	4	WASHER, FLAT
20	HDW5920	4	PIN, COTTER, 1/8 x 1"
21	21002	4	PAD WELDMENT
			Serial Number Break 3072RT: 9201083 and up — 3772RT: 9301182 and up
			On previous models, Power to Platform Plug was located in the Control Module (see Page 6-9)
22	16735	1	BRACKET, POWER TO PLATFORM
23	90749	1	POWER TO PLATFORM PLUG
NS	7617	50'	WIRE (NOT SHOWN)






MEC
ILLUSTRATION No.
ART_2493

Generator Option, RT, Dual Fuel



ITEM	PART NO.	QTY	DESCRIPTION
			GENERATOR - OPTION, DUAL FUEL REFER TO PARTS SECTION 5 FOR HOSE KIT
1	91550	1	GENERATOR, 2000 WATT
2	5630	1	SWITCH, TOGGLE
3	91551	1	VALVE, SOLENOID, 2-WAY, N.C.
4	91002	1	COIL, 12V 10 SERIES
5	91546	1	NEEDLE VALVE
6	91375	1	RELAY. SPDT
7	91544	1	PLUG, MALE, 3 PRONG
8	91545	2	RECEPTACLE, FEMALE
9	7594	1	STRAIN RELIEF
11	7617	6 FT	WIRE, 14GA, 3 CONDUCTOR
12	91556	1	LABEL, AC GENERATOR
13	9502	1	SOLENOID, GENERATOR-THROTTLE
15	91469	2 FT	CHAIN, SASH #8
16	REF	1	HARNESS, ENGINE INTERMEDIATE, GENERATOR OPTION
17	6434	4	BOLT
18	90480	4	WASHER
19	8268	4	NUT
20	5204	4	BOLT
21	8304	4	NUT
22	16369	1	BRACKET, GENERATOR MOUNT
23		1	GROMMET (PUSH-ON WEATHER STRIPPING)





MEC
ILLUSTRATION No.
ART_2494

Generator Option, RT, Diesel



ITEM	PART NO.	QTY	DESCRIPTION
			GENERATOR - OPTION, DIESEL REFER TO PARTS SECTION 5 FOR HOSE KIT
1	91550	1	GENERATOR, 2000 WATT
2	5630	1	SWITCH, TOGGLE
3	91551	1	VALVE, SOLENOID, 2-WAY, N.C.
4	91002	1	COIL, 12V 10 SERIES
5	91546	1	NEEDLE VALVE
6	91375	2	RELAY. SPDT
7	91544	1	PLUG, MALE, 3 PRONG
8	91545	2	RECEPTACLE, FEMALE
9	7594	1	STRAIN RELIEF
11	7617	6 FT	WIRE, 14GA, 3 CONDUCTOR
12	91556	1	LABEL, AC GENERATOR
13	91589	1	SOLENOID, GENERATOR-THROTTLE
14	91727	1	BRACKET, SOLENOID MOUNT
15	91469	2 FT	CHAIN, SASH #8
16	REF	1	HARNESS, ENGINE INTERMEDIATE, GENERATOR OPTION
17	6434	4	BOLT
18	90480	4	WASHER
19	8268	4	NUT
20	5204	4	BOLT
21	8304	4	NUT
22	16369	1	BRACKET, GENERATOR MOUNT
23		1	GROMMET (PUSH-ON WEATHER STRIPPING)











**SECTION 7:
DECALS**

DECAL KIT, UPPER CONTROL BOX 7-3
DECAL KIT, SIDES, 3072RT 7-5
DECAL KIT, ENDS, 3072RT 7-7
DECAL KIT, SIDES, 3772RT 7-9
DECAL KIT, ENDS, 3772RT 7-11
DECALS - ANCHORAGE POINTS OPTION 7-13


2
91190
THIS CONTROL BOX
TO BE USED WITH
MEC X72RT
MODEL ONLY




5
7155
LOCATE CONTROL BOX HERE
FOR NORMAL OPERATION OF THIS UNIT



3072RT Control Side



3072RT Power Side





90747 -or- 91553



ITEM	PART NO.	QTY	DESCRIPTION
			DECAL KIT, SIDES, 3072RT
1	91156	2	DECAL, MEC 3072RT
2	8402	2	DECAL, RAIL STRIPE
3	7982	2	DECAL, SAFETY STRIPE
4	8503	1	DECAL, KEEP CLEAR
5	91266	2	DECAL, QUAD TRAX 4WD
6	91221	1	DECAL, LOWER CONTROLS, DIESEL
	91157	1	DECAL, LOWER CONTROLS, DUAL FUEL
7	9910	4	DECAL, PINCH POINT
9	90717	1	DECAL, MAINTENANCE LOCK
10	6873	1	DECAL, HYDRAULIC OIL
11	90267	1	DECAL, BRAKE RELEASE
12	9052	1	DECAL, BATTERY DISCONNECT AND LOCK
13	90732	1	DECAL, WARNING, PRESSURE WASH
14	8867	1	TAG, WARNING,
15	6948	1	WARNING, LPG
16	9932	1	DECAL, PLATFORM CAPACITY, SMALL
18	90747	1	SERIAL PLATE: BEFORE SN 9201060
18	91553	1	SERIAL PLATE: AFTER SN 9201061
19	91109	1	DIAGNOSTIC LABEL





ITEM	PART NO.	QTY	DESCRIPTION
			DECAL KIT, SIDES, 3772RT
1	91323	2	DECAL, MEC 3772RT
		2	DECAL, MEC 3772RT HD (W/OUTRIGGERS)
2	8402	2	DECAL, RAIL STRIPE
3	7982	2	DECAL, SAFETY STRIPE
4	8503	1	DECAL, KEEP CLEAR
5	91266	2	DECAL, QUAD TRAX 4WD
6	91221	1	DECAL, LOWER CONTROLS, DIESEL
	91157	1	DECAL, LOWER CONTROLS, DUAL FUEL
7	9910	4	DECAL, PINCH POINT
9	90717	1	DECAL, MAINTENANCE LOCK
10	6873	1	DECAL, HYDRAULIC OIL
11	90267	1	DECAL, BRAKE RELEASE
12	9052	1	DECAL, BATTERY DISCONNECT AND LOCK
13	90732	1	DECAL, WARNING, PRESSURE WASH
14	8867	1	TAG, WARNING,
15	6948	1	WARNING, LPG
16	90269	1	DECAL, PLATFORM CAPACITY, SMALL
17	9465	4	DECAL, DANGER, KEEP CLEAR OUTRIGGERS (HD)
18	90747	1	SERIAL PLATE: BEFORE SN 9301060
18	91553	1	SERIAL PLATE: AFTER SN 9301061
19	91109	1	DIAGNOSTIC LABEL
20	91374	1	DECAL, EMERGENCY LOWERING SWITCH INSIDE
21	90918	1	DECAL, EMERGENCY LOWERING SWITCH




WARNING


- LANYARD ANCHORAGE POINTS ARE RECOMMENDED FOR WORK POSITIONING RESTRAINTS ONLY.

USE OF FALL ARREST SYSTEMS ATTACHED TO ANCHORAGE POINTS ON MOBILE EQUIPMENT MAY CAUSE MACHINE TO TIP, RESULTING IN SERIOUS INJURY OR DEATH.

8606



CERTIFIED LANYARD ANCHORAGE POINT





THIS PAGE IS LEFT INTENTIONALLY BLANK



Limited Owner Warranty

MEC Aerial Platform Sales Corp. warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered. MEC Aerial Platform Sales Corp. further warrants the structural weldments of the main frame and scissor arms to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered. Excluded from such warranty is the battery(s) which carries a ninety (90) day warranty from described purchase date. Warranty claims within such warranty period shall be limited to repair or replacement, MEC Aerial Platform Sales Corp's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC Aerial Platform Sales Corp's then current flat rate, provided the defective part in question is shipped prepaid to MEC Aerial Platform Sales Corp. and is found upon inspection by MEC Aerial Platform Sales Corp. to be defective in material and/or workmanship. MEC Aerial Platform Sales Corp. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty. The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded. No Dealer, Sales Representative, or other person purporting to act on behalf of MEC Aerial Platform Sales Corp. is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC Aerial Platform Sales Corp. any liability or obligation which exceeds MEC Aerial Platform Sales Corp's obligations under this warranty.



Aerial Platform Sales Corp.

1775 Park Street, Suite 77 • Selma, CA 93662 USA
Ph: 1-800-387-4575 • 559-891-2488 • Fax: 559-891-2448
E-mail: info@mecawp.com • Web: www.mecawp.com