





Operator's Manual

CE/Australian Specifications



ART_4265

4069 RT

Serial #13500001 - Up

93075
April 2014

- Specifications** **inside cover**
- Introduction** **1**
- Safety** **2**
 - Safety Alert Symbols 2
 - Fall Protection 3
 - Electrocution Hazard 4
 - Tip-over Hazards 6
 - Fall Hazards 7
 - Collision Hazards 7
 - Additional Safety Hazards 8
 - Battery Safety 8
- Controls & Components** **9**
 - Platform Controls 9
 - Lower Controls 10
 - Component Locations 11
- Workplace Inspection** **12**
- Operating Instructions & Function Tests** **13**
 - Prestart 13
 - Starting Engine from Lower Control Panel 14
 - Starting Engine from Upper Control Box 15
 - Base Controls Operation and Test 16
 - Platform Control Operation and Test 17
 - Control Lever Operation 20
 - Shutdown Procedure 21
 - Deck Extension 22
 - Sheet Materials Rack 22
 - Outrigger Operation (optional) 25
 - Emergency Lowering System 25
 - Fold Down Platform Railings 26
- Maintenance** **27**
 - Routine Maintenance 28
 - Frequent and Annual Maintenance 28
 - Maintenance Lock 28
 - Lubrication 29
- Machine Inspections** **30**
 - Pre-Start Inspection Checklist 31
 - Frequent Inspection Checklist 32
 - Annual Inspection Report 33
- Troubleshooting** **34**
- Warning and Instructional Decals** **35**
- Transport and Lifting Instructions** **38**
 - Loading 38
 - Lifting and Tie Down Instructions 40

—Specifications—

4069 RT			
Working Height*		46 ft	14 m
Platform Height		40 ft	12.0 m
Maximum Drive Height		40 ft	12.0 m
Stowed Height	Top Guardrail	95.5 in.	2.43 m
	Rails Folded	64 in.	1.63 m
	Platform Floor	51 in.	1.3 m
Guardrail Height		43.5 in.	1.11 m
Toeboard Height		6 in.	15 cm
Machine Weight** (Unloaded)		11,500 lb	5,210 kg
Lift Capacity	Total	900 lb	410 kg
	Standard platform w/ Sheet Materials Rack	Platform 600 lb	274 kg
	Sheet Material Rack	300 lb	136 kg
Lift Capacity -- Optional centered platform w/ no Sheet Materials Rack		882 lb	400 kg
Deck Extension Capacity		1 Person / 250 lb (113 kg)	
Maximum Occupants		2	
Length-Stowed (Overall)		126 in.	3.2 m
Length-Stowed (Without Step)		125 in.	3.18 m
Platform Length (Extended)		166 in.	4.22 m
Platform Length (Retracted)		118 in.	3 m
Width (Overall)		69 in.	1.75 m
Platform Width (Outside)		59 in.	1.5 m
Sheet Rack Width††		7 in.	18 cm
Wheel Base		94.5 in	2.4 m
Turning Radius--Inside		79 in.	2 m
Ground Clearance		10 in	25 cm
Drive Speed (Proportional)	Platform Stowed	0-3.4 mph	0-5.5 km/h
	Platform Elevated†	0-.5 mph max.†	0-.8 km/h max.†
Gradability		40%/21.8°	
Breakover Angle		42%/23°	
Optional Outrigger Range Of Motion		10° side to side	
Maximum Ground Pressure, Wheel		123 psi	8.6 kg/cm ²
Maximum Ground Pressure, Outrigger Pad		56 psi	3.9 kg/cm ²
Maximum Wheel Load		3540 lb	1605 kg
Maximum Operating Wind Speed		28 mph / 12.5 m/sec (45 km/h)	
Tire Size		26" x 12" / 66 cm x 33 cm	
Tire Pressure		Foam-filled	
Wheel Bolt Torque		55 ft/lb	74.6 Nm
Hydraulic Pressure	Drive System	3500 psi/ 240 bar	
	Lift System	3200 psi / 220 bar	
Hydraulic Fluid Capacity		14 gal / 53 liter	
System Voltage		12 Volt DC	
Fuel Capacity		15 gal/ 57 liter	
Battery		Type 31 1000CCA	
Engine		Kubota D1105 Diesel 24.8 HP Tier 4	
		Maximum Vibration	does not exceed 2.5 m/sec ² at operator's position
		Ambient Operating Range	-30° C minimum; 50° C maximum
		Sound Pressure At Workstation	80 dB(A)
		Sound Power Level	86 dB @ 1m

Meets requirements of CE EN280:2001 + A2:2009 and Australian Standard AS/NZS1418.10:2011. *Working Height adds 6 feet (2 m) to platform height. **Weight may increase with certain options.

†Drive speed while elevated is inversely proportional to platform height; the higher the platform is, the lower the maximum elevated drive speed. The machine is driveable at full height. ††Not applicable to machines with optional Centered Platform.

Introduction

This Operator's Manual has been designed to provide you, the owner, user or operator, with the instructions and operating procedures essential to properly and safely operate your MEC Aerial Work Platform for positioning personnel, along with their necessary tools and materials, to overhead work locations.



The Operator's Manual must be read and understood prior to operating your MEC Aerial Work Platform. The user/operator should not operate the machine until he/she has been trained and has read and understands the operator's manual as well as having operated the MEC Aerial Work Platform under supervision of an authorized, trained and qualified operator.

It is essential that the operator of the aerial work platform is not alone on the workplace during operation.

Modifications of this machine from the original design and specifications without written permission from MEC are strictly forbidden. A modification may compromise the safety of the machine, subjecting operator(s) to serious injury or death.

Your MEC Aerial Work Platform has been designed, built, and tested to provide safe, dependable service. Only authorized, trained and qualified personnel shall be allowed to operate or service the machine.

MEC, as manufacturer, has no direct control over machine application and operation. Proper safety practices are the responsibility of the owner, user and operator.

If there is a question on application and/or operation contact:



MEC Aerial Platform Sales Corp.

1401 S. Madera Avenue, Kerman, CA 93630 USA

Toll Free: 1 - 877 - 632 - 5438

Phone: 1 - 559 - 842 - 1500

Fax: 1 - 559 - 842 - 1520

info@MECawp.com

www.MECawp.com

Safety

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

Failure to read, understand and follow all safety rules, warnings, and instructions could result in serious injury or death. For your safety and the safety of those around you, you must operate your machine as instructed in this manual.

MEC designs aerial work platforms to safely and reliably position personnel, along with their necessary tools and materials, at overhead work locations. The owner/user/operator of the machine should not operate this machine unless properly trained.

NEVER perform work or inspection on the machine with the platform elevated without first blocking the scissor assembly with the Maintenance Lock (see page 28).

Safety Alert Symbols

MEC manuals and decals use symbols and colors to help you recognize important safety, operation and maintenance information.



RED – Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



ORANGE – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



YELLOW with alert symbol – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



YELLOW without alert symbol – Indicates a potentially hazardous situation which, if not avoided, may result in property damage.



GREEN – Indicates operation or maintenance information.


Fall Protection

Operators must comply with employer, job site and governmental rules regarding the use of personal protective equipment.

If required by your employer or job site, use Personal Fall Protection Equipment (PFPE) when operating this machine.

All PFPE must comply with applicable governmental regulations, and must be inspected and used in accordance with the PFPE manufacturer's instructions.

Fall restraint must be properly attached to a designated anchorage point when driving or operating the machine. Attach only one fall restraint to each anchorage point.



Electrocution Hazard



ELECTROCUTION HAZARD! THIS MACHINE IS NOT INSULATED!

DEATH OR SERIOUS INJURY will result from contact with or inadequate clearance from any electrically charged conductor.

You must maintain a CLEARANCE OF AT LEAST 10 FEET (3.05 m) between any part of the machine, or its load, and any electrical line or apparatus carrying over 300 Volts up to 50,000 Volts. One foot (30.5 cm) additional clearance is required for every additional 30,000 Volts.

Observe Minimum Safe Approach Distance.



Art_2824



Art_2823

DO NOT work in close proximity to, or in contact with, energized power lines and electrical equipment. This machine is not insulated and WILL NOT protect the operator from injury or the machine from damage.

Refer to the following diagram and all applicable governmental regulations for the minimum safe distances from energized power lines and electrical equipment.

DO NOT touch the machine if it contacts energized power lines.

Personnel in the platform:

- Move away from the platform rails,
- DO NOT attempt to operate the machine, and
- DO NOT touch any part of the machine until energized power lines are shut off.


Personnel on the ground:

- DO NOT approach the machine and
- DO NOT touch or attempt to operate the machine until energized power lines are turned off.


Do not operate the machine during electrical storms or lightning.

DO NOT use the machine as a ground for welding unless properly equipped with a weld-line-to-platform option.

Minimum Safe Approach Distance



CLEARANCES FROM LIVE AERIAL CONDUCTORS



LEGEND

- = No shading, in the front views, indicates no proximity requirements
- = Light shading indicates spotter is required
- = Heavy shading indicates the NO GO ZONE

ART_3265

Tip-over Hazards



Art_2828

DO NOT exceed the maximum platform capacity. The weight of options and accessories will reduce the rated platform capacity and must be factored into the total platform load. Refer to the decals on the options.

DO NOT elevate the platform when the machine is on a surface that is soft and/or on a slope. STOP if the alarm sounds and the Tilt light illuminates when the platform is raised. Use extreme caution to lower the platform.

Driving: DO NOT drive the machine on a slope that exceeds the maximum uphill or downhill slope rating. Slope rating applies to machines in the stowed position.

Driving in stowed position: use extreme care and reduce speed when driving across uneven terrain, debris, unstable or slippery surfaces, and near holes or drop-offs.

Driving with the platform elevated: DO NOT drive on or near uneven terrain, unstable surfaces, curbs, drop-offs or other hazardous conditions.

DO NOT push off or pull toward any object outside the platform.

Maximum Allowable Side Force

CE
400 N



Art_2834

DO NOT DRIVE ON IRREGULAR OR UNSTABLE SURFACE

DO NOT elevate the platform when wind speeds are in excess of 28 m.p.h. (12.5 m/s). If wind speeds exceed 28 m.p.h. (12.5 m/s) when the platform is elevated, carefully lower the platform and discontinue operation.

DO NOT increase the surface area of the platform (i.e. cover the rails with tarp or plywood). Increased surface area exposed to the wind will decrease machine stability.

DO NOT attach overhanging loads or use the machine as a crane.

DO NOT exceed the Sheet Materials Rack maximum capacity of 300 lbs (136 kg).

DO NOT exceed the maximum sheet area of 48 ft.² (4.5 m²).

Ensure that material is secure.

NEVER transport tools and materials unless they are firmly secured. Secure all tools and loose materials.

NEVER alter or disable any machine components.

NEVER replace any part of the machine with items of different weight or specification.

NEVER modify or alter the work platform without written permission from MEC.

NEVER place ladders or scaffolds in the platform or against any part of the machine.

NEVER use the machine on a moving or mobile surface or vehicle.

Ensure that all tires are in good condition and lug nuts are properly torqued.

Ensure that air-filled tires are properly inflated.



Art_2833

DO NOT PUSH OR PULL OBJECTS OUTSIDE PLATFORM



Art_2831

DO NOT ELEVATE IN WINDY CONDITIONS



Art_2832

DO NOT USE AS CRANE

Fall Hazards



Art_2826

DO NOT CLIMB ON RAILS

DO NOT sit, stand or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.

DO NOT exit the platform when elevated

Keep the platform floor clear of debris.

DO NOT fasten a fall restraint lanyard to an adjacent structure.

Ensure that the platform entry is properly closed and secured before operating the machine.

Operators must comply with employer and job site rules and governmental regulations regarding the use of personal protective equipment.



Art_2825

DO NOT EXIT PLATFORM WHEN ELEVATED

Collision Hazards



Art_2835

Check path before moving for equipment, materials or other obstructions.

Check path before moving for overhead obstructions.

Check path before moving for crushing hazards when holding the platform rail.

Reduce travel speed when moving the machine on slopes, when near personnel and obstacles, or when surface conditions are wet, slippery or otherwise limiting.

DO NOT operate in the path of any crane unless the controls of the crane have been locked out and/or precautions have been taken to prevent any possible collision.

Stunt driving and horseplay are PROHIBITED.

Watch for personnel and obstructions below the platform when lowering the platform.

From the ground, pay careful attention to the platform during lowering to avoid collision.



Art_2829



Art_2827

Additional Safety Hazards

Explosion and Fire Hazards

DO NOT operate the machine in hazardous locations or locations where potentially flammable or explosive gasses or particles may be present.

Damaged Machine Hazards

Conduct a thorough pre-start inspection of the machine and test all functions before each work shift to check for damage, malfunction and unauthorized modification. Tag and remove a damaged, malfunctioning or modified machine from service. DO NOT use a damaged, malfunctioning or modified machine.

Routine maintenance must be performed by the operator before each work shift. Scheduled maintenance must be performed by a qualified service technician at scheduled intervals. Tag and remove from service any machine that has not had scheduled preventative maintenance performed.

Check that all safety and instructional decals are in place and undamaged.

Check that the operator's, safety and responsibilities manuals are present in the storage container located in the platform. All manuals must be complete, undamaged and readable.

Bodily Injury Hazards

DO NOT operate the machine when there is a hydraulic fluid or air leak. Hydraulic fluid or air under pressure can penetrate and/or burn skin.

All compartments must remain closed and secure during machine operation. Improper contact with components under any cover will cause serious injury. Only trained maintenance personnel should access compartments. The operator should only access a compartment when performing pre-operation inspection.

Weld Line to Platform Safety (if equipped)

Read, understand and follow all warnings and instructions provided with the welding power unit.

Do not connect weld leads or cables unless the welding power unit is turned off at the platform controls.

DO NOT operate unless the weld cables are properly connected.

DO NOT connect the ground lead to the platform.

Battery Safety

Burn Hazards

Batteries contain acid. Always wear protective clothing and eye wear when working with batteries.

Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

Explosion Hazard


Keep sparks, flame and lighted tobacco away from batteries. Batteries emit explosive gas.

Electrocution Hazard

Avoid contact with electrical terminals.

Controls & Components

Platform Controls




ART_4410



ALWAYS be aware of the machine's position and of your surroundings before activating any control function.

CONTROL		DESCRIPTION	
1	Speed/Torque Selector Switch	Move this switch to the up position for high speed drive. Move to the middle position for mid-speed/mid-torque drive. Push this switch to the down position for high torque drive.	
2	Overload Indicator Light	Platform overloaded when light is ON. An audible alarm will sound and all machine functions will stop. Remove weight from the platform to restore function and continue.	
3	Lift/Drive Switch	Move this switch UP to enable the Lift function. Move this switch DOWN to enable the Drive function.	
4	Emergency Stop Switch	Press the EMERGENCY STOP switch at any time to stop all machine functions. Turn switch <i>clockwise</i> to reset.	
5	Start Switch	Turn to far right to start engine. Switch will return to RUN position for normal operation. Turn to OFF to shut engine down.	
6	Glow	Operate when starting in cold start conditions.	
7	Generator (Option)	Starts and stops optional generator.	
8	Horn Button (Option)	Press to sound warning horn.	
9	Drive Enable Indicator (Outrigger Option)	Lamp ON	Outriggers are retracted and machine will drive.
		Lamp OFF	Outriggers are extended and machine will not drive.
10	Extend/Retract (Outrigger Option)	Push the toggle switch DOWN to extend the outriggers. Continue pushing down until the outriggers stop automatically. Push the toggle switch UP to retract the outriggers.	
11	Steer Switch	Using your thumb, press and hold the rocker switch to steer Left or Right.	
12	Control Handle	DRIVE	Proportionally controls Forward and Reverse travel.
		LIFT	Proportionally controls Lift and Lower functions.
13	Enable Bar	Squeeze to enable DRIVE, STEER, and LIFT functions from the Joystick.	

Lower Controls



ART_4399




WARNING

ALWAYS be aware of the machine's position and of your surroundings before activating any control function.

CONTROL		DESCRIPTION
1	Emergency Stop Switch	Press the EMERGENCY STOP switch at any time to stop all machine functions. Turn switch <i>clockwise</i> to reset.
2	Platform Lift Button	Press this button to lift the platform.
3	Platform Lower Button	Press this button to lower the platform.
4	Selector Switch	PLATFORM Select to operate from the platform control panel.
		BASE Select to operate from the base control panel.
		OFF Select to stop operation from either control panel.
5	Hour Meter	Indicates total elapsed time of machine operation.
6	Glow	Operate when starting in cold start conditions.
7	Emergency Down Switch	Move this switch down to lower the platform in the event of an emergency or power loss.
8	Circuit Breaker	Trips when there is excessive electrical load. Push to reset.
9	Start Button	Press to start engine. Release when engine starts.
10	Start Delay Light	Prevents over-cranking of engine. When lit, starter is disabled. After approximately 35 seconds the light will go out and starter will operate.

Component Locations



Module Covers removed for clarity

ART_4403

Workplace Inspection

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

Inspect the workplace and determine whether the workplace is suitable for safe machine operation. Do this before moving the machine to the workplace.

Be sure the lift is the correct machine for the job.

Be aware of workplace conditions, and continue to watch for hazards while operating the machine.

Workplace Inspection

Before operating the machine, check the workplace for all possible hazards, including but not limited to:

- drop-offs or holes, including those concealed by water, ice, mud, etc.
- sloped, unstable or slippery surfaces
- bumps, surface obstructions and debris
- overhead obstructions and electrical conductors
- other objects or equipment
- hazardous locations and atmospheres
- inadequate surface and support to withstand all load forces imposed by the machine
- wind and weather conditions
- the presence of unauthorized personnel
- other possible unsafe conditions

Operating Instructions & Function Tests

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

This section provides instructions and tests for each function of machine operation. Follow all safety rules and instructions. The operator must conduct inspections and a Functions Test of the machine before each work shift to check that all machine systems are working properly.

Test the machine on a firm level surface with no debris, drop-offs, potholes or overhead obstructions. Perform each step outlined in this section.

This machine shall only be operated by trained and authorized personnel. If multiple operators use this machine, all must be trained, qualified and authorized to use it. New operators must perform a Pre-Start Inspection and Functions Test prior to operating the machine.

Operators must comply with all employer and job site rules and governmental regulations regarding the use of personal protective equipment.


DO NOT use a machine that is malfunctioning. If any function does not perform as described, tag the machine and remove for repair by a qualified service technician. After repairs are completed, a Pre-Start Inspection and Functions Test must be performed before using the machine.

Prestart

- Perform *Prestart Inspection* (see page 31).
- Check Emergency Stop Switches at both the base and platform controls – turn clockwise to reset.



ART_3817





ART_2356

- Check Battery Disconnect Switch outside the Controls Module. Must be in ON position.

Starting Engine from Lower Control Panel

Be sure that the upper and lower EMERGENCY STOP Switches are reset.

- **Upper Control Box:** Turn Engine Start Switch to RUN.



- **Lower Control Box:** Turn key switch to BASE.




- Press and hold the START button - release the button when the engine starts.
- **Cold Start:** press and hold the GLOW button as indicated in the Preheat table.
- With the GLOW Button held, press and hold the START Button until the engine starts.
- Release both buttons once the engine starts.

Preheat Table


Ambient Temperature	Preheat Time
Above 50°F (10°C)	5 Seconds
50°F to 23°F (10°C to -5°C)	10 Seconds
Below 50°F (-5°C)	20 Seconds
20 Seconds = Limit of Continuous Use	

- To protect the starter motor, power will cut off to the starter circuit when the starter motor has run continuously for approximately 15 seconds without starting the engine. The Starter Circuit Cutout indicator light will turn on and power to the starter circuit will cut out for 30 seconds.

Starting Engine from Upper Control Box



- **Lower Control Box:** Turn the Key Switch to PLATFORM.



- **Upper Control Box:** Turn the Engine Start Switch to START - release when the engine starts.




- **Cold Start:** lift and hold the GLOW Switch as indicated in the Preheat table.
- With the GLOW Switch held, turn the START Switch until the engine starts.
- Release both switches once the engine starts.

Preheat Table

Ambient Temperature	Preheat Time
Above 50°F (10°C)	5 Seconds
50°F to 23°F (10°C to -5°C)	10 Seconds
Below 50°F (-5°C)	20 Seconds
20 Seconds = Limit of Continuous Use	

- To protect the starter motor, power will cut off to the starter circuit when the starter motor has run continuously for approximately 15 seconds without starting the engine. The Starter Circuit Cutout indicator light will turn on and power to the starter circuit will cut out for 30 seconds.

Base Controls Operation and Test



ART_4400



Check the area above and around the machine for obstructions before operating the machine. The machine must have space to allow full elevation of platform.


Emergency Stop



ART_3817

- Press the Emergency Stop Switch at any time to stop all machine functions.
- Turn switch *clockwise* to reset.

Select BASE Operation




ART_3035

- Turn the Selector Key Switch to BASE.

Lift/Lower

! WARNING

Pay careful attention during platform lowering to avoid collision with personnel or objects.



ART_4274


- Press and hold the Lift button on the Base Control Panel to lift the platform.
- Press and hold the Lower button on the Base Control Panel to lower the platform.

Test Operation

- Raise the platform until it stops. Platform should lift to full height.
- Lower the platform until it stops. Scissor assembly should close completely.
- Releasing the switch will stop Lift/Lower function.
- Pressing the Emergency Stop Switch will stop lift/lower function.

Platform Control Operation and Test

Entering The Platform




ART_4275

Personnel shall enter and exit the platform only at the Personnel Entry Gate.

When entering or exiting the platform, use the hand holds and entry ladder to maintain three point contact with the machine.

Check that the gate is properly secured before operation.

Platform Control Panel



ART_4411

IMPORTANT—Before moving, check that the route of travel to be taken is clear of persons, obstructions, debris, holes, and drop offs, and is capable of supporting the machine.

Platform Operations Test

Emergency Stop



ART_3823


- Press the EMERGENCY STOP switch at any time to stop all machine functions.
- Turn switch *clockwise* to reset.



Activation of the EMERGENCY STOP switch will apply brakes immediately. This may cause unexpected platform movement as the machine comes to a sudden stop. Brace yourself and secure objects on the platform during operation of machine.


Select PLATFORM Operation

- **Base Controls:** Turn the selector switch to PLATFORM.



ART_3038

Operate from Platform



- Enter the platform through the personnel entry gate. Close and secure the entry.
- Turn the platform selector switch to the ON position.
- Start the engine as previously described (see page 15).

- Press the Horn Button (if equipped) to verify proper operation.




Overload Indicator Light



- Light ON indicates too much weight on the platform.
- An audible alarm will sound and all machine functions will stop. Remove weight from the platform to restore function and continue.

Control Lever Operation



ART_2363

- Function speed is proportional and is controlled by the movement of the control lever.
- The further it is moved from neutral (center), the faster the speed will be.
- The control lever returns to the neutral (center) position when released.



WARNING

Do not elevate platform unless guardrails are installed and secure. If the platform fails to lower DO NOT attempt to climb down the elevating assembly. Serious injury may result.



ART_3828

Elevate Platform

- Place the MODE SELECT switch in the LIFT position.
- Squeeze the enable bar and move the control lever toward you.

Test Operation

- Rate of lift is proportional and is dependent on the position of the control lever.
- Elevate to maximum height.
- Releasing the enable bar or the control lever will stop elevation.
- Pressing the EMERGENCY STOP switch will stop elevation.

Lower Platform

- Place the MODE SELECT switch in the LIFT position. Check that no persons or obstructions are in the path of the descending platform.
- Move the control lever away from you.

Test Operation

- Rate of descent is fixed - platform lowers at same rate regardless of handle position.
- Pressing the EMERGENCY STOP switch will stop descent.



WARNING

Check that the route is clear of persons, obstructions, debris, holes and drop-offs, and is capable of supporting the machine.

IMPORTANT—Always check front steer wheel direction before driving.

Steering



ART_3827

- Place the MODE SELECT switch in the DRIVE position.
- Squeeze the Enable Bar.
- Press the Steering Switch with your thumb to steer left or right.

Test Operation

- Releasing the Enable Bar or Steering Switch will stop steering function.
- The steer wheels do not automatically center after a turn. The steer wheels must be returned to the straight-ahead position with the steering switch.



ART_4276

Drive Torque (Speed Control)

Drive speed is selectable until the platform is elevated above 10 Feet (3 m). When the platform is elevated the machine defaults to creep speed and the switch is locked-out (non functioning).

- HIGH SPEED: allows higher drive speeds for travel across flat ground.
- MID-SPEED/MID-TORQUE: use for moderate slopes.
- HIGH TORQUE: use to drive up or down a steep slope or for careful positioning of the machine.

Drive Forward



ART_3827

- Place the MODE SELECT switch in the DRIVE position.
- Squeeze the enable bar and move the control lever away from you.

Test Operation

- Drive speed is proportional and is dependent on the position of the control lever.
- Releasing the enable bar or returning the control lever to the center position will stop drive.
- Pressing the EMERGENCY STOP switch will stop drive.

Drive Reverse



ART_3827

- Place the MODE SELECT switch in the DRIVE position.
- Squeeze the enable bar and move the control lever toward you.


Test Operation

- Drive speed is proportional and is dependent on the position of the control lever.
- Releasing the enable bar or returning the control lever to the center position will stop drive.
- Pressing the EMERGENCY STOP switch will stop drive.

Brake

- For parking, the brake is automatically applied when the control lever is positioned in the neutral (center) position.

Shutdown Procedure




ART_3037

- When finished with the machine, place the platform in the stowed position.
- Park the machine on a level surface.
- Turn the Selector Key Switch to the OFF position and remove the key to prevent unauthorized use.
- Carefully exit the platform using a constant three (3) point dismount/grip.
- Always put the switch in OFF position when leaving the machine at the end of the work day.

Deck Extension

WARNING

CHECK FOR CLEARANCE UNDER DECK AREA BEFORE LOWERING PLATFORM IF THE ROLL-OUT DECK IS EXTENDED.




ART_4277

- Swing up the handle at the rear of the extension deck to raise the spring-loaded pin from the locked position.
- With handle raised, push or pull the deck to the desired extended length and release the handle for the spring-loaded pin to lock into position.
- Extensions can be achieved in intervals of 1 inches (2.5 cm) throughout the entire length of the roll-out extension deck.

Sheet Materials Rack

WARNING

**DO NOT exceed the Sheet Materials Rack capacity of 300 lbs (136 kg).
DO NOT allow any personnel to stand below the machine when the Sheet Materials Rack is in use.
Fasten the material securely with straps or optional material clamps until use.**



ART_4278

This machine is equipped with a Sheet Materials Rack. Up to 300 lbs (136 kg) of sheet material may be secured outside the platform to this rack. Maximum size of material on the Sheet Material Rack is 4' x 12' (1.2m x 3.6 m) for outdoor wind loading. All material should be centered on the Sheet Materials Rack.

Fasten the sheets to the platform with straps or optional material clamps until ready to use. Attach the straps to the guardrail of the main platform only. **DO NOT** fasten the straps to the deck extension guardrail.

Use caution when driving the machine or elevating the platform when the Sheet Material Rack is loaded.

Optional Centered Platform

Machines equipped with the optional Centered Platform are not equipped with a sheet materials rack. DO NOT use the optional Material Clamps/Pipe Racks or mount materials outside the platform.

Optional Material Clamps/Pipe Racks


WARNING

The Material Clamps/Pipe Racks may be used only on the Sheet Material Rack side of the platform. DO NOT use on the side opposite the Sheet Material Rack. All material must be centered.

The optional Material Clamp/Pipe Rack allows the user to hold sheet material in place without the use of straps, or by inverting the clamps, to carry pipe or other long material.

Mount the clamps approximately 8 inches (20 cm) from the ends of the materials, above the Sheet Material Rack. Move the clamps closer together as needed to enable the use of both clamps on shorter material.

Material Clamp Use



ART_4279

Remove the J-shaped arms from the Material Clamps when loading material on the Sheet Material Rack.

When all material is loaded, replace the J-shaped arms as shown and secure them in place with the snap pins.


Pipe Rack Use

WARNING

The Sheet Material Rack MAY NOT be used when the Pipe Rack is in use. Maximum capacity is 125 lbs (57 kg) each side/250 lbs (114 kg) total. Maximum length of pipe/long material is 12 feet (3.65 m). Material must be centered on the Pipe Rack. Material must be entirely contained by the arms of the rack and may not extend above the shorter arm.

CAUTION

Use extreme caution and watch for obstructions when driving and lifting/lowering with long material on the rack.




Mount the J-shaped arms as shown for Pipe Rack use.

The maximum permissible length of material is 12 feet (3.65 m). All material must be centered on the Pipe Rack.

Outrigger Operation (optional)



Check that all ground personnel are clear of the machine before deploying the outriggers.



ART_4407

Lower the outriggers only when the machine is on a firm surface. The surface must be capable of supporting the maximum ground pressure per wheel/outrigger (see Specifications).

The Outrigger Control Switch is located on the front face of the Upper Control Box.

Extend


Push and hold the Outrigger Control Switch DOWN to extend the outriggers.

- The outriggers will extend and level the machine. When the machine is level and ready to operate, the outriggers will stop automatically.
- The Drive Enable Indicator Lamp will turn OFF, indicating that the outriggers are extended and that machine drive function is disabled.

Retract

Push and hold the Outrigger Control Switch UP to retract the outriggers.

- The outriggers will retract.
- The Drive Enable Indicator Lamp will turn ON, indicating that the outriggers are retracted and that machine drive function is enabled.




ART_4291

Emergency Lowering System



If the control system fails while the platform is elevated, use the Emergency Lowering System to safely lower the platform.

Do not climb down the scissor assembly or exit the platform.




ART_4281

The Emergency Lowering System is used to lower the platform in case of power failure.


To lower the platform, push down on the Emergency Lowering Switch, located at the Lower Control Box.

Fold Down Platform Railings




Spring Pin

18 places. Remove as needed to perform the following steps.




1

Fold down the Personnel Entry Gate and Main Deck rear rails.




2

Swing open the front Extension Deck Rail.




3

Fold down the left-side Extension Deck rail.




4

Fold down the left-side Main Deck rail.




5

Fold down the right-side Extension Deck rail.



6

Fold down the right-side Main Deck rail.



Rail Fold-down is complete

ART_4288

To return the machine to normal operation mode:

- Lift all rails into their upright position, then secure them with spring pins
- Check that the Personnel Entry Gate functions properly
- Position the platform control box on the front right rail of the machine.

DO NOT use the machine until all closures and guard rails are in position and properly secured.

Maintenance

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

Tag and remove a damaged, malfunctioning or modified machine from service. DO NOT use a damaged, malfunctioning or modified machine.

Use the Pre-Start Inspection to determine what Routine Maintenance is required. The operator may perform only the routine maintenance items specified in this manual.

IMPORTANT—Scheduled maintenance inspection checklists are included in this manual for use only by qualified service technicians. Only qualified service technicians may perform repairs to the machine. After repairs are completed, the operator must perform a Pre-Start Inspection before proceeding to the Functions Test.



Hydraulic fluid under pressure can penetrate and burn skin, damage eyes, and may cause serious injury, blindness, and death. Repair leaks immediately. Fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.



NEVER perform work or inspection on the machine with the platform elevated without first blocking the scissor assembly with the Maintenance Lock (see page 28).

Failure to perform scheduled maintenance at recommended intervals may result in injury or death. Keep maintenance records current and accurate.

Immediately report any damage, defect, unauthorized modification or malfunction to your supervisor. Any defect must be repaired prior to continued use. DO NOT use a damaged, modified or malfunctioning machine.



Never leave hydraulic components or hoses open. Plug all hoses and fitting immediately after disassembly to protect the system from outside contamination (including rain).

Never open a hydraulic system when there are contaminants in the air.

Always clean the surrounding area before opening hydraulic systems.

Use only recommended lubricants. Improper lubricants or incompatible lubricants may cause as much damage as no lubrication.

Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.

Inspection and maintenance should be performed by qualified personnel familiar with the equipment.

Routine Maintenance

IMPORTANT— The operator may perform only maintenance items on the Pre-Start Inspection Checklist. Frequent and Annual maintenance must be performed by qualified service technicians.

Pre-Start Inspection Perform routine maintenance as identified in the *Pre-Start Inspection Checklist* on page 31.

Frequent and Annual Maintenance


Frequent Inspection Checklists and Annual Inspection Reports must be completed by qualified service technicians trained and authorized to perform maintenance on this machine, and must be done in accordance with the procedures outlined in the service manual. Scheduled maintenance inspection checklists are included in this manual for use by qualified service technicians.

Machines that have been out of service for more than three months must have the Frequent Inspection Checklists completed before returning to service.

Maintenance Lock




NEVER perform work or inspection on the machine with the platform elevated without first blocking the scissor assembly with the Maintenance Lock.



To set the Maintenance Lock, raise the platform enough to allow the Maintenance Lock to rotate to vertical. Carefully lower the platform until the pin above rests securely on the Maintenance Lock.

Lubrication

Operator may perform routine maintenance only. Lubrication listed as Scheduled Maintenance must be performed by a qualified service technician.



Lubrication

No.	ITEM	SPECIFICATION	FREQUENCY
1	Hydraulic Reservoir	Mobile Fluid DTE 10, DTE 13 M, or AW32 Do not substitute other fluids as pump damage may result. Fill to the middle of the sight gauge with platform in the stowed position and outriggers (if equipped) retracted.	Routine Maintenance Check sight gauge level daily Scheduled Maintenance Change yearly or every 600 hours, whichever occurs first
2	Hydraulic Filter	Filter Element (located inside Hydraulic Reservoir)	Scheduled Maintenance Normal Conditions Change every six months or 300 hours, whichever occurs first Severe Conditions--very dusty, exceptionally hot or exceptionally cold conditions Change every three months or 150 hours, whichever occurs first
3	Hubs	SAE 90 Multipurpose Hypoid Gear Oil API Service Classification GL5	Scheduled Maintenance Check every three months or 250 hours, whichever occurs first Change yearly or every 1000 hours, whichever occurs first

Machine Inspections

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

The operator must conduct a Pre-Start Inspection of the machine and test all functions before each work shift to check for damage, malfunction and unauthorized modification.

Tag and remove a damaged, malfunctioning or modified machine from service. **DO NOT** use a damaged, malfunctioning or modified machine.

Use the Pre-Start Inspection to determine what Routine Maintenance is required. The operator may perform only the routine maintenance items specified in this manual.

IMPORTANT— Scheduled maintenance inspection checklists are included in this manual for use only by qualified service technicians. Only qualified service technicians may perform repairs to the machine. After repairs are completed, the operator must perform a Pre-Start Inspection before proceeding to the Functions Test.



Hydraulic fluid under pressure can penetrate and burn skin, damage eyes, and may cause serious injury, blindness, and death. Repair leaks immediately. Fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.



NEVER perform work or inspection on the machine with the platform elevated without first blocking the scissor assembly with the Maintenance Lock (see page 28).

Perform scheduled maintenance at recommended intervals. Failure to perform scheduled maintenance at recommended intervals may result in a defective or malfunctioning machine and may result in injury or death of the operator. Keep maintenance records current and accurate.

Immediately report any damage, defect, unauthorized modification or malfunction to your supervisor. Any defect must be repaired prior to continued use. DO NOT use a damaged, modified or malfunctioning machine.



Never leave hydraulic components or hoses open. Plug all hoses and fitting immediately after disassembly to protect the system from outside contamination (including rain).

Never open a hydraulic system when there are contaminants in the air.

Always clean the surrounding area before opening hydraulic systems.

Use only recommended lubricants. Improper lubricants or incompatible lubricants may cause as much damage as no lubrication.

Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.

Inspection and maintenance should be performed by qualified personnel familiar with the equipment.

Pre-Start Inspection Checklist

The operator must conduct a Pre-Start Inspection of the machine before each work shift.

DO NOT use a damaged or malfunctioning machine.

Initial	Description
_____	Check that the operator's manual and manual of responsibilities are in the storage container located on the platform.
_____	Perform a visual inspection of all machine components. Look for missing parts; torn or loose hoses; hydraulic fluid leaks; loose, torn or disconnected wires; damaged tires; etc.
_____	Check all structural components of the machine for cracked welds, corrosion and collision damage.
_____	Check all hoses and the cables for worn or chafed areas.
_____	Check the platform rails and personnel entry for damage or modification. Check for missing spring pin retainers.
_____	Check that all warning and instructional decals are present, legible and secure.
_____	Check the tires for damage.
_____	Check that all structural components, pins and fasteners are present and properly tightened.
_____	Check for fluid leaks.
_____	Check hydraulic fluid level (check with platform fully lowered).
_____	Check that battery is clean and secure. Check terminals for proper tightness. Check for corrosion.
_____	Check engine coolant level in coolant recovery bottle.
_____	Check engine oil level.
_____	Secure all covers, panels and guard rails.
_____	Ensure that the personnel entry is properly closed and secured before operating the machine.

Consult the Kubota engine manual for details regarding other engine checks and change intervals for filters and fluids.

Frequent Inspection Checklist



This checklist must be used at 3-month intervals or every 150 hours of machine use, whichever occurs first. Failure to do so could result in death or serious injury. The frequency and extent of periodic examinations may depend on national and/or government regulations.

Frequent Maintenance Inspections should be conducted by qualified service technicians only. Photocopy this page for reuse. Keep inspections records up to date. Record and report all discrepancies to your supervisor.

Model Number _____ **Serial Number** _____ **Hour Meter Reading** _____

Initial **Description**

- _____ Perform all checks listed on Pre-Start Inspection.
- _____ Inspect the condition of hydraulic fluid in the reservoir. Oil should be a clear amber color.
- _____ Check battery electrolyte level and connections.
- _____ Check wheel lug bolts for proper torque (see "Machine Specifications").
- _____ Check if tires are leaning in or out.
- _____ Inspect all structure and pivot points for signs of wear and/or damage.
- _____ Check the pin joints and retaining rings for security.
- _____ Inspect the entire machine for signs of damage, broken welds, loose bolts, improper or makeshift repairs.
- _____ Check that the platform does not drift down with a full load.
- _____ Check all wire connections for tightness and corrosion.
- _____ Check outriggers (if equipped) for proper operation.
- _____ Check the operation speeds to ensure they are within specified limits (see *Specifications*).
- _____ Check the emergency lowering system.
- _____ Clean and lubricate all push button switches with dry lubricant and ensure that the switches operate freely in all positions.
- _____ Check the tightness of the platform frame and the linkage pins.
- _____ Check the overall platform and guardrail component security.
- _____ Check the electrical mounting and hardware connections for security.
- _____ Check the steering kingpins for excessive play.
- _____ Consult the Kubota engine manual for details regarding other engine checks and change intervals for filters and fluids.

Additional maintenance requirements for severe conditions

- _____ If the machine is used in very dusty, exceptionally hot or exceptionally cold conditions, replace engine air filter element and hydraulic filter element (under normal conditions replace every 6 months or 300 hours, whichever comes first).

DATE _____ **INSPECTED BY** _____

Annual Inspection Report



Annual Inspection Report

MEC Aerial Platform Sales Corp.
 1401 S. Madera Avenue • Kerman, CA 93630 USA
 877-632-5438 • 559-842-1500 • Fax: 559-842-1520

Date _____
 Serial Number _____
 Model Number _____
 Date Of Last Inspection _____
 Date Placed In Service _____

Customer _____
 Street _____
 City/State/Zip _____
 Phone Number _____
 Contact _____

Dealer _____
 Street _____
 City/State/Zip _____
 Phone Number _____
 Contact _____

- Check each item listed below.
- Use proper Operator's, Service and Parts manual for specific information and settings.
- If an item is found to be "Unacceptable" make the necessary repairs and check the "Repaired" box.
- When all items are "Acceptable", the unit is ready for service.

Key: "Y" Yes/Acceptable
 "N" No/Unacceptable
 "R" Repaired
 "U" Unnecessary/Not Applicable

	Y	N	R	U		Y	N	R	U		Y	N	R	U
Decals:					Base:					Operation:				
Proper Placement/Quantity					Cover Panels Secure					Wires Tight				
Legibility					Base Fasteners Tight					Switches Secure				
Correct Capacity Noted					Bolts Tight					All Functions Operational				
Rails:					Front Axle Mounting (4WD)					Emergency Down:				
All Rail Fasteners Secure					Rear Axle Mounting (4WD)					Operational				
Entry Gate/Chain Closes Properly					Front Axle/Front Wheel Assemblies:					Slow Speed Limit Switch:				
Manual/Safety Data In Box					Wheel Motors-Mounting Secure					Set Properly				
Rear Rail Pad In Place					Wheel Motors-Leaks									
Extending Platform:					Lug Nuts Torqued Properly									
Slides Freely					Steering Cylinder Pins Secure									
Latches In Stowed Position					Pivot Points Lubed									
Latches In Extended Position										Pressures & Hydraulics:				
Rail Latches Work Properly										Oil Filter Secure/Chg				
Cable Secure										Oil Level Correct/Chg				
Platform:					Rear Axle/Rear Wheel Assemblies:					Steering Pressure Set				
Platform Bolts Tight					Brakes Operational					Drive Pressure Set				
Platform Structure					Wheel Motors-Mounting Secure					Lift Pressure Set				
Platform Overload System:					Wheel Motors-Leaks					Engine:				
Functional					Lug Nuts Torqued Properly					Engine Mounts Tight				
Calibrated										Fuel Lines Secure				
Wire Harnesses:										Fuel Lines Free Of Leaks				
Mounted Correctly					Component Area:					Fuel Tanks Secure				
Physical Appearance					Valve Manifold(s) Secure					Fuel Shut Off Valves Func.				
110/220V Outlet Safe/Working					Hoses Tight/No Leaks					All Shields/Guards In Place				
Elevating Assembly:					D/C Mtr(s) Secure/Operational					Oil Level				
Beam Structures					Contactors Secure					Oil Filter				
Welds					Pump Secure					Air Filter				
Retaining Rings					Batteries:					Options Operational:				
Upper Cylinder Pins Secure					Secure					Hour Meter				
Lower Cylinder Pins Secure					Fully Charged					Battery Indicator				
Lower Beam Mounts tight					Battery Charger:					Warning Light				
Rollers Turn Freely					Secure					Warning Horn				
Maintenance Locks:					Operational					Generator				
Secure					Emergency Stop:					Converter				
Operational					Breaks All Circuits									

Comments: _____

Signature/Mechanic: _____ Date: _____
 Signature/Owner-User: _____ Date: _____



Troubleshooting



Should you experience erratic operation or notice any malfunction while operating this machine, discontinue use immediately. Call for assistance and report the incident to your supervisor, and do not use the machine until it has been checked by a trained, qualified mechanic.


Machine functions will not operate

- Master disconnect turned on?
- Battery properly connected?
- Battery fully charged?
- Fuel level sufficient?
- Circuit Breaker tripped?
- Function toggle switch or the Enable Bar not activated?
- Selector Key Switch in proper position?
- Both Emergency Stop Switches reset?
- Hydraulic fluid level low?
- Obvious fluid leak or damaged component?
- Wires disconnected, broken, or loose?

Warning and Instructional Decals

Serial Plate Location

The serial plate is attached to the machine at the time of manufacture. Important information about the machine is recorded on the serial plate.



ART_4316

Serial Plate Description

MFG DATE. Month / Year of manufacture

MODEL NUMBER. Identifies the machine.

SERIAL NUMBER. Identifies a machine with reference to its original owner. Refer to the number when requesting information or ordering parts.

MAX. PLATFORM CAPACITY INCLUDING PERSONS. The maximum safe load (material, persons + equipment) which can be correctly placed on the platform at any elevation.

ELECTRICAL VOLTAGE. The voltage at which this machine operates.

MAX. MANUAL FORCE. The maximum safe force that the occupant can exert laterally on an object outside the platform.

MAX. DRIVE HEIGHT. The maximum safe platform height at which the machine can be driven.

MAX. PLATFORM HEIGHT. The maximum attainable height measured from level ground surface to platform floor.

MACHINE WEIGHT. The weight of the machine with no options.

MAX. WIND SPEED. The maximum wind speed at which this platform may be safely operated.

MAX. GROUND PRESSURE. The amount of pressure exerted on the surface at each wheel. Calculated with all available options installed.

$$P_{max} = 30\% (W_m + W_c + W_{opt}) / \text{Contact Area}$$


MAX. WHEEL LOAD. The maximum safe weight applied to each wheel. Calculated with all available options installed.

$$F_w = 30\% (W_m + W_c + W_{opt})$$

MAX HYDRAULIC SYSTEM PRESSURE. The maximum pressure at which this machine operates.

Decals

All warning and instructional decals must be present, legible and secure.



Decals (continued)

1 93209 (white), 93210 (dark gray)
4 Places
mec 4069 RT

2 92416 (white), 92547 (dark gray)
3 Places
www.mecawp.com

3 90730
WARNING

4 90721
DANGER

5 93204
2 Places

6 90722
WARNING

7 8911

8 not used

9 91850
6 Places

10 90729

11 7156
FRONT

12 93215

13 91730 (Option)

14 92848 (Option)
2 Places
WARNING
PIPE RACK CAPACITY
125 LBS EACH/250 LBS TOTAL.
SHEET MATERIAL RACK MAY NOT
BE USED WHEN PIPE RACK IS IN USE

15 7982
4 Places

16 8503
2 Places
KEEP CLEAR

17 9910
4 Places

18 90739
MADE IN USA

19 90719 (white)
93412 (dark gray)

20 93051
5 Places
WARNING
MATERIAL RACK CAPACITY
300 LBS (136 KG)

21 90717
MAINTENANCE LOCK
REFER TO PARTS AND SERVICE
MANUAL FOR PROPER USE

22 8779
WARNING
BATTERIES PRODUCE
EXPLOSIVE GAS.
CHARGE BATTERIES IN
WELL VENTILATED AREA
DO NOT EXPOSE TO
SPARKS OR FLAMES.

23 90726
WARNING
EACH REPLACEMENT BATTERY MUST WEIGH
A MINIMUM OF 60 POUNDS / 27,3 kg
FAILURE TO MEET MINIMUM WEIGHT
REQUIREMENT MAY CAUSE MACHINE
INSTABILITY.

24 90725
4 Places
WARNING
REPLACE TIRES WITH MANUFACTURER'S
EQUIPMENT ONLY.
FAILURE TO USE MANUFACTURER'S
TIRES MAY CAUSE MACHINE INSTABILITY.
REFER TO SERVICE AND PARTS MANUAL
FOR REPLACEMENT PART NUMBER.

25 11026730
4 Places

26 90751
POWER TO PLATFORM

27 92768

28 not used

29 9052

30 91930

31 90268
PLATFORM CAPACITY
600 LBS (272kg)

32 91975

33 92089

34 6873
HYDRAULIC OIL

35 9465 (Option)
4 Places
DANGER
STAND CLEAR

36 8605
6 Places
CERTIFIED LANYARD
ANCHORAGE POINT

37 8606 (option)
WARNING
LANYARD ANCHORAGE POINTS ARE RECOMMENDED
FOR WORK POSITIONING RESTRAINTS ONLY.
USE OF FALL ARREST SYSTEMS ATTACHED TO
ANCHORAGE POINTS ON MOBILE EQUIPMENT
MAY CAUSE MACHINE TO TIP, RESULTING IN
SERIOUS INJURY OR DEATH.

38 7155
LOCATE CONTROL BOX HERE
FOR NORMAL OPERATION OF THIS UNIT

39 90732
WARNING
DO NOT FUMERASH OR
SMOKE IN THE
COMPARTMENT OR
CONDUIT AREA.
FUMERASH OR
SMOKE MAY CAUSE
DAMAGE AND AFFECT
PROPER OPERATION.

40 92054
Multiple Patents
Pending

41 91325 Australia only
DANGER

42 92119
START RELAY
THROTTLE RELAY
GLOW/CHOKE RELAY

43 93186
4 Places
MAX
3540 lbs
1606 kg

44 92769
2 Places
NO STEP

45 93188 (optional)
4 Places
MAX
3540 lbs
1606 kg

46 7982 cut short to fit
4 Places

47 91388
LWA
86 dB

5 93573
2 Places

31 90577
PLATFORM CAPACITY
400 KG

Optional Centered Platform

Option omits items #14, #20, #44

mec
ILLUSTRATION No.
ART_4408

Transport and Lifting Instructions

Safety Information



WARNING

This section is provided for reference and does not supersede any government or company policy regarding the loading, transport or lifting of MEC machinery.

Truck drivers are responsible for loading and securing machines, and should be properly trained and authorized to operate MEC machinery. Drivers are also responsible for selecting the correct and appropriate trailer according to government regulations and company policy. Drivers must ensure that the vehicle and chains are strong enough to hold the weight of the machine. See the serial number plate for machine weight.

Loading

Free-wheel configuration for Winching or Towing.




DANGER

RUNAWAY HAZARD!

After releasing the brakes there is nothing to stop machine travel. Machine will roll freely on slopes. ALWAYS chock the wheels before manually releasing the brakes.

The machine can be winched or towed short distances at speeds not to exceed 5 MPH (8.05 kph). Before towing or winching the machine, it is necessary to release the brakes. Reset the brakes after towing or winching.



ART_4293

Disengage Brakes before Towing or Winching

- Chock the wheels.
- Push and hold the release valve.
- Using the hand pump on the manifold, pump valve until pressure is built and valve cannot be pumped.
- Machine is now ready for towing.

Engage Brakes before Driving

- Pull out the manual brake release valve to reset brakes.

Brakes will reset automatically when drive function is activated.

Driving or Winching onto or off of a Transport Vehicle

WARNING

Always attach the machine to a winch when loading or unloading from a truck or trailer by driving. Read and understand all safety, control, and operating information found on the machine and in this manual before operating the machine.

- Attach the machine to a winch.
- Remove all machine tie downs. Remove wheel chocks.

Driving

- Turn the Base Key Switch to PLATFORM. Check that the Emergency Stop Switch is reset by turning it clockwise.
- Enter the platform and reset the Platform Emergency Stop Switch.
- Test platform control functions.
- Carefully drive the machine off the transport vehicle with the winch attached.


Note: The brakes are automatically released for driving and will automatically apply when the machine stops.

Winching

- Disengage brakes (see *Disengage Brakes before Towing or Winching* on page 38).
- Carefully operate the winch to lower the machine down the ramp.
- Chock the wheels and engage the brakes.


Securing to Truck or Trailer for Transport

- Turn the key Selector Key Switch to OFF and remove the key before transport.
- Inspect the entire machine for loose or unsecured items.
- Use chains or straps of ample load capacity.
- Use a minimum of four (4) chains or straps.
- Adjust the rigging to prevent damage to the chains and the machine.



Truck Tie Down

Minimum 4 chains of adequate capacity



ART_4285


Lifting and Tie Down Instructions

Lifting Instructions



Only qualified riggers should rig and lift the machine.

Ensure that the crane, loading surfaces, spreader bars, cables, chains and straps are of sufficient capacity to withstand the machine weight. See the serial plate for the machine weight.



Adjust rigging to prevent damage to the machine and to keep the machine level.

Fully lower the platform. Be sure the deck extension is retracted and the module doors are closed and secure. Remove all loose items from the machine.


Determine the center of gravity of the machine.

Attach rigging to the designated lift points *only*.

For machines NOT equipped with outriggers, use two lengthwise spreader bars set to 128" length. Attach rigging to the lift/tie-down points on the chassis. Route the rigging to avoid damage to the guardrails.

Use only slings for outrigger-equipped machines.

Attach the slings to the outrigger weldments as close to the outriggers as possible. Route the rigging as shown to avoid damage to the guardrails.



Center of Gravity	X Axis	Y Axis
4069	49.5" (126 cm)	25.5" (65 cm)

ART_4286



Limited Owner Warranty

MEC Aerial Platform Sales Corp. warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered. MEC Aerial Platform Sales Corp. further warrants the structural weldments of the main frame and scissor arms to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered. Excluded from such warranty is the battery(s) which carries a ninety (90) day warranty from described purchase date. Warranty claims within such warranty period shall be limited to repair or replacement, MEC Aerial Platform Sales Corp's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC Aerial Platform Sales Corp's then current flat rate, provided the defective part in question is shipped prepaid to MEC Aerial Platform Sales Corp. and is found upon inspection by MEC Aerial Platform Sales Corp. to be defective in material and/or workmanship. MEC Aerial Platform Sales Corp. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty. The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded. No Dealer, Sales Representative, or other person purporting to act on behalf of MEC Aerial Platform Sales Corp. is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC Aerial Platform Sales Corp. any liability or obligation which exceeds MEC Aerial Platform Sales Corp's obligations under this warranty.



MEC Aerial Platform Sales Corp.

1401 S. Madera Avenue, Kerman, CA 93630 USA

Toll Free: 1 - 877 - 632 - 5438

Phone: 1 - 559 - 842 - 1500

Fax: 1 - 559 - 842 - 1520

info@MECawp.com

www.MECawp.com

4069 RT

93075