HEFF-T-HERMAN

Models: 015BMEP, 115SPEP, 215SPEP, 216AM, 019BMEP, 119SPEP, 219SPEP, 220AM, 215TM II, 220TM II




Operating, Service and Maintenance Manual









MAYVILLE ENGINEERING CO.
AERIAL WORK PLATFORMS
A DIVISION OF
MAYVILLE ENGINEERING CO., INC.
715 SOUTH STREET
MAYVILLE, WISCONSIN 53050

TABLE OF CONTENTS

1.	Operator Qualifications Safety and Limitations Description Specifications	. 1
2.	OPERATION. Preliminary Installations. Safety Features. Operating Instructions	4 4 6
3.	INSTALLATION EXTENDING PLATFORM	
4.	MAINTENANCE Use of NOTES, CAUTIONS, and WARNINGS Inspection and Lubrication Servicing, Replacement and Adjustments	13 14
5.	TROUBLESHOOTING	34
6.	PARTS CATALOG	63

LIMITED OWNER WARRANTY

Mayville Engineering Co. warrants its equipment, to the original purchaser only, against defects in workmanship and materials under normal use and service for one (1) year from date of authenticated purchase or date equipment is first placed in use, whichever is earlier; excluded from such warranty are the batteries which carry a ninety (90) day warranty from such date of purchase and prorated thereafter up to one (1) year from such date of purchase. Warranty within such warranty period is limited to replacement or repair, at MEC's option, of equipment or parts thereof shipped prepaid to MEC which are found, upon inspection by MEC, to be defective. MEC's sole obligation and buyer's exclusive remedy hereunder shall be limited to such repair or replacement.

MEC SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, INCIDENTAL OR CONTINGENT DAMAGES WHATSOVER. USE OF OTHER THAN FACTORY AUTHORIZED PARTS, MISUSE, IMPROPER MAINTENANCE OR MODIFICATION OF THE EQUIPMENT VOIDS THIS WARRANTY. PARTS OTHER THAN OF OUR MANUFACTURE ARE SUBJECT TO THE ORIGINAL MANUFACTURER'S WARRANTY.

THE FOREGOING WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OF IMPLIED. ALL SUCH OTHER WARRANTIES, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY EXCLUDED.

NO DEALER, SALES REPRESENTATIVE OR OTHER PERSON PURPORTING TO ACT ON BEHALF OF MEC IS AUTHORIZED TO ALTER THE TERMS OF THIS WARRANTY OR TO IN ANY MANNER ASSUME ON BEHALF OF MEC ANY LIABILITY OR OBLIGATION WHICH EXCEEDS MEC'S OBLIGATIONS UNDER THIS WARRANTY.

1. INTRODUCTION

OPERATOR QUALIFICATIONS

Heff-T-Herman is to be operated and maintained by qualified personnel only!

To qualify for operation and maintenance of this unit, an individual must read and thoroughly understand this manual. If a proposed operator or maintenance man fails to understand any segment of this manual, his Supervisor can clarify the misunderstanding through written correspondence or a phone call to:

Mayville Engineering Co. Aerial Work Platforms Division of Mayville Engineering Co., Inc. 715 South Street Mayville, Wisconsin 53050 #414-387-4500

SAFETY AND LIMITATIONS

MEC designs Heff-T-Herman work platforms to be safe and reliable. They are rugged and maneuverable but must be used only for purposes and ways intended. That is to raise personnel and tools to overhead work areas.

The following precautions are based on common sense and on the code of safe practices developed by the Scaffold Industry Association, Inc. for the elevating work platform industry.

- 1. Respect your machine; do not neglect or misuse it.
- 2. Check jobsite for unsafe working conditions.
- 3. Inspect machine before using. Do not use machine if it is malfunctioning in any way.
- 4. Use machine only for purposes for which it was designed.
- 5. Never take chances. Do not use machine if your physical condition is uncertain in any way.
- 6. The platform and its enclosures are not insulated. Do not use near electrically energized circuits.
- 7. An operator of any type of work platform is subject to certain hazards that cannot be protected by mechanical means. It is therefore essential that operators be competent, careful, physically and mentally fit and thoroughly trained in safe operation of this machine.

DESCRIPTION

General

Heff-T-Herman aerial work platforms are electrically actuated, hydraulically operated units. The platform is raised and lowered by a scissors mechanism. The one wheel drive (fifth wheel type) and the two wheel (front wheel drive) self-propelled units are steered by a hydraulic cylinder which is operated from the control console on the platform. Emergency lowering and auxiliary lift controls are located at the base of the machine.




Figure 1. 219 SPEP Plant Master




Figure 3. 220 AM Aisle Master




Figure 2. 119 SPEP Plant Master




Figure 4. 220 TM II Torque Master

HEFF-T-HERMAN SPECIFICATIONS:

Through our constant efforts to improve our products, specifications may change without notice.

PLANT-MASTER:

MODEL NO.	DRIVE	PLAT. HT.	WORK HT.	STOW.	LIFT. CAP.	PLAT. EXT.	POWER	O/A LENGTH	WHEEL BASE	O/A WIDTH	WHEEL TRACK	GRND. CLEAR.	INSIDE TURN RAD.	APPROX. WT.†
015BMEP		15' (4,58m)	21' (6.41m)	28" (.71m)	1000# (453.6kg)	Yes	24 vdc Batt.	89" (2.97m)	73.5" (1.87m)	31" (.79m)	24" (.61m)	2.5" (63.5mm)	N/A	2490# (1129kg)
019BMEP	AROUND	19'4" (5.90m)	25'4" (7.73m)	31.5" (.80m)	500# (226kg)	Yes	24 vdc Batt.	89" (2.97m)	73.5" (1.87m)	31" (.79m)	24" (.61m)	2.5" (63.5mm)	N/A	2750# (1247kg)
115SPEP	1	15' (4.58m)	21' (6.41m)	28" (.71m)	1000# (453.6kg)	Yes	24 vdc Batt.	89" (2.97m)	73.5" (1.87m)	31" (.79m)	24" (.61m)	2.5" (63.5mm)	0"	2595# (1177kg)
119SPEP	DRIVE	19'4" (5.90m)	25'4"	31.5" (.80m)	500# (226kg)	Yes	24 vdc Batt.	89" (2.97m)	73.5" (1.87m)	31" (.79m)	24" (.61m)	2.5" (63.5mm)	0"	2850# (1293kg)
215SPEP	2	15'2" (4.63m)	21'2" (6.46m)	30" (.76m)	1000# (453.6kg)	Yes	24 vdc Batt.	89" (2.97m)	77.5" (1.97m)	30" (.76m)	26" (.66m)	2" (50.8mm)	31" (.79m)	2715# (1231kg)
219SPEP	DRIVE DRIVE	19'6" (5.95m)	25′6″ (7.78m)	33.5" (.85m)	500# (226kg)	Yes	24 vdc Batt.	89" (2.97m)	77.5" (1.97m)	30" (.76m)	26" (.66m)	2" (50.8mm)	31" (.79m)	2975# (1349kg)

[†] Plant-Master weights include 125 lb. (57kg) skid.

AISLE-MASTER:

MODEL NO.	DRIVE	PLAT. HT.	WORK HT.	STOW.	LIFT. CAP.	PLAT. EXT.	POWER	STEER.	O/A LENGTH	O/A WIDTH	GRND. CLEAR.	INSIDE TURN. RAD.	APPROX. WT.*
216 AM	2	15'5" (4.69m)	21'5" (6.53m)	33" (.84m)	1000# (453.6kg)	Yes	24 vdc Batt.	Elec./ Hydr.	90.8" (2.31mm)	34.5" (.88m)	5" (127mm)	38" (.97m)	2765# (1254kg)
220 AM	WHEEL DRIVE	19'9" (6.02m)	25'9" (7.85m)	36.5" (.927m)	500# (226.8kg)	Yes	24 vdc Batt.	Elec./ Hydr.	90.8" (2.31mm)	34.5" (.88m)	5" (127mm)	38" (.97m)	3025# (1372kg)
216 AM HT		15'5" (4.69m)	21'5" (6.53m)	33" (.84m)	1000# (453.6kg)	Yes	24 vdc Batt.	Elec./ Hydr.	90.8" (2.31mm)	34.5" (.88m)	5" (127mm)	38" (.97m)	2815# (1276kg)
220 AM HT		19'9" (6.02m)	25'9" (7.85m)	36.5" (.927m)	500# (226.8kg)	Yes	24 vdc Batt.	Elec./ Hydr.	90.8" (2.31mm)	34.5" (.88m)	5" (127mm)	38" (.97m)	3075# (1395kg)

^{*} Aisle-Master weights include 125 lb. (57kg) skid.

TORQUE-MASTER II:

MODEL NO.	DRIVE	PLAT. HT.	WORK HT.	STOW. HT.	LIFT. CAP.	PLAT. EXT.	POWER	STEER.	O/A LENGTH	O/A WIDTH	GRND. CLEAR.	INSIDE TURN. RAD.	APPROX. WT.*
215 TM II	2 WHEEL DRIVE	15'9½" (4.81m)	21'9½" (6.61m)	33" (.838m)	1000# (453kg)	Yes	24 vdc Batt.	Elec./ Hydr.	94" (2.388m)	47½" (1.207m)	6" (152.4mm)	34.5" (.88m)	2845# (1290kg)
220 TM II	2 WHEEL DRIVE	19'9½" (6.032m)	25′9½" (7.86m)	37" (.940m)	500# (226.8kg)	Yes	24 vdc Batt.	Elec./ Hydr.	94" (2.388m)	47½" (1.207m)	6" (152.4mm)	34.5" (.88m)	3260# (1479kb)

^{*} Torque-Master weight includes 150 lb. (68kg) skid.

2. OPERATION

PRELIMINARY INSTALLATIONS

1. Before operating the machine the control console must be mounted. The control is packed and located under the platform deck, between the scissors. To reach the control console, remove the phillips head screws in the deck board. Lift and remove board. Remove the control console and connect to cable at front of machine. Reinstall deck board in reverse procedure.




Figure 5. Deck Board Removal.




Figure 6. Mounting Control Console.

2. Install Warning Decals

The warning decal specifying the carrying capacity of the extended platform is included in the pack with the operator's manual. Placement of decals is described in installation of the extended platform. (See Page 11.)




Figure 7. Control Switch Locations

SAFETY FEATURES

- 1. Automatic Parking Brake (Two Wheel Drive Units Only)
 - The automatic parking brake is a spring actuated system. The brake is released during drive by hydraulic pressure built up in the drive circuit. A brake valve is used to maintain release during drive and an orifice is used to delay braking function during coast down.
- 2. **Emergency Stop** (All Self-Propelled Units)

The emergency stop is located on the control console. Depress red knob as indicated and all functions of machine will be de-energized. Pull up on knob to reactivate circuits. (Fig. 7)

- 3. Automatic Stabilizer
 - Stabilizers extend automatically as platform is elevated. When positioning unit for work, leave approximately 12 inches of space for stabilizer extension between the unit and any obstruction on both sides of the machine. If the stabilizers contact an immobile object while extending, the platform automatically stops rising.
- 4. Automatic Pot Hole Bars (Aisle Master Models only)
 - Rotate down and out to be flush with the outside edge of wheels. The unit can be positioned with wheels against an obstruction but none between front and rear wheels. (Fig. 8)




Figure 8. Pot Hole Bar.

OPERATING INSTRUCTIONS

A. ALL MODELS

1. To operate your Heff-T-Herman you must first turn the key to the "ON" position. The key is located at the lower control station at the base of the machine. (Figure 9)



Figure 9. Key Switch Location.

- 2. To Raise Platform
 Activate up/down toggle switch to up position. To stop platform, release switch.
- 3. **To Lower Platform**Activate up/down toggle switch to down position. To stop platform, release switch.
- 4. All models have dual controls for raising and lowering. The second set of controls is found at the lower control station. (Figure 9)

B. SELF-PROPELLED MODELS

- To Travel (Forward or Reverse)
 Activate forward/reverse toggle in direction desired.
- 2. **To Steer** (Left or Right)
 Activate steering toggle switch in desired direction.

C. TORQUE MASTER MODELS

1. **To Travel** (Slow Speed 1-mph)

Position slow/fast switch to slow position. Activate primary drive switch (Figure 10) in direction desired. One power source (primary) will propel drive wheels in a series circuit at a reduced speed. (Automatically engaged when platform is elevated **beyond** four feet.)

2. **To Travel** (Regular Speed 2-mph)

Position slow/fast switch to fast position. Activate primary drive switch in direction desired. One power source (primary) will propel drive wheels in a series circuit. (Only available when platform is **below** four feet in elevation.)

3. **To Travel** (High Speed 3-mph)

Position slow/fast switch to fast position. Position power/speed switch to speed position. Activate primary drive switch and secondary motor switch simultaneously in direction desired. Both power sources will propel drive wheels in a series circuit at increased speed. (Only available when platform is **below** four feet in elevation.)

4. **To Travel** (Power Mode - Slow Speed 1-mph)

Position slow/fast switch to slow position. Position power/speed switch to power position. Activate primary drive switch and secondary motor switch simultaneously in direction desired. The primary power source will propel one drive wheel, and the secondary power source will propel the other drive wheel, in a parallel circuit at a reduced speed.

5. **To Travel** (Power Mode - Regular Speed 2-mph)

Position slow/fast switch to fast position. Position power/speed switch to power position. Activate primary drive switch and secondary motor switch simultaneously in direction desired. The primary power source will propel one drive wheel, and the secondary power source will propel the other drive wheel, in a parallel circuit. (Only available when platform is below four feet in elevation.)

6. To Raise Platform (Normal Speed)

Activate the up/down switch to up position. (See Section A-2.)

7. **To Raise Platform** (High Speed)

Position power/speed switch to speed position. Activate the up/down switch to up position and the secondary motor switch simultaneously.

8. To Lower Platform

Activate the up/down switch to down position. (See Section A-3.)




Figure 10. Torque Master Motor Switches

GENERAL OPERATING RULES AND SAFETY

- 1. The following instructions must be complied with to ensure safe operation of the Heff-T-Herman work platform.
- 2. Before operation Ensure that the machine is properly serviced. (**Do Not Use** if machine is not working properly.)
- 3. Ensure that platform guard railings and safety chains are in place whenever someone is on the platform.
- 4. Always set parking brake or lock caster brakes before elevating platform.
- 5. **Do Not** operate on uneven or soft terrain.
- 6. **Do Not** exceed the load capacity of platform.
- 7. Always check clearance around machine before maneuvering. . . . Especially before lowering platform.
- 8. **Do Not** use near power lines. . . . Platform and enclosure are **not** insulated.
- 9. Do Not elevate on incline.

3. INSTALLATION EXTENDING PLATFORM

EXTENDING PLATFORM

1. Drive the expanpin from the pivot pin and remove the pivot pin from the main platform assembly. (Fig. 11)




Figure 11. Pivot Pin Removal.

2. Lift the extending platform up into place, lining up the holes in the platform with those in the main unit.

3. Slide the pivot pin through the holes. (Fig. 12)




Figure 12. Pivot Pin Installation.




Figure 13. Expanpin Installation.

- 4. Install the expanpin in the pivot pin. (Fig. 13)
- 5. Adjust level of extending platform by turning adjusting bolts on main platform. When the extending platform is sitting in the same plane as the main platform, lock the adjustment bolts by turning nuts tight against the main platform. (Fig. 14)




Figure 14. Leveling Platform.

- 6. Install the right hand side rail into its pockets on the platform, with the retaining clip to the inside. Do not bottom the rail completely in its pockets.
- 7. Slide a two by four under the rail to keep it from dropping all the way into its pockets. (Fig. 15)
- 8. Lay the front rail down on the platform, and engage the pin in the front rail in the hole on the right hand rail. (Fig. 16)




Figure 15. Right Hand Rail Installation.

Figure 16. Front Rail Installation.

- 9. Lift left rail up into position. Engage the pin on the front rail in the hole while installing the side rail in its pockets. (Fig. 17)
- 10. Remove two-by-four and bottom the rails in their pockets.
- 11. Secure rails by tightening bolts in the four pockets. (Fig. 18)




Figure 17. Left Rail Installation.




Figure 18. Securing Rails.

NOTE

Decals are found in literature pack. Check to make sure that capacity on decal corresponds with capacity on serial plate.

- 12. Attach decals with platform in extended position as follows: (Fig. 19)
 - a. Place one decal upside down on outside front end of platform.

NOTE

Operator can see this decal when platform is in stowed position.

b. Place one decal right side up on inside of front railing.

NOTE

Operator can see this decal when platform is in extended position.





Figure 19. Warning Decal Installation.



When stowing or extending the platform be sure to move the control box and cord out of the way.

- 13. To return platform to its stowed position, grasp the front rail and pivot back until it disengages from the retaining clips.
- 14. Walk backwards while pulling on front rail until extending platform rotates to its stowed position. Lower railing to its stowed position. (Fig. 20)






Figure 20. Railing Stowed Position.

Figure 21. Platform Latch.

- 15. Extend the platform by grasping the top rail with the left hand and free the latch with the right hand. (Fig. 21)
- 16. Lower platform carefully with both hands on the front rail and walk toward the extended platform as it lowers into position. (Fig. 22) Pivot front rail to its vertical position until it snaps into the retaining clips.
- 17. To retract extending platform, pull back on front hand rail pulling extended platform into the stowed position. Lower front hand rail and check to see that platform latch is in locked position. See Fig. 21.




Figure 22. Lowering Extended Platform.

4. MAINTENANCE

USE OF NOTES, CAUTIONS, AND WARNINGS

NOTE — Additional information to further understand instructions.

CAUTION — Denotes that failure to comply with instructions could cause damage to the equipment.

WARNING — Denotes that failure to comply with instructions would create a hazardous condition that could result in injury to personnel.

.....; WARNING!

Maintenance on the Heff-T-Herman series is relatively simple with a minimum of servicing required; however, with any scissor type lifting device, a hazard to personnel exists when maintenance is performed by working through the lifting beams with the unit raised.

When possible, all maintenance should be performed through the floorboards with the platform lowered. The power core can also be removed to provide access to components while in the lowered position.

BEFORE ANY ATTEMPT IS MADE TO SERVICE MACHINE WHEN EXTENDED OR PARTIALLY EXTENDED, IT IS ABSOLUTELY NECESSARY TO ENGAGE THE MAINTENANCE LOCKS. (Procedure Shown Below.)

- 1. Remove load from platform.
- 2. Raise platform as high as necessary to engage MAINTENANCE LOCKS.
- 3. MAINTENANCE LOCKS located at the front inside corners of the unit lower frame. Lift and slide back to engage. (Fig. 23)




Figure 23. Positioning Maintenance Locks.




Figure 24. Engaging Maintenance Locks.

4. Lower platform until lower beams make contact with the MAINTENANCE LOCKS. (Fig. 24)

DO NOT SERVICE EXTENDED OR PARTIALLY EXTENDED MACHINE UNTIL THE ABOVE PROCEDURE IS FOLLOWED.

INSPECTION AND LUBRICATION

1. Visual Structural Inspection

- a. Visually check machine for bent structural members. (Beams, main frame, platform, lift arm, pivot pins, etc.) Machines which have been overloaded could have bent members and fatigued pivot pins. Replace all bent members and pins, and always replace lower pivot pin at center of lower cross beams to insure a safe operating machine.
- b. Check bushings in scissor beams for broken or cracked welds. Replace beams if bushing welds are cracked or bushings elongated.

2. Lubrication

All pivot areas of scissors and lift cylinder must be lubricated as described. Failure to do so will result in extensive damage to structural members and bushings which would create a hazardous condition and could result in injury or death to personnel.

Every 15 hours or weekly, whichever comes first, lubricate the following areas with EP-90 oil or equivalent:

All pivot areas of scissor members and lift cylinder. (Both sides of bushing in beams.)
 (Figs. 25 and 26)




Figure 25. Scissors Lubrication Areas.





Figure 26. Scissors Lubrication.



2-Wheel Drive

1-Wheel Drive

Figure 27. Lubricating Steering Linkage.

- b. Pivot points of steering cylinder and pivot areas of steering linkage. (Fig. 27)
- c. Pivot points of brake cylinder.
- d. Lubricate bushings (4). (Fig. 28)
- e. Lift arm, platform, and base rollers. (Fig. 29 and 30) Lubricate shaft on both sides of roller.




Figure 28. Lubricating Brake Linkage.




Figure 29. Lift Arm and Platform Lubrication Points.




Figure 30. Lubricating Roller at Lift Arm.

Grease the following fittings weekly:

- a. Lift arm pivot tube. (Fig. 31)
- b. Caster swivel plates and caster axles.

Pack rear wheel bearings every six months, or sooner if required (on 2-wheel self-propelled models only).




Figure 31. Grease Fitting Location.

- Battery
 1. Check Wiring
 2. Check Fluid Level

- Hydraulic System

 1. Check for Leaks
- 2. Check Hoses

- 2. Check Hoses
 Scissor System
 1. Check for Damage
 2. Check Snap Rings

Platform

- 1. Safety Chains
- 2. Extension Latch and Pin
- 3. Extension Pivot Pin
- 4. Railings Secure in Pockets
- 5. Safety Decals

- Keep log as follows:
 1. Inspect components
 2. Check Boxes if components OK

or

Make repairs 3. Initial boxes

- Key:
 B Battery
 H Hydraulic System
 S Scissor System
- P = Platform

MONTH				
DAY	7	14	21	28
INIT.				
B-1				
2				
H-1				
2				
S-1				
2				
P-1				
2				
3				
4				
5				
MONTH				
DAY	7	14	21	28
INIT.				
B-1				
2				
H-1				
2				
S-1				
2				
P-1				
2				
3				
4				
5				
MONTH				
DAY	7	14	21	28
INIT.				
B-1				
2				
H-1				
2				
S-1				
2				
P-1				
2				
3				
4				
5				

Table 3A. Inspection and Lubrication Daily Log.

				p						·			 	
MONTH														
DAY														
INITIAL														
Battery				banes ne samel em sinkk	nin minimin ka	umlikasise ((garyisaika)		<u> </u>		-	· ·		 •	
1. Clean Battery														
2. Coat Terminals			***************************************									***************************************		
Hydraulic System					•								 	
1. Check Fluid Level														
2. Inspect Commutator and brushes*		Da	te L	ast	Che	ckec	i i							
3. Check Fittings														
Scissor System						~							 and a second second	
1. Oil Pivot Points & Rollers														
Drive and Lift Mechanisms	···												 	
1. Oil Steering Pivot Points														
2. Oil Brake Pivot Points														
3. Grease Lift Arm, Pivot Tube (All Models)														
Main Frame														
Grease Caster Axles and Swivel Plates (Manual and 1 SP)	***************************************													
Grease Drive Assembly Spindles (2 Wheel Drive Models)														
3. Check Structure and Pivot Pins														
Control System														
1. Check Terminals and Plugs														
2. Check Cords														

^{*}Check every 6 months

Table 3B. Inspection and Lubrication Weekly Log.

		TIME II	NTERVAL	
COMPONENT	DAILY	WEEKLY	6 MONTHS	1 YEAR
Battery 1. Check Wiring 2. Check Fluid Level 3. Clean Battery Connections 4. Coat Terminals	X X	X		
Hydraulic System 1. Check for Leaks 2. Check Fluid Level 3. Inspect Commutator and Brushes 4. Check Hoses 5. Check Fittings	X	X	Х	
6. Oil Filter (Replace) Scissor System 1. Check for Damage 2. Oil Pivot Points and Rollers	X	X		X
Drive and Lift Mechanism 1. Oil Steering Pivot Points 2. Oil Brake Pivot Points 3. Grease Lift Arm, Pivot Tube		X X X		
Main Frame 1. Grease Casters 2. Check Structure 3. Check Pivot Pins 4. Grease Wheel Spindles		X X		X
Control System 1. Check Terminals and Plugs 2. Check Cords		X X		
Safety Decals* 1. Check if missing. Add if necessary. 2. Check if legible. Replace if necessary.	X X			
Platform 1. Safety Chains 2. Extension Latch and Pin 3. Oil Latch Pivot Pin 4. Extension Pivot Pin 5. Oil Extension Pivot Pin 6. Railing Secure in Pockets	X X X X			

^{*} See page 61 for safety decals and locations.

Table 3C. Inspection & Lubrication Schedule.

SERVICING, REPLACEMENT & ADJUSTMENTS

This section contains three basic maintenance functions: Servicing, Replacement, and Adjustments.

SERVICING describes items to be checked and serviced when necessary, on a daily basis, or prior to using the unit after it has been out of service for a period of time.

REPLACEMENT describes the proper method for removal and installation of replaceable components in case of failure.

ADJUSTMENT describes any adjustments necessary to ensure proper operation of the unit or adjustments required after the replacement of components, if necessary.

CAP SCREWS

NOTE: Any bolt replacement should be of same grade or greater than original bolt. Any questions, call the factory for verification.

Grade markings for Cap Screws grades 2, 5, and 8 are based on SAE J429. Markings may be raised or depressed (Manufacturer's option).



1. BATTERY

NEVER SMOKE OR USE OTHER COMBUSTIBLES NEAR BATTERY WHILE SERVICING BATTERY OR OTHER COMPONENTS. PROVIDE PLENTY OF VENTILATION. PRESENCE OF HYDROGEN FUMES COULD LEAD TO EXPLOSION!

Heff-T-Herman battery models are supplied with heavy duty deep-cycle batteries. The care and maintenace of your batteries has much to do with how well your Heff-T-Herman functions. Battery wiring and water level should be checked daily. After using Heff-T-Herman continuously for a period of time, it is recommended that the batteries be brought to a full charge as soon as possible. If the batteries are allowed to remain discharged, the lead plates will harden and become sulfated. This will shorten their life as much as over-charging. In this sulfated condition the battery fails to deliver its rated capacity or come up to full charge. Several long, slow charges and fast discharges are then necessary to correct the sulfation and hardened plates. It is recommended that once a month the batteries be given an equalizing charge of 25% over the regular charge. The equalizing charge must always be given at a low rate to eliminate excessive gassing. Whenever battery temperature reaches 125°F, the charging rate should be reduced or the battery taken off charge and allowed to cool to room temperature.

Do not overfill. When the cells are filled too full, the battery fluid will expand as it becomes warm from charging causing fluid to seep out. Each time this happens, the solution weakens by adding water. Loss of ampere hour capacity will result. Do not run battery dead. Put battery on charge when approximately 80% discharged. (Hydrometer reading of 1.500 at 80° F. or 26.6° C.)

NEVER SMOKE OR USE OTHER COMBUSTIBLES NEAR BATTERY. MAKE SURE THERE IS PLENTY OF VENTILATION. HYDROGEN FUMES COULD LEAD TO EXPLOSION.

- a. Checking and Filling (Every 15 hours of use or when recharging)
 - (1) Lower platform completely.
 - (2) Remove floorboard.
 - (3) If there is any dirt or corrosion on battery, wash with solution of 5 teaspoons baking soda per quart of warm water.
 - (4) Remove battery caps and check fluid.
 - (5) Fill, if needed, as follows:
 - (a) Before charging, fluid must be above plates in battery.
 - (b) After charging, fill to split ring.



CAUTION

Do not overfill. Fluid will expand as it becomes warm from charging and seep out of the battery. When water is then added, the solution is weakened and a loss of ampere hour capacity results.

Never add acid to battery. The solution is at its proper strength when the battery is manufactured. Use distilled water and keep fluid up to proper level. When required, water should be added to battery **after** charging, unless water level is below the top of the plates.

(6) Coat terminals with petroleum jelly or equivalent coating.

b. Charging Notes

- (1) The surrounding temperature has a great effect on the power reserve in a battery.
 - (a) A battery 100% charged at 80° F.
 - -drops to 65% at 32° F.
 - -drops to 40% at 0° F.
 - (b) A battery 46% charged at 80° F.
 - -drops to 32% at 31° F.
 - -drops to 21% at 0° F.
- (2) When battery temperature reaches 125°, battery should be taken off charge and cooled to room temperature or the charging rate should be lowered.
- (3) Battery should be brought to full charge as soon as possible after continuous use. (Hydrometer reading of 1.265 at 80°F. or 26.6°C.

(Lead plates in discharged batteries become hardened and sulfated. The battery eventually will not deliver its rated capacity or come up to a full charge. Several long slow charges and fast discharges help restore plate condition.)

(4) Once a month, battery should be given an equalizing charge of 25% over regular charge. Charge must be given at low rate to avoid gassing.

c. Charging

- (1) Lower platform completely.
- (2) Remove floorboards.
- (3) Remove caps, check fluid level and if needed, fill to cover plates.
- (4) Reinstall caps before charging.

NOTE

After charging, fill to split ring.

- (5) Plug charger into 120 VAC, 60 HZ power source.
- (6) Turn timer clockwise to "ON" position.
- (7) Charge until meter reads in finish area or near zero (0). (Charger will turn off automatically when timer runs out.)
- (8) Unplug charger.
- (9) Check that fluid level is up to split rings and reinstall caps.

d. Battery Replacement

- (1) Completely lower unit.
- (2) Remove floorboard.
- (3) Remove nuts from battery hold down and remove.
- (4) Remove battery cables.
- (5) Remove battery.
- (6) Reverse procedure.

2. HYDRAULIC SYSTEM

a. Hydraulic Pump Motor Servicing

Common maintenance on DC motors is brush replacement. It is recommended that brushes be checked and replaced if necessary, along with commutator inspection, approximately every six months. The time element will greatly vary depending on how the machine is being used and the condition of the battery. It is to your advantage to keep the batteries fully charged and in top condition to eliminate service problems in general, and to extend the life of the motor and brushes. (See Battery servicing)

b. Check and Fill Hydraulic Reservoir

- (1) Raise platform, engage safety locks and lower platform on safety locks.
- (2) Check sight gauge on right side of machine. (Fig. 32)
- (3) If oil is not visible in sight gauge, unscrew the filler plug located inside the left frame member and fill the reservoir with hydraulic fluid conforming to MIL. Spec. O-5606. (Fig. 32)

- (a) The reservoir should be filled with the platform raised and the safety locks engaged. Check the reservoir level with the platform lowered onto the safety locks. Oil should be visible in the sight gauge at this position. This ensures that the proper amount of oil is available when the platform is fully lowered.
- (b) If filling the reservoir is required when the platform is in a stowed position, remove the reservoir sight guage and fill the reservoir with oil through the sight gauge hole. Then replace the sight gauge, raise the platform, engage the safety locks and adjust the oil level to the proper height.
- c. **Spin-on Oil Filter** The spin-on oil filter in the Hydraulic system should be changed yearly. Replace with filter part #6156 only. (Fig. 32)




Figure 32. Hydraulic Oil Sight Gauge and Oil Filter.

d. Hydraulic System Bleeding

The Heff-T-Herman hydraulic system is self-bleeding. After the system has been drained, such as during the replacement of a hydraulic system component, actuate the platform full up and down for six cycles and recheck the reservoir fluid level between each cycle. Fill as required.

e. Hydraulic Pump and Motor Replacement

- (1) Disconnect positive and negative battery cables by separating quick disconnect connector located beneath left frame rail.
- (2) Remove power core from base.
- (3) Tag and remove wires from hydraulic pump and motor assembly.
- (4) Remove hydraulic hoses from pump.

NOTE

In the following step, the high pressure hydraulic line may still be under pressure and fluid will squirt out when line is disconnected. Do not reuse fluid, as it may become contaminated.

(5) Remove four bolts securing pump motor to base mount from underside of base.

- (6) Lift pump up out of base and remove.
- (7) Install new or repaired hydraulic pump assembly in reverse order of removal. Install power core to base.
- (8) Refill hydraulic reservoir to replace fluid lost during disassembly.
- (9) Raise and lower the platform six times to bleed the system. Check the fluid level after cycling and fill as required.

3. SLOW SPEED SWITCH (Self-Propelled Units Only)

a. Adjustment

- (1) Raise platform approximately (4) four feet.
- (2) Remove lower control box.
- (3) Adjust switch in or out to activate circuit at this height. Slow speed valve will then be energized when platform reaches this height allowing machine to travel in slow speed only.

4. BRAKES (2-WHEEL SELF-PROPELLED UNITS ONLY)

NOTE

Adjust brakes so that parking brake holds machine on an incline which it is capable of climbing.

a. Adjust brake rods and spring tension as follows:

(1) Loosen adjustment block bolts. (Fig. 33)




Figure 33. Adjusting Brakes.

- (2) Loosen spring adjustment nut until nut is at end of stud (PM models only).
- (3) Remove screws holding lower control panel. Lay on boards stuck in fork pockets.
- (4) Remove wire 3 (coming from component tray) from terminal board TS1-3. Temporarily connect to TS1-1.
- (5) Actuate drive switch forward then reverse to fill brake cylinder with fluid. Valve V4 should be energized by step 4 and hold cylinder in extend position. Brake cylinder must remain at full extension during setup.

NOTE


If this does not occur, check to make sure V4 is energized or it is not leaking. If so, replace first.


- (6) Rotate brake eccentric shafts to obtain the following:
 - (a) SPEP's: 1/8" gap between brake pad and wheel. (Fig. 33)
 - (b) TM and AM Models: 1/16" gap between brake shoe and wheel drum. (Fig. 35)

NOTE

Brake pad eccentrics must be toward rear of unit.

- (7) Tighten bolts in adjustment block when dimensions are achieved on both sides.
- (8) Return wire 3 to proper location.
- (9) Tighten brake spring adjustment nut to obtain 3/4" to 1" of thread showing at end of threaded stud.
- (10) Test drive unit on flat surface and observe brake pad action. Both brake pads should lift off wheels on start up and come back to rest near end of coast down. If braking action is too soon, repeat steps above increasing gap slightly. If too long, reduce gap.








Figure 35. Brake Shoe Clearance.

5. FRONT WHEEL ALIGNMENT (All 2 WHEEL DRIVE MODELS)

NOTE

Front wheels should be aligned so that wheel brackets are parallel to the center bar. (Fig. 36)

a. Adjust tie rods so that brackets are parallel to center bar.




Figure 36. Aligning Front Wheels.

b. Steering Stop Adjustment (TM II Model and AM Model)

- 1. Loosen the lock nut, and back all four steering stop bolts out completely so they do not protrude from the bracket. (Fig. 37)
- 2. Turn the front wheels hard left so the steering cylinder is completely extended. (Fig. 38)
- 3. There should be a slight gap between the steering stop and the adjustment bracket. Turn the front adjustment bolt in so that the gap is removed and the bolt just contacts the stop. Tighten the locking nut.
- 4. Turn the steering hard right and repeat the adjustment on the rear steering stop bolt.
- 5. Repeat the adjustment for the opposite wheel.




Figure 37. Steering Stop Bolt.




Figure 38. Steering Stop Adjustment.

c. Flow Control Valve

- (1) Raise unit to fully extended position. (Engage maintenance locks while adjusting.)
- (2) Depress DOWN switch and open or close flow control valve, as necessary, to adjust descent speed of platform to about 6" per second.

6. HYDRAULIC LIFT CYLINDER (ALL MODELS)

.....; WARNING !

- 1. This procedure requires platform to be raised for access to unit through opened lifting beams.
 - NEVER work through beams unless maintenance locks are engaged correctly; serious injury or death can result if locks are not correctly engaged. (Fig. 39)
- 2. Follow steps in order. Failure to do this could result in serious injury or death.

A. Replacement

- 1. Raise platform.
- 2. Engage maintenance locks. (Fig. 35)
- 3. Place a $4'' \times 4'' \times 36''$ long block of hardwood under center pivot pin of lower beam for added safety. (Fig. 40)




Figure 39. Engaging Maintenance Locks.




Figure 40. Installing Wood Block for Safety.

- 4. Lower platform until lower beams touch maintenance locks.
- 5. Remove cotter pin from lower cylinder pin.
- 6. Set up to remove cylinder as follows:
 - Attach rope to end of lift arm, around roller and wrap once around center pivot bar which is third from bottom center pivot bar. Attach a weight of about 8 lbs. to end of rope. (Fig. 41)

NOTE

The weight counterbalances the lift arm and makes it easy to maneuver.




Figure 41. Counter Balancing Lift Arm.

Figure 42. Taking Pressure Off Lift Support Rod.

Relieve pressure on lift arm support rod by activating down switch with the aid of a vise grip pliers as weight, and forcing lift arm down with a board (2" x 4" x 8") until there is 1/2" clearance between arm and support rod. (Fig. 42)

- 7. Remove low pressure hose from upper end of cylinder and high pressure hose from lower end of cylinder.
- 8. Remove lower cylinder pin. Lower cylinder toward floor and pivot lift arm down as far as possible.
- 9. Remove one plug from lift arm at attaching point to cylinder.
- 10. Remove upper lift arm pin and remove cylinder.
- 11. Install new or repaired hydraulic cylinder in reverse order.
- 12. Grease top cylinder pin before reinstalling new cylinder. (Fig. 43)





Figure 43. Top Cylinder Pin.

- 13. Grease and replace bottom cylinder pin as follows: (Fig. 44)
 - a. Install pin with spacer on each side and secure with cotter pin.

Be sure that one leg of cotter pin is bent 90° to ensure that when cylinder pin rotates it will not straighten leg of cotter pin.






Figure 44. Bottom Cylinder Pin.

Figure 45. Blocking Up Lower Beam.

- 14. Raise piatform, disengage maintenance locks and completely lower platform.
- 15. Bleed air from system (see Step #9 under Servicing Hydraulic System).

7. CENTER PIVOT BAR, LOWER BEAM (ALL MODELS)

Failure to follow instructions in proper sequence could result in serious injury or death.

A. Replacement

- 1. Place machine so that there is room to work on both sides of machine.
- 2. Set up to remove pivot bar as follows:
 - a. Raise platform high enough to place a 4" x 4" x 36" long block of hardwood on top of machine base and under lower beam center pivot bar. (Fig. 45)

- b. Lower platform until beams rest on 4×4 .
- c. Insert jack between second and third inner beam from bottom of unit. (Fig. 46)
- d. Spread beams approximately 2" with jack.




Figure 46. Installing Jack.

e. Actuate lift switch until lift arm makes firm contact with support bar. (Fig. 46)

NOTE

This step is designed to remove free play from lift arm to maintain alignment of bushings.



CAUTION

Do not overlift or jack may fall out of place.

- 3. Remove retaining ring from end of pivot bar.
- 4. Attach one retaining ring to new pivot bar (Part Number 1946).
- 5. Install new bar as follows:
 - a. Lubricate new pivot bar with heavy grease.

...... WARNING

Keep opposite side of machine clear of people when driving the old bar out with the new pivot bar, in the next step. The old bar can shoot out of beam bushings at high speed, causing injury to people and/or damage to nearby equipment.



In the following step, use a rawhide or lead hammer. Do not use a steel hammer on pivot bar or damage to the retaining ring groove can result.

- b. Rap the end of the old pivot bar with the hammer to start the bar through the first beam.
- c. Place the free end of the new pivot bar against the old bar and drive the new bar in with hammer.

NOTE

If bushings become misaligned, it may be necessary to do one of the following:

- 1. If bushings are vertically misaligned, the 4×4 must be moved fore or aft with hammer.
- 2. If bushings are horizontally misaligned, adjust with jack either up or down.
- c. Attach retaining ring to other end of pivot bar.
- 6. Remove hydraulic jack and remove 4 x 4 block raising unit with lift control.
- 7. Check unit for proper operation before returning to service.

8. ALL OTHER BEAM PIVOT BARS (ALL MODELS)

Perform the following procedure with unit in the fully down (stowed) position. Attempting to replace this pivot bar with the platform raised could cause serious injury or death.

A. Replacement

- 1. Place machine so that there is room to work on both sides of machine.
- 2. Remove retaining ring from end of pivot bar.
- 3. Attach one retaining ring to new pivot bar (Part Number 1946).
- 4. Install new pivot bar as follows:
 - a. Lubricate new pivot bar with heavy grease.

Keep opposite side of machine clear of people when driving the old pivot bar out with the new pivot bar. The old bar can shoot out of beam bushings at high speed, causing injury to people or damage to nearby equipment.



In the following step, use a rawhide or lead hammer. Do not use a steel hammer directly on pivot bar or damage to retaining ring groove can result.

- b. Rap the end of the old pivot bar with hammer to start bar through the first beam.
- c. Place free end of new pivot bar against old bar and drive new bar in with hammer.

NOTE

If bushings get misaligned, realign by jogging platform up slightly with lift control.

- d. Attach retaining ring to other end of pivot bar.
- 5. Check unit for proper operation before returning to service.

9. AUTOMATIC STABILIZERS

There are three (3) areas of concern when replacing stabilizer components.

- Stabilizer switch adjustment
- Stabilizer activating arm adjustment
- Stabilizer bar spacing to floor

a. Stabilizer Switch Adjustments

- (1) Raise lift to its full elevated position.
- (2) Check spacing between switch plunger and actuator angle. (Fig. 47) This space should be about .060 inch (the thickness of a nickel).
- (3) To adjust loosen locknut on adjustment bolt and adjust in or out accordingly to obtain the .060 spacing.
- (4) Retighten locknut, then recheck spacing between plunger and angle.




Figure 47. Stabilizer Switch Adjustment.




Figure 48. Activating Arm Adjustment.

b. Stabilizer Activating Arm Adjustment:

(1) Raise lift to full elevated position.

Stabilizers are spring loaded — Care must be taken when performing the next step of these instructions.

- (2) Close stabilizers manually by rotating cam pivot (Fig. 48) back over center so stabilizers are in the closed position.
- (3) Remove stabilizer closing spring between stabilizers.
- (4) Remove stabilizer over center spring.
- (5) Remove roll pin from closing pin at stabilizer arm.
- (6) Adjust length of actuator arm by rotating rod eye.

To obtain proper length, align pivot points A, B, & C in a straight line while stabilizer arm is **against stop.** *It is important that the stabilizer is against the stop when making this adjustment.* When rotating cam to full open position the spring washers should collapse slightly, but not enough to activate the stabilizer switch.

c. Stabilizer Bar Spacing to Floor

- (1) Before removing the stabilizer arms or stabilizer bar from the unit, mark the location of all spacers and washers.
- (2) When assembled correctly, the space from the lower edge of the stabilizer bar to the floor must not exceed .750 inch. (Fig. 49)

NOTE

On Aisle Master Models only the space from the lower edge of the stabilizer bar to the floor must not exceed .500 inch (Fig. 50)

(3) When reassembling the stabilizer arms and bar, the large spacer is always placed on top of the stabilizer arm on caster mounted units (Fig. 51), and between the arm and the bar on 2-wheel drive units. The smaller spacers are placed either on top or bottom of stabilizer arm depending on manufacturing tolerances. Place these smaller spacers accordingly to obtain a space of approximately .500 to .750 inch from stabilizer bar to the floor, when the stabilizers are in the extended position. Stabilizer has to be mounted with largest part of bar in outside position.




Figure 49. Stabilizer Bar Clearance Setting.

Figure 50. Automatic Pot Hole Bar.

Figure 51. Caster Mounted Units.

5. TROUBLESHOOTING

BEFORE ANY ATTEMPT IS MADE TO SERVICE MACHINE WHEN EXTENDED OR PARTIALLY EXTENDED, IT IS ABSOLUTELY NECESSARY TO ENGAGE THE MAINTENANCE LOCKS. (Procedure Shown on Page 13.)

- 1. Remove load from platform.
- 2. Raise platform as high as necessary to engage MAINTENANCE LOCKS.
- MAINTENANCE LOCKS located at the front inside corners of the unit lower frame. Lift and slide back to engage.
- 4. Lower platform until lower beams make contact with the MAINTENANCE LOCKS.

DO NOT SERVICE EXTENDED OR PARTIALLY EXTENDED MACHINE UNTIL THE ABOVE PROCEDURE IS FOLLOWED.

PROBLEM	POSSIBLE CAUSES	REPAIR PROCEDURE
No LIFT motion	1. Blown fuse.	Check fuse and replace if necessary.
(pump not operating). (All Models)	2. Dead battery.	Check and charge battery as directed in MAINTENANCE section.
	Electrical circuit defective.	Refer to electrical schematic.
	4. Worn brushes.	1. Replace brushes and springs.
	5. Shorted armature	1. Replace motor.
	6. Defective motor contactor.	Replace contactor.
	7. Defective emergency stop switch or coil.	1. Replace switch or coil.
	8. Defective key switch.	1. Replace key switch.
	9. Defective UP switch.	1. Replace UP switch.
No FAST LIFT (TM II only)	Electrical circuit defective.	Refer to electrical schematic.
(one pump not operating)	2. Worn brushes.	1. Replace brushes and springs.
	Defective motor contactor.	1. Replace contactor.
	Defective secondary pump switch.	Replace secondary pump switch.

PROBLEM	POSSIBLE CAUSES	REPAIR PROCEDURE
No LIFT motion	Hydraulid fluid level low.	Add fluid (see MAINTENANCE section).
(pump operating) (All Models)	Pump cavitation caused by improper fluid for temperature conditions.	1. Drain reservoir and bleed system. Use only recommended type fluids (see MAINTENANCE section).
	3. Defective UP valve or coil.	Replace UP valve or coil.
	Electrical circuitry defective.	Refer to electrical schematic.
	Stabilizer safety switch defective.	1. Test and/or replace switch.
No FAST LIFT (pump operating) (TM II only)	Hydraulic fluid level low.	Add fluid (see MAINTENANCE section).
(TIVI II OIIIY)	Pump cavitation caused by improper fluid for temperature conditions.	1. Drain reservoir and and bleed system. Use only recommended type fluids (see MAINTENANCE section).
	Electrical circuitry defective.	Refer to electrical schematic.
	4. Loose intake hose or oil filter.	1. Tighten.
	5. Defective high speed valve or solenoid.	Replace high speed valve or solenoid.
Ascent speed slow or erratic.	1. Weak battery.	Charge battery (see MAINTENANCE section).
. Of errand.	Loose connections in electrical circuitry.	Perform visual inspection and ensure all connections are secure.
	Momentary short in wiring.	Refer to electrical schematic.
	4. Bent structural members.	Replace damaged members as necessary (see visual structural inspection in MAINTENANCE section).
	5. Restriction in hydraulic hose.	Replace defective hydraulic hose.
	6. Defective or jammed seals in hydraulic lift cylinder.	Replace hydraulic cylinder (see MAINTENANCE section)

PROBLEM		POSSIBLE CAUSES		REPAIR PROCEDURE
Ascent speed slow	7.	Gear or gear cavity worn or damaged.	1.	Replace pump. (See REPLACEMENT section.)
or erratic (continued)	8.	Worn brushes in motor.	1.	Replace brushes.
	9.	Defective valves.	1. 2.	and manifold.
	10.	Defective high speed valve or coil.	1.	Replace high speed valve or coil.
	11.	Loose intake hose or oil filter.	1.	Tighten connection or filter.
	12.	Defective down valve in manifold or in cylinder.	1.	Replace valve.
	13.	Defective emergency down valve.	1.	Replace valve.
Descent speed slow.	1.	Flow control out of adjustment.	1.	Adjust (see ADJUSTMENT section).
	2.	Friction in structural members.	2.	Lubricate and check for damaged members and cracked welds. (See MAINTENANCE.) Replace damaged structural members. This is to be done by factory authorized personnel only.
	3.	Obstruction in hydraulic hose.	1.	Replace defective hose.
	4.	Defective down valve.	1.	Replace valve.
Unit will not descend.	1.	Down signal not applied to down solenoid.	1. 2. 3.	Check fuse. Check battery charge. Check electrical circuitry. Refer to electrical schematic.
	2.	Defective down coil.	1	Replace coil.
	3.	Defective down valve.	1.	Replace valve.
Unit creeps down.	1.	Damaged seal in lift cylinder.	1.	Replace hydraulic cylinder (see MAINTENANCE section).
	2.	Defective down valve.	1.	Replace valve.
	3.	Defective emergency down valve.	1.	Replace valve.

NOTE: Torque Master models **must** have the front wheels off the ground in order to properly troubleshoot drive system for speed and power.

PROBLEM	POSSIBLE CAUSES	REPAIR PROCEDURE
Drive function	Defective forward/reverse switch.	Check continuity. Replace switch.
inoperative (hydraulic pump not	Defective electrical circuitry.	Refer to electrical schematic.
operating). Self-propelled units only!	Defective motor contactor.	1. Replace contactor.
Drive function.	Defective forward/reverse switch.	1. Replace switch.
inoperative in either direction.	Defective drive valve or coil.	 Replace drive valve or coil.
(hydraulic pump	Defective electrical circuitry.	Refer to electrical schematic.
operating). Self-propelled	4. Low battery.	1. Charge battery.
units only!	5. Defective hydraulic motor.	1. Replace drive motor.
	6. Defective brake.	Adjust brake. (See MAINTENANCE.)
No motion in one drive direction only.	Defective forward/reverse valve or solenoid in faulty mode.	Replace defective valve or solenoid.
Self-propelled units only!	Defective electrical circuit.	Refer to electrical schematic.
Torque Master drive function	Defective electrical circuitry.	Refer to electrical schematic.
inoperative (right wheel only).	Defective power valve (secondary manifold).	Replace power valve (V3).
	Defective drive valve or coil (secondary manifold).	Replace drive valve or coil.
Machine travels in fast speed when platform is above 5 ft.	Misadjusted or defective SLOW SPEED switch.	Adjust or replace switch.
	Defective electrical circuitry.	Refer to electrical schematic.
Self-propelled units only!	Defective slow speed valve or coil or slow speed switch.	Replace valve, coil or switch.

PROBLEM	POSSIBLE CAUSES	REPAIR PROCEDURE
Brake does	1. Defective brake valve.	Replace valve.
not release.	2. Brake pads misadjusted.	Adjust brake. (See ADJUSTMENTS section.)
Two wheel	3. Defective brake cylinder.	1. Replace cylinder.
drive units only!	Contamination lodged in brake orifice.	1. Remove contamination.
Brake does not set.	Misadjusted brake pads or spring.	Adjust brake. (See ADJUSTMENT section.)
Two wheel	2. Defective brake valve.	1. Replace.
drive units only!	Defective electrical circuitry.	Refer to electrical schematic.
Steering inoperative.	Defective electrical circuitry.	Refer to electrical schematic.
Self-propelled units only!	Defective steering valve or coil.	Replace steering valve or coil.
	3. Defective steering cylinder.	Replace steering cylinder.
	Defective crossover relief valve.	1. Replace valve.
	5. Contamination lodged in steering orifice.	1. Remove contamination.

ELECTRICAL WIRING DIAGRAMBATTERY MANUAL PLANT MASTER SERIES





Figure 52.

* NOTE: Switch wiring as seen from rear of switch.

Symbol	Description	Part No.
F1	Fuse 10 AMP	6190
S5	Switch, Up/Down	5230
S8	Key Switch	5936
S9	Contactor	5967
S10	Stabilizer Switch	6504
TS1	Terminal Strip	5991

ELECTRICAL WIRING DIAGRAM

PLANT MASTER (PM) ONE-WHEEL DRIVE SERIES



^{*} NOTE: Switch wiring as seen from rear of switch.

Up/Down Switch at Upper Control Box — Contacts Made With Toggle at Keyway Position 1-2, 4-5 — Center Position 1-2, 5-6 — Opposite Keyway 2-3, 5-6


Figure 53.

Symbol Identification for Figure 53.

Symbol	Description	Part No.
D1	Diode Assembly (3A.600PIV)	6070
F1	Fuse	6190
H1	Harness, Control Box	5982
H2	Harness, To Control Box	5983
H3	Harness, 15' Nos. 1,3,9,10,11	6072
H4	Harness, 15' Nos. 2,4,5,6,7,8	6073
H5	Harness, 19' Nos. 1,3,9,10,11	6075
H6	Harness, 19' Nos. 2,4,5,6,7	6076
H7	Harness, Manifold	6021
S1	Switch, Emergency Stop	
	Body	6665
	Retainer	6666
	Contactor	6667
S2	Switch, Slow/Fast	5630
S3	Switch, Up/Down	5979
S4	Switch, Steering, Fwd./Rev.	5694
S5	Switch, Lower Up/Down	5230
S7	Switch, Slow Sp. Limit	6016
S8	Switch, Key	5936
S9	Contactor Assy., Motor Start	5967
S10	Switch, Stabilizer	6504
TS1	Terminal Strip	5991
V1	Varistor Assembly	6231

ELECTRICAL WIRING DIAGRAM

PLANT MASTER (PM) (TWO-WHEEL DRIVE SERIES)
AISLE MASTER (AM)



^{*} NOTE: Switch wiring as seen from the rear of switch.

Up/Down Switch at Upper Control Box — Contacts Made With Toggle at Keyway Position 1-2, 4-5 — Center Position 1-2, 5-6 — Opposite Keyway 2-3, 5-6


Figure 54.

Symbol Identification for Figure 54.

Symbol	Description	Part No.
D1	Diode Assembly (3A.600PIV)	6070
F1	Fuse	6190
H1	Harness, Control Box	5982
H2	Harness, To Control Box	5983
Н3	Harness, 15' Nos. 1,3,9,10,11	6072
H4	Harness, 15' Nos. 2,4,5,6,7,8	6073
H5	Harness, 19' Nos. 1,3,9,10,11	6075
H6	Harness, 19' Nos. 2,4,5,6,7,8	6076
H7	Harness, Manifold	6021
S1	Switch, Emergency Stop	
	Body	6665
	Retainer	6666
	Contactor	6667
S2	Switch, Slow/Fast	5630
S3	Switch, Up/Down	5979
S4	Switch, Steering, Fwd./Rev.	5694
S7	Switch, Slow Sp. Limit	6016
S8	Switch, Key	5936
S9	Contactor Assy., Motor Start	5967
S10	Switch, Stabilizer	6504
TS1	Terminal Strip	5991
V1	Varistor Assembly	6231

ELECTRICAL WIRING DIAGRAM

TORQUE MASTER (TM) SERIES




^{*} NOTE: Switch wiring as seen from rear of switch.

Up/Down Switch at Upper Control Box — Contacts Made With Toggle at Keyway Position 1-2, 4-5 — Center Position 1-2, 5-6 — Opposite Keyway 2-3, 5-6

Figure 55.

ELECTRICAL WIRING DIAGRAM AISLE MASTER (AM) AND PLANT MASTER (PM) HI TORQUE SERIES



UP/DOWN SWITCH AT UPPER CONTROL BOX - CONTACTS MADE WITH TOGGLE AT KEYWAY POSITION 1-2, 4-5 — CENTER POSITION 1-2, 5-6 — OPPOSITE KEYWAY 2-3, 5-6 NOTE: F2 FUSE (2A) - EMERGENCY STOP, 1 USED: FORWARD, 2 USED: REVERSE, 2 USED.

Figure 56.

^{*} NOTE: Switch wiring as seen from rear of switch.

Symbol Identification for Figure 55 & 56.

Symbol	Description	Part No.
D1	Diode Assembly (3A.600PIV)	6070
D3	Diode Assembly(3A.600PIV)	6241
F1	Fuse	6190
H1	Harness, Control Box	5982
	Wire Set	6296
H2	Harness, To Control Box	5983
H5	Harness, 20 Nos. 1,3,9,10,11	6075
H6	Harness, 20 Nos. 2,4,5,6,7,8	6076
H7	Harness, Component Tray	6600
H9	Harness, 20 Nos. 12,13,14,15	6074
H10	Harness, 15 Nos. 1,3,9,10,11	6072
H11	Harness, 15 Nos. 2,4,5,6,7,8	6073
H12	Harness, 15 Nos. 12,13,14,15	6071
S1	Switch, Emergency Stop	
	Body	6665
	Retainer	6666
	Contactor	6667
S2	Switch, Slow/Fast	5630
S3	Switch, Up/Down	5979
S4	Switch, Steering, Fwd./Rev.	5694
S6	Switch, Power/Speed	6234
S7	Switch, Slow Sp. Limit	6016
S8	Switch, Key	5936
S9	Contactor Assy., Motor Start	5967
S10	Switch, Stabilizer	6504
TS1	Terminal Strip	5991
V1	Varistor Assembly	6231

HYDRAULIC SCHEMATIC BATTERY MANUAL — PLANT MASTER SERIES




Figure 57.

Symbol	Description	Part No.
C1	Lift Cylinder	4155
	Seal Kit W/Wire Lock	4088
	Wire, Lock	6313
CV1	Check Valve	5434
	"O" Ring Kit	5475
F1	Filter Element	6156
FC1	Flow Control	5963
	"O" Ring Kit	5475
H4	Hose	6001
H5	Hose	5999
M1	24 VDC Motor	6194
MA5	Manifold Pt.	2141
P1	Hydraulic Pump	6334
V1	2-Way NC Valve - Down	5964
	"O" Ring Kit	5475
	Valve Only	6973
	Coil Only, 24V	6163
V4	2-Way N.O.	5962
	"O" Ring Kit	5475
	Valve Only	6974
	Coil Only, 24V	6163
V5	Manual Pull-Emergency Down	5435
	"O" Ring Kit"	5475

NOTES




Figure 58. Manifold Assembly Battery Manual

HYDRAULIC SCHEMATIC PLANT MASTER (PM) SERIES 1-WHEEL DRIVE




Figure 59.

Symbol Identification for Figure 59.

Symbol	Description	Part No.
C1	Lift Cylinder Seal Kit W/Wire Lock Wire, Lock	4155 5838 6313
C4	Steering Cylinder Seal Kit	2512 5947
F1	Filter Element	6156
FC1	Flow Control "O" Ring Kit	5963 5475
H6	Hose	6003
H2	Hose	6002
H4	Hose	6001
H5	Hose	5999
M1	24VDC Motor	6194
M3	Drive Motor	5949
MA1	Primary Manifold Pt.	4166
O1	Orifice, Fitting Assembly	6107
P1	Hydraulic Pump	6334
PFC1	Priority Flow Control 1.0 GPM (STD.) Priority Flow Control .5 GPM (Special) "O" Ring Kit	5954 6189 5475
RV1	Relief Valve "O" Ring Kit	6316 5475
V1	2-Way N.C. Valve "O" Ring Kit Valve Only Coil Only - 24VDC	5964 5475 6973 6163
V2	4-Way 3-Position Valve Spring and "O" Ring Kit Valve Only Coil Only 24 VDC	5960 6161 5960X 6163
V3	3-Way 2-Position Valve "O" Ring Kit Valve Only Coil Only 24 VDC	5961 5476 6976 6163
V4	2-Way N.O. "O" Ring Kit Valve Only Coil Only - 24 VDC	5962 5475 6974 6163
V5	Manual Pull - Emergency Down "O" Ring Kit	5435 5475

NOTES

MANIFOLD ASSEMBLY PLANT MASTER 1-WHEEL DRIVE




Figure 60.

AISLE MASTER HYDRAULIC SCHEMATIC

(AM) AND PLANT MASTER (PM) SERIES 2-WHEEL DRIVE




Figure 61.

Symbol Identification for Figure 61.

Symbo	l Description	Part No
C1	Lift Cylinder Seal Kit	4155 4088
C2	Steering Cylinder Seal Kit	2838 5947
C3	Brake Cylinder Seal Kit	2483 5947
F1	Filter Element	6156
FC1	Flow Control "O" Ring Kit	5963 5475
H1	Hose	5997
НЗ	Hose	6351
H4	Hose	6001
H5	Hose	5999
Н8	Hose	5996
M1	24 VDC Motor	6194
M2	Drive Motor	6032
MA1	Primary Manifold	4166
MA6	Manifold Block	2972
01	Orifice, Fitting Assembly	6107
O2	Orifice, Fitting Assembly	4055
О3	Orifice, Fitting (Brass)	2974
P1	Hydraulic Pump	6334
PFC1	Priority Flow Control 1.0 GPM (STD.)	5954
	Priority Flow Control .5 GPM (Special) "O" Ring Kit	6189
RV1	Relief Valve "O" Ring Kit	6316 5475
V1	2-Way N.C. Valve	5964
	"O" Ring Kit Valve Only	5475
	Coil Only - 24 VDC	6973 6163
V2	4-Way 3-Position Valve	5960
	Spring and "O" Ring Kit	6161
	Valve Only	5960X
1/0	Coil Only 24 VDC	6163
V3	3-Way 2-Position Valve "O" Ring Kit	5961 5476
	Valve Only	6976
	Coil Only 24 VDC	6163
V4	2-Way N.O.	5962
	"O" Ring Kit Valve Only	5475
	Coil Only - 24 VDC	6974 6163
	Manual Pull - Emergency Down	5435
	"O" Ring Kit	5475
	2-Way N.O. (Spool Valve)	6554
	"O" Ring Kit Valve Only	5475
	vaive Univ	6975

NOTES

MANIFOLD ASSEMBLY AISLE MASTER AND PLANT MASTER 2-WHEEL DRIVE




Figure 62.

HYDRAULIC SCHEMATIC TORQUE MASTER (TM II) SERIES





Figure 63.

HYDRAULIC SCHEMATIC

HI TORQUE SERIES(AM)
(PM)




(SEE PAGES 61 AND 62 FOR PICTORAL VIEW)

Figure 64.

Symbol Identification for Figures 63 & 64.

Description	Part No.	Symbol	Description	Part No.
	4155	P1	Hydraulic Pump	6334
Seal Kit W/Wire Lock	4088	PFC1	Priority Flow Control 1.0 GPM (STD.)	5954
Steering Cylinder	2838		Priority Flow Control .5 GPM (Special)	6189
Seal Kit	5947		"O" Ring Kit	5475
Brake Cylinder	2483	RV1	Relief Valve	6316
Seal Kit	5947			5475
Check Valve	5434	V1	•	5964
"O" Ring Kit	5475		3	5475 6973
Flow Control	5963		· · · · · · · · · · · · · · · · · · ·	6163
"O" Ring Kit	5475		And the second s	5960
Hose	5997	٧Z	•	6161
Hose	6351		Valve Only	5960X
Hose	6001		Coil Only 24 VDC	6163
Hose	5999	V3	•	
Hose	6237		•	5476 6976
Hose	6238		Coil Only - 24 VDC	6163
24 VDC Motor	6194	V4	2-Way N.O.	5962
Drive Motor (Hydraulic)	6210		"O" Ring Kit	5475
Primary Manifold	4166		•	6974 6163
High Speed Manifold Pt.	2281	\/E		5435
Secondary Manifold Pt.	4167	V3	"O" Ring Kit	5475
Manifold Block	2972	V6	2-Way N.O. (Spool Valve)	6554
Orifice, Fitting Assembly	6107		"O" Ring Kit	5475
Orifice, Fitting Assembly	4055		•	6975 6163
Orifice, Fitting (Brass)	2975	***************************************	Con Only 24 VDO	
	Lift Cylinder Seal Kit W/Wire Lock Steering Cylinder Seal Kit Brake Cylinder Seal Kit Check Valve "O" Ring Kit Flow Control "O" Ring Kit Hose Hose Hose Hose Hose Hose Hose Seal Kit Flow Control "O" Ring Kit Flow Control "O" Ring Kit Hose Hose Hose Company Hose Hose Hose Company Hose Company Co	Lift Cylinder Seal Kit W/Wire Lock Steering Cylinder Seal Kit Sea	Lift Cylinder 4155 P1 Seal Kit W/Wire Lock 4088 PFC1 Steering Cylinder 2838 Seal Kit Seal Kit 5947 RV1 Brake Cylinder 2483 RV1 Seal Kit 5947 V1 Check Valve 5434 V1 "O" Ring Kit 5475 V2 Flow Control 5963 V2 "O" Ring Kit 5475 V2 Hose 6351 V2 Hose 6001 V3 Hose 6237 V3 Hose 6238 V4 24 VDC Motor 6194 V4 Drive Motor (Hydraulic) 6210 V5 Primary Manifold 4166 V5 High Speed Manifold Pt. 2281 V5 Secondary Manifold Pt. 4167 V6 Orifice, Fitting Assembly 6107 Orifice, Fitting Assembly 4055	Lift Cylinder 4155 P1 Hydraulic Pump Seal Kit W/Wire Lock 4088 PFC1 Priority Flow Control 1.0 GPM (STD.) Steering Cylinder 2838 PFC1 Priority Flow Control 5 GPM (Special) Seal Kit 5947 "O" Ring Kit Brake Cylinder 2483 RV1 Relief Valve Seal Kit 5947 "O" Ring Kit Check Valve 5434 V1 2-Way N.C. Valve "O" Ring Kit 5475 "O" Ring Kit Hose 5997 V2 4-Way 3-Position Valve Foring Amily Coil Only 24 VDC Valve Only Valve Only Hose 6351 V3 3-Way 2-Position Valve Hose 6237 V3 3-Way 2-Position Valve "O" Ring Kit Valve Only Valve Only Hose 6238 Coil Only 24 VDC 24 VDC Motor 6194 V4 2-Way N.O. Primary Manifold 4166 "O" Ring Kit Primary Manifold Pt. 2281 V5 Manual Pull - Emergency Down <tr< td=""></tr<>

SECONDARY MANIFOLD ASSEMBLY TORQUE MASTER



HIGH SPEED MANIFOLD ASSEMBLY TORQUE MASTER




Figure 66.

PRIMARY MANIFOLD ASSEMBLY TORQUE MASTER




Figure 67.

6. PARTS CATALOG

IMPORTANT REPLACEMENT PART NOTES

1. CAPSCREWS

ANY BOLT REPLACEMENT SHOULD BE OF THE SAME GRADE OR GREATER THAN ORIGINAL BOLT. ANY QUESTIONS, CALL FACTORY FOR VERIFICATION.

Grade markings for cap screws grades 2, 5, and 8 are based on SAE J429. Markings may be raised or depressed (manufacturer's option).



2. BATTERY

Replacement battery MUST WEIGH AT LEAST 66 POUNDS, to maintain the stability factor of the machine.

3. TIRES

Tires on Torque Master machines must be replaced with manufacturer's replacement tires to maintain stability factor of the machine.

4. DECALS AND LABELS

All decals and labels are furnished at no charge. Refer to the following part numbers when requesting decals. See next page for proper location or specific safety decals.


Part No.	Description		
2422 2423 2422 2423 2423 2423 2410 2411 2501 2502 2501	115SPEP 119SPEP 215SPEP 219SPEP 216AM 220AM 015BMEP 019BMEP 220TM II 215TM II	Decal Kit	Side Railing Decals 6692 Front 6693 Rear
2501 2501 2502	219AMHT 219SPHT 215SPHT	Decal Kit Decal Kit Decal Kit	

NOTE: Side railing decals are not included in kit.

NOTES

IMPORTANT

When servicing machine check to see if decals shown in diagram below are in place and legible. If not, they must be added or replaced.



NOTE: Make sure capacity decals match capacity of machine.

^{*}Decal placed upside down so that when extending platform is not extended, decals will read correctly to operator.





Figure 68. Models 019BMEP (shown), and 015BMEP

Item	015 BMEP Part No.	019 BMEP Part No.	Description
1	1827		
2	1823	1827 1823	Front Rail Assy.
3	2137	2138	Side Rail (R.H.) (Ext. Plt.)
4	2854	2854	Control Box Assy. w/Harness
,	6417	6417	Latch Plate Kit
5	1558	1558	Torsion Spring
	1906	1906	110 A.C. Kit Hanger Clip
6	4142	4142	Side Rail Weld, L.H.
6	4143	4143	Side Rail Weld, R.H.
7	4069	4069	Guard Rail Tube
8	4038	4038	Guard Sliding Tube
9	4191	4191	Parts Package
10	1377	1377	Connecting Pin
	5937	5937	Retaining Ring
11	**************************************	1879P	Beam Assy.
12	1883 (R.H.)	1879P	Beam Assy.
	1884 (L.H.)	1879P	Beam Assy.
13	1946	1946	Pivot Bar
	5419	5419	Retaining Ring
14	1879P	1867P	Lower Beam Assy, Painted
15	1881	1877	Inner Beam Assy.
16	2989	2989	Battery Cover Assy.
	2983	2983	Hold Down, Battery
17	5970	5970	
.,	3070	3970	Battery (replacement battery must weigh at least 66 lbs.
	2025	2025	due to stability factor of machine)
	6208	6208	Battery Tray
	6014		Battery Jumper
18	1870	6014	Connector & Cable Assy, Battery
19	1038	1870	Beam & Support Arm Assy.
19	1039	1038	Connecting Pin
20		1039	Retaining Ring
20 21	(Fig. 75) 1983	(Fig. 75)	Lower Control Box Assy. (Figure 75)
21	5919	1983	Spacer
22	2177	5919	Retaining Ring
22	5930	2177	Stabilizer, Rear
23	2006	5930	Bearing, Nyliner, Flanged
24	1978	2006	Support Bar Weldment
24	1976	1978	Stabilizer Mtg. Bearing Block
25	1995	1988	Bearing, Nylon
25	1995	1995	Stabilizer Mtg. Bearing Block, L.H.
	1988	1994	Stabilizer Mtg. Bearing Block, R.H.
26	2121	1988	Bearing, Nylon
		2121	Components Tray Assy. (Figure 77)
27	2088	2088	Stabilizer, Front
00	5930	5930	Bearing, Nyliner, Flanged
28	2111	2111	Spring Anchor Weldment
00	1966	1966	Closing Pin
29	5951	5951	Return Spring
30	5941	5941	Spring, Cam Lock
31	1036	1036	Roller Bar
	1033	1033	Roller
	5868	5868	Bearing, Nylon
	1993	1993	Maintenance Lock Weld
	4187	4187	Cam Weldment, L.H.
	4188	4188	Cam Weldment, R.H.
	5912	5912	Bearing
	5901	5901	Cam Thrust Washer
00	5918	5918	Retaining Ring
32	5520	5520	Caster, Swivel Lock, W/Brake
33	2051	2051	Base Assy.
34	2172	2172	Emergency Down Assy.
	2430	2430	Cam Roller Assembly
	5913 5928	5913	Bearing
35	2058	5928	Retaining Ring
36		2058	Lower Outer Beam Assy.
	4155	4155	Cylinder 5 x 12 (Figure 76)
37 38	2856 4042	2856	Guard Spring
32	5432	4042	Lift Arm Assy.
of for	5432 5823	5432 5823	Grease Fitting
	3020	5823	Bearing

	015 BMEP	019 BMEP		
Item	Part No.	Part No.	Description	
39	1033	1033	Roller	
00	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
40	1882	1880	Upper Inner Beam Assy.	
41	1881	1881	Inner Beam Assy.	
42	2055	2055	Platform Weldment	
	6329	6329	Floor Board	
	5213	5213	Screw, Floor Board	
43	1893	1893	Cover, Terminal Board	
.0	6350	6350	Foam Tape	
	5991	5991	Terminal Board	
44	1833	1833	Pivot Pin	
• /	5719	5719	Pin, Expansion	
45	5721	5721	Capscrew, 3/4-10 x 2.00 Lg.	
10	5022	5022	Hex Nut, 3/4-10	
46	1782	1782	Extending Platform Weldment	
10	5716	5716	Floor Board	
	5213	5213	Screw, Floor Board	
	6668	6668	Manual Box	
47	1824	1824	Side Rail (L.H.) (Ext. Plt.)	
48	2238	2238	Roller Bar	
	1033	1033	Roller	
	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
49	6305	6305	Safety Strip	

NOTES



Item	115 SPEP Part No.	119 SPEP Part No.	Description
1	1827	1827	Front Rail Assy.
2	1823	1823	Side Rail (R.H.) (Ext. Plt.)
3	2107	2107	Upper Control Box
4	1558	1558	110 A.C. Kit
	1906	1906	Hanger Clip
5	4142	4142	Side Rail Weld, L.H.
6	4143	4143	Side Rail Weld, R.H.
7	4069	4069	·
8	4038		Guard Rail Tube
0		4038	Guard Sliding Tube
0	4191	4191	Parts Package
9	1377	1377	Connecting Pin
4.0	5937	5937	Retaining Ring
10	1883 (R.H.)	1879P	Beam Assy.
	1884 (L.H.)	1879P	Beam Assy.
11	-	1879P	Beam Assy.
12	1946	1946	Pivot Bar
	5419	5419	Retaining Ring
13	1879P	1867P	Beam Assy.
14	1881	1877	Inner Beam Assy.
15	2989	2989	Battery Cover Assy.
	2983	2983	•
16	5970		Hold Down, Battery
10	3970	5970	Battery (replacement battery must weigh at least 66 lbs.
	0005	2005	due to stability factor of machine)
	2025	2025	Battery Tray
	6208	6208	Battery Jumper
	6014	6014	Connector & Cable Assy., Battery
7	1870	1870	Beam & Support Arm Assy.
8	1038	1038	Connecting Pin
	1039	1039	Retaining Ring
9	(Fig. 75)	(Fig. 75)	Lower Control Box Assy.
20	5087	5087	Caster, Rigid, W/Brake
.o !1	1983	1983	
. 1	5919	5919	Spacer
0			Retaining Ring
.2	2177	2177	Stabilizer, Rear
_	5930	5930	Bearing, Nyliner, Flanged
!3	2006	2006	Support Bar Weldment
!4	1978	1978	Stabilizer Mtg. Bearing Block
	1988	1988	Bearing
25	1995	1995	Stabilizer Mtg. Bearing Block, L.H.
	1994	1994	Stabilizer Mtg. Bearing Block, R.H.
	1988	1988	Bearing
6	2122	2122	Component Tray Assy. (Figure 68)
7	2051	2051	Base Assy.
8	2088	2088	
U	5930		Stabilizer, Front
0		5930	Bearing, Nyliner, Flanged
9	2111	2111	Spring Anchor Weld
•	1966	1966	Closing Pin
0	5951	5951	Return Spring
1	5941	5941	Spring, Cam Lock
2	5245	5245	Swivel Caster
3	1036	1036	Roller Bar
	1033	1033	Roller
	5868	5868	Bearing, Nylon
	2210	2210	Stop Bracket
	1993	1993	•
	4187	4187	Maintenance Lock Weld
	4188		Cam Weldment, L.H.
		4188	Cam Weldment, R.H.
	5912	5912	Bearing
	5901	5901	Cam Thrust Washer
	5918	5918	Retaining Ring
ļ	2131	2131	Front Drive Assy. (Figure 81)
5	2172	2172	Emergency Down Assy. (Not Shown)
3	2058	2058	Lower Outer Beam Assy.
	2430	2430	Cam Roller Assembly
	5913	5913	Bearing
	5928	5928	
,	4155	4155	Retaining Ring
	2856		Cylinder 5 x 12 (Figure 76)
3	2856 6072	2856	Guard Spring
	6072	607E	Have
	6073	6075 6076	Harness

	115 SPEP	119 SPEP		
Item	Part No.	Part No.	Description	
39	4042	4042	Lift Arm Assy	
55	5432	5432	Grease Fitting	
	5823	5823	Bearing	
40	1033	1033	Roller	
40	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
41	1882	1880	Upper Inner Beam Assy.	
42		1881	Inner Beam Assy.	
43	2238	2238	Roller Bar	
40	1033	1033	Roller	
	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
44	2055	2055	Platform Weld	
7-7	6329	6329	Floor Board	
	5213	5213	Screws, Floor Board	
45	1893	1893	Cover, Terminal Board	
40	6350	6350	Foam Tape	
	5991	5991	Terminal Board	
46	5983	5983	Harness Assy.	
47	1833	1833	Pivot Pin	
71	5719	5719	Pin, Expansion	
48	5721	5721	Cap Screw, 3/4-10 x 2.00 Lg.	
40	5022	5022	Hex Nut, 3/4-10	
49	1782	1782	Extending Platform Weldment	
43	5716	5716	Floor Board, Extending Platform	
	5213	5213	Screw, Floor Board	
	6668	6668	Manual Box	
50	1824	1824	Side Rail (L.H.) (Ext. Plt.)	
51	6417	6417	Torsion Spring	
52	6305	6305	Safety Strip	
53	2082	2082	Cover	
54	2854	2854	Latch Plate Kit	

NOTES




Figure 70. Models 219SPEP (Shown), 215SPEP

Hous	215 SPEP	219 SPEP	
Item	Part No.	Part No.	Description
1	1827	1827	Front Rail Assembly
2	1823	1823	Side Rail (R.H.) (Ext. Plt.)
3	2106	2106	Upper Control Box
4	2854	2854	Latch Plate Kit
_	6417	6417	Torsion Spring
5	1558	1558	110 A.C. Kit
0	1906	1906	Hanger Clip
6	4142	4142	Side Rail Weld, L.H.
7	4143	4143	Side Rail Weld, R.H.
8	4069	4069	Guard Rail Tube
9	4038	4038	Guard Sliding Tube
40	4191	4191	Parts Package
10	1377	1377	Connecting Pin
	5937	5937	Retaining Ring
11	4000/5	1879P	Beam Assy.
12	1883(R.H.)	1879P	Beam Assy.
40	1884(L.H.)	1879P	Beam Assy.
13	1946	1946	Pivot Bar
	5419	5419	Retaining Ring
14	1879P	1867P	Beam Assy.
15	1881	1877	Inner Beam Assy.
16	2989	2989	Battery Cover Assy.
	2983	2983	Hold Down, Battery
17	5970	5970	Battery (Replacement battery must weigh at least 66 lbs.
			due to stability factor of machine.)
	2025	2025	Battery Tray
	6208	6208	Battery Jumper
	6014	6014	Connector & Cable Assy, Battery
18	1870	1870	Beam & Support Arm Assy.
19	(Fig. 75)	(Fig. 75)	Lower Control Box Assy.
20	(Fig. 88)	(Fig. 88)	Rear Axle Assy.
21	4046	4046	Rear Wheel
22	2177	2177	Stabilizer, Rear
	5930	5930	Bearing, Nylon
23	1983	1983	Spacer
24	2006	2006	Support Bar Weldment
25	1978	1978	Stabilizer Mtg. Bearing Block
	1988	1988	Bearing, Nylon
26	1995	1995	Stabilizer Mtg. Bearing Block, L.H.
	1994	1994	Stabilizer Mtg. Bearing Block, R.H.
	1988	1988	Bearing, Nylon
27	1038	1038	Connecting Pin
	1039	1039	Retaining Ring
28	2123	2123	Components Tray Assy. (Figure 77)
29	2051	2051	Base Assembly
30	2088	2088	Stabilizer, Front
	5930	5930	Bearing, Nylon
31	2111	2111	Spring Anchor Weld
	1966	1966	Closing Pin
32	5951	5951	Return Spring
33	5941	5941	Spring, Cam Lock
34	2838	2838	Steering Cylinder
	2302	2302	Steering Cylinder Mount
35	1036	1036	Roller Bar
	1033	1033	Roller
	5868	5868	Bearing, Nylon
	2210	2210	Stop Bracket
	1993	1993	Maintenance Lock Weld
	4187	4187	Cam Weldment, L.H.
	4188	4188	Cam Weldment, R.H.
	5912	5912	Bearing
	5901	5901	Cam Thrust Washer
	5918	5918	Retaining Ring
36	5918 (Fig. 70)	5918 (Fig. 70)	Retaining Ring Front Drive Assy.

	215 SPEP	219 SPEP		
Item	Part No.	Part No.	Description	
38	2058	2058	Lower Outer Beam Assy.	
00	2430	2430	Cam Roller Assembly	
	5928	5928	Retaining Ring	
39	4155	4155	Cylinder 5 x 12	
40	2856	2856	Guard Spring	
70	6072	6075	Harness	
	6073	6076	Harness	
41	4042	4042	Lift Arm Assy.	
71	5432	5432	Grease Fitting	
	5823	5823	Bearing	
42	1033	1033	Roller	
42	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
43	1882	1880	Upper Inner Beam Assy.	
44	1062	1062	Roller Bar	
44	1033	1033	Roller	
	5868	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
45	1893	1893	Cover, Terminal Board	
40	6350	6350	Foam Tape	
	5991	5991	Terminal Board	
46	2055	2055	Platform Weld	
40	6329	6329	Floor Board	
	5213	5213	Screw, Floor Board	
47	02.0	1881	Inner Beam Assy.	
48	5983	5983	Harness Assy.	
49	5721	5721	Capscrew, 3/4-10 x 2.00 Lg.	
40	5022	5022	3/4-10 Hex Nut	
50	1782	1782	Extending Platform, Weldment	
50	5716	5716	Floorboard, Extending Platform	
	5213	5213	Screw, Floor Board	
	6668	6668	Manual Box	
51	1833	1833	Pivot Pin	
51	5719	5719	Pin, Expansion	
52	1824	1824	Side Rail (L.H.) (Ext. Plt.)	
Ų	2066	2066	Rear Axle Weldment (Fig. 88)	
	6305	6305	Safety Strip	

NOTES




Figure 71. Models 216 AM (Not Shown) and 220 AM (Shown).




Figure 72. Model 220AMHT (Shown)

ltem	216 AM Part No.	220 AM	
1	1827	Part No.	Description
2	1823	1827	Front Rail Assembly
3	2107	1823	Side Reil (D.L.) (F
	2731	2107	Side Rail (R.H.) (Ext. Plt.) Upper Control Box
4	2854	2731	Upper Control Box
	6417	2854	Upper Control Box (HT Series) Latch Plate Kit
5	1558	6417	Torsion 0
	1906	1558	Torsion Spring
6	4142	1906	110 A.C. Kit Hanger Clip
7	4143	4142	Sido Dallara
8	4069	4143	Side Rail Weld, L.H.
9	4038	4069	Side Rail Weld, R.H. Guard Rail Tube
	4191	4038	Guard Clid:
0	1377	4191	Guard Sliding Tube
	5937	1377	Parts Package
1	-50,	5937	Connecting Pin
2	1883(R.H.)	1879P	Retaining Ring Beam Assy.
	1884(L.H.)	1879P	Beam Assy.
3	1946	1879P	Beam Assy.
	5419	1946	Pivot Bar
	1879P	5419	Potoinia - Di
	1881	1867P	Retaining Ring
	2989	1877	Beam Assy.
	2983	2989	Inner Beam Assy.
	5970	2983	Battery Cover Assy.
	33,0	5970	Hold Down, Battery
	2025		Battery (Replacement battery must weigh at least 66 lbs.
	6208	2025	due to stability factor of machine.)
	6014	6208	attory ridy
	1870	6014	Battery Jumper
	(Fig. 75)	1870	Connector & Cable Assy, Battery
	(Fig. 87)	(Fig. 75)	Court & Support Arm Accu
	(· ·g. 0/)	(Fig. 87)	Lower Control Box Assy. Rear Axle Assy.

	216 AM	220 AM Part No.	Description	
Item	Part No.	4071	Rear Wheel	
21	4071	6305	Safety Strip	
22	6305	4162	Pivot Arm Weldment Front R.H.	
23	4162	4164	Pivot Arm Weldment Front L.H.	
	4164	6620	Bearings, Pivot Arm (Not Shown)	
	6620	4035	Spring Pivot Arm Retractor	
24	4035	5941	Spring Cam Lock	
25	5941	5766	Retaining Ring, Pivot Arm	
26	5766		Connecting Pin	
27	1038	1038	Retaining Ring	
2.	1039	1039	Components Tray Assy. (Figure 77)	
28	2123	2123	Base Assembly	
29	2051	2051	Retaining Ring, Pot Hole Bar	
30	5919	5919	Bearing-Nyliner, Pot Hole Bar	
31	5930	5930	Pot Hole Bar	
	4023	4023	Pivot Arm Mounting Weld. Front	
32	4016	4016	Plyot Affil Woulding Work	
33	2838	2838	Steering Cylinder Steering Cylinder Mount	
34	2302	2302	Steering Cylinder Would	
0.5	1036	1036	Roller Bar	
35	1033	1033	Roller	
	5868	5868	Bearing, Nylon	
	2210	2210	Stop Bracket	
	1993	1993	Maintenance Lock Weld	
	4187	4187	Cam Weldment, L.H.	
		4188	Cam Weldment, R.H.	
	4188	5912	Bearing	
	5912	5901	Cam Thrust Washer	
	5901	5918	Retaining Ring	
	5918	(Fig. 84)	Front Drive Assy	
36	(Fig. 84)	2172	Emergency Down Assy.	
37	2172	2058	Lower Outer Beam Assy.	
38	2058	2430	Cam Roller Assembly	
	2430	5913	Bearing	
	5913	5928	Retaining Ring	
	5928	4155	Cylinder 5 x 12	
39	4155	2856	Guard Spring	
40	2856	6075	Harness	
	6072	6076	Harness	
	6073	4042	Lift Arm Assy.	
41	4042	5432	Grease Fitting	
	5432	5868	Bearing, Nylon	
	5868		Roller	
42	1033	1033	Bearing, Nylon	
72	5868	5868	Retaining Ring	
	1039	1039	Upper Inner Beam Assy.	
43	1882	1880	Roller Bar	
44	1062	1062	Roller	
4-7	1033	1033	Bearing , Nylon	
	5868	5868	Retaining Ring	
	1039	1039	Cover, Terminal Board	
A.E.	1893	1893	Foam Tape	
45	6350	6350	Terminal Board	
	5991	5991	Platform Weld	
40	2055	2055		
46	6329	6329	Floor Board	
	5213	5213	Screw, Floor Board	
	6668	6668	Manual Box	
	6000	1881	Inner Beam Assy.	
47	5983	5983	Harness Assy.	
48	5963 5721	5721	Capscrew, 3/4-10 x 2.00 Lg.	
49		5022	3/4-10 Hex Nut	
	5022	1782	Extending Platform, Weldment	
50	1782	5716	Floorboard, Extending Platform	
	5716	5213	Screw, Floor Board	
	5213	1833	Pivot Pin	
51	1833	5719	Pin, Expansion	
	5719	1824	Side Rail (L.H.) (Ext. Plt.)	
	1824	1044		

Item	216 AM Part No.	220 AM Part No.	Description
53	4163	4163	Pivot Arm Weldment Rear R.H.
	4164	4164	Pivot Arm Weldment Rear L.H.
54	4017	4017	Pivot Arm Mounting Weld. Rear R.H.
	4018	4018	Pivot Arm Mounting Weld. Rear L.H.
55	4006	4006	Rear Axle Weldment (Fig. 88)
56	6617	6617	Rod End
	(Fig. 86)	(Fig. 86)	Activating Arm Assy.




Figure 73. 220TM II Model (215TM II Model Not Shown)

Item	215TM II Part No.	220 TM II Part No.	Description
1	2462	2462	Front Rail Assy.
2	1823	1823	Side Rail (R.H.) (Ext. Plt.)
3	2992	2992	Upper Control Box
4	2854	2854	Latch Plate Kit
	6417	6417	Torsion Spring
5	1558	1558	110 A.C. Kit
•	1906	1906	Hanger Clip
6	1824	1824	Side Rail Weld, L.H. (Ext. Plt.)
7	2872	2872	
8	4068	4068	Side Rail Weld, R.H. Guard Rail Tube
9	4038	4038	Guard Sliding Tube
10	4191	4191	Parts Package
U	2761	2761	Connecting Pin
	2773	2773	Spacer
	1039	1039	Retaining Ring
1	2439	2439	Platform Weld
	6325	6325	Floor Board
2		1879P	Beam Assy.
3	1884 (L.H.), 1883 (R.H.)	1879P	Beam Assy.
4	1946	1946	Pivot Bar
	5419	5419	Retaining Ring
5	1879P	1867P	Beam Assy.
6	1881	1877	Inner Beam Assy.
7	2989	2989	Battery Cover Assy.
	2983	2983	Hold Down, Battery
8	5970	5970	
0	3370	3970	Battery (Replacement battery must weigh at least 66 lbs.
	0005	0005	due to stability factor of machine.)
	2025	2025	Battery Tray
	6208	6208	Battery Jumper
_	6205	6205	Connector & Cable Assy, Battery
9	1870	1870	Beam & Support Arm Assy.
0	(Fig. 75)	(Fig. 75)	Lower Control Box Assy. (Figure 69)
1	(Fig. 86)	(Fig. 86)	Rear Axle Assy.
2	4045	4045	Rear Wheel
3	2177	2177	Stabilizer, Rear
4	2115	2115	Spacer
	5919	5919	Retaining Ring
5	2372	2372	Support Bar Weldment
6	1978	1978	
	1988	1988	Stabilizer Mtg. Bushing
7	1995	1995	Bearing
'			Stabilizer Mtg. Block, L.H.
	1994	1994	Stabilizer Mtg. Block, R.H.
,	1988	1988	Bearing
3	1038	1038	Connecting Pin
	1039	1039	Retaining Pin
3	2306	2306	Components Tray Assy. (Figure 77)
)	2051	2051	Base Assy.
	2088	2088	Stabilizer, Front
	5930	5930	Bearing, Nylinder Flanged
2	2111	2111	Spring Anchor Weld
	5910	5910	Rod End
	1966	1966	Closing Pin
3	5951	5951	Return Spring
	(Fig. 86)	(Fig. 86)	Activating Arm Assy.
1	5941	(1 ig. 30) 5941	Spring, Cam Lock
5	2838	2838	Steering Cylinder
	2302	2838	- ·
	1036	2302 1036	Steering Cylinder Mount
	1033		Roller Bar
		1033	Roller
	5868	5868	Bearing, Nylon
	2210	2210	Stop Bracket
	1993	1993	Maintenance Lock Weld
	4187	4187	Cam Weldment, L.H.
	4188	4188	Cam Weldment, R.H.
	5912	5912	Bearing
	5901	5901	Cam Thrust Washer
	5918	5918	
	3910		Retaining Ring

	215TM II	220 TM		
Item	Part No.	Part No.	Description	
38	2172	2172	Emergency Down Assy.	
39	2058	2058	Lower Outer Beam Assy.	
	2430	2430	Cam Roller Assembly	
	5913	5913	Bearing	
	5928	5928	Retaining Ring	
40	4155	4155	Cylinder 5 x 12 (Figure 76)	
41	2856	2856	Guard Spring	
	6071	6074	Harness	
	6072	6075	Harness	
	6073	6076	Harness	
42	4042	4042	Lift Arm Assy.	
	5432	5432	Grease Fitting	
	5823	5823	Bearing	
43	1033	1033	Roller	
	5863	5868	Bearing, Nylon	
	1039	1039	Retaining Ring	
44	1882	1880	Upper Inner Beam Assy.	
45		1881	Inner Beam Assy.	
46	2468	2468	Pivot Pin	
	5719	5719	Pin, Expansion	
47	5721	5721	Cap Screw, 3/4-10	
	5022	5022	Hex Nut, 3/4-10	
48	2457	2457	Extending Platform Weldment	
	6324	6324	Floor Board, Extending Platform	
	5213	5213	Screw, Floor Board	
	6668	6668	Manual Box	
49	2871	2871	Side Rail Weld, L.H.	
50	5983	5983	Harness Assy.	
51	1893	1893	Cover, Terminal Board	
•	6030	6030	Foam Tape	
	5991	5991	Terminal Board	
52	2762	2762	Roller Bar	
	2774	2774	Spacer	
	1033	1033	Roller	
	5868	5868	Bearing, Nylon	
53	6305	6305	Safety Strip	




Figure 74. Upper Control Box Assembly (HT Shown)

Item	PM 1 Wheel Drive Part No.	PM & AM 2 Wheel Drive Part No.	AM & PM HT Series	TM II 2 Wheel Drive Part No.	Description
	2107	2107	2731	2992	Complete Control Box
1	2089	2089	2089	2318	Wrapper Weldment
2	2095	2095	2095	2095	Front and Bottom Panel
3	2094	2094	2991	2991	Cover
	5978	5978	5978	5978	Screw
4	1313	1313	1313	1313	Switch Guard
5	6572	6572	6572	6575	Decal Control, Box Side
6	6580	6580	6580	6580	Decal Control, Box Front
7	5692	5692	5692	5692	Boot, Toggle
8	6573	6573	6574	6574	Decal
9	6665	6665	6665	6665	Emergency Stop Switch, Body
	6666	6666	6666	6666	Emergency Stop Switch, Retainer
	6667	6667	6667	6667	Emergency Stop Switch, Contactor
11	5694	5694	5694	5694	Switch
12	5979	5979	5979	5979	Switch
13	5982	5982	5982	5982	Harness Set (TM II Also Requires Pt. 6296)
14	5630	5630	5630	5630	Switch
15				6234	Switch
16			5230	5230	Switch
17				6296	Harness Set (Not Shown)
	6318	6318	6318	6318	Connector Repair Kit 12 Pins
					12 Sockets 1 Retractor
	6057	6057	6057	6057	Decal (Obstruction)




Figure 75. Lower Control Box Assembly

Item	Battery Man. PM Part No.	1 Whl. Drive PM Part No.	2 Whl. Drive PM & AM Part No.	2 Whl. Drive TM II Part No.	Description
2	2096	2096	2096	2096	Lower Control Box
3		6070	6070	6070	Diode
4		6070	6070	6070	Diode
5	5991	5991	5991	5991	Terminal Board
6	5265	5265	5265	5265	Fuse Holder
	6190	6190	6190	6190	Fuse
7	5936	5936	5936	5936	Key Switch
8	5230	5230	5230	5230	Switch
9	6576	6576	6576	6576	Decal, Lower Control Station (Not Shown)
10	6285	6286	6286	6286	Harness Assy.
11		6016	6016	6016	Slow Speed SW
	6581	6581	6581	6581	Decal, Fork Lift Pockets (Not Shown)




Figure 76. Lift Cylinder Assembly

Item	Part No.	Description
1	4155	Cylinder 5 x 12
	4088	Seal Kit W/Wire Lock (Not Shown)
2	6021	Harness (One & Two Wheel Drive)
	6022	Harness (Battery Manual Models)
3	1945	Cylinder Pin - Lower
4	5964	Valve, 2 Way, N.C., 24V DC - Battery Models
	5475	"O" Ring Kit
	6973	Valve Only
	6163	Coil Only - Battery Models
5	543 5	Valve Manual Pull
	5475	"O" Ring Kit
6	6125	Fitting, Bayonet
7	2153	Return Line
8	1944	Cylinder Pin - Upper
9	1908	Plug
10	5766	Retaining Ring
11	5874	Bearing
12	6001	Hyd. Hose, Lift
13	5765	Cotter Pin
14	2389	Washer




Figure 77. Component Tray Assembly (TM II & HT Shown)

Item	Batt. Manual PM Part No.	1 Whl. Drive PM Part No.	2 Whl. Drive PM & AM* Part No.	2 Whl. Drive TM II Part No.	Description
1	5955	5955	5955	5955	Battery Charger (See Fig. 78)
2	2102	2102	2102	2102	Component Tray Weld.
5	5938	5938	5938	5938	Gauge, Sight
6				5995	Hyd. Hose
7	6510	6510	6510	5493	Fitting
8	5969	5969	5969	5969	Filter Head
9	6156	6156	6156	6156	Filter Cartridge
10	6225	6225	6225	6225	Hyd. Hose
11	6194	6194	6194	6194	Motor (With Fan)
	4041	4041	4041	4041	Brush Set
	6371	6371	6371	6371	
12	6231	6231	6231	6231	Armature
13	5967	5967	5967	5967	Varistor Assy.
14	5 98 5	5985	5985	6206	Contactor 24VDC
15	6022	6021	6021	6021	Connector/Cable Assy.
16	5999	5999	5999	5999	Wire Harness
17	6334	6334	6334	6334	Hose
	*	*	*	*	Pump
18	See Fig. 58	See Fig. 60	See Fig. 62	See Fig. 67	Coupler
19		3	000 / .g. 02		Manifold Assy.
20					Manifold Assy.
21					Wire Harness - Secondary Manifold
	5052	5052	5052		Return Block
22	2392	2392	2392		Bayonet Fitting
	2185	2185	2185		Breather Cap
	2186	2186	2186	2185	Cover, LH (Not Shown)
	6127	6127	6127	2186	Cover, RH (Not Shown)
23		0127	0127	6127	Wing Nut (Not Shown)
	6607	6607	6607		T' Fitting
***************************************		0007	0007	6607	Drain Plug (Not Shown)

^{*} Fenner Stone - 6012 Coupler and 6013 Spring J.S. Barnes - 6314 Coupler Webster - 6353 Coupler

^{*}Hi-Torque models same as TM II less Item 19 (Manifold Assy.)




Figure 78. Battery Charger - MAC

Item	Part No.	Description
1	6157	Transformer
2	6158	Condenser
3	5553	Rectifier Assy.
4	6522	Circuit Breaker
5	5554	Ammeter
6	5643	Timer Dial Plate
7	5642	Timer
8	5649	A.C. Cord)
9	5556	Knob




Figure 79.




Figure 81. Front Drive Assembly, 1-Wheel Drive PM (115, 119)

Item	Part No.	Description
1	4160	Front Drive Weldment
2	5952	Traction Spring
3	2024	Pressure Bar Weldment
4	2505	Rod, Steering Cyl.
5	1962	Steering Link
6	2512	Steering Cylinder w/Rod End
·	5947	Seal Kit
7	1959	Steering Cylinder Mount
·	5916	Mounting Bolt
8	5122	Fitting, Elbow
9	5949	Motor, Drive (Char-Lynn)
	6816	Seal Kit H-Plus Series (Char-Lynn)
10	4161	Steering Brkt, Weld.
	5993	'O' Ring
	5992	Capscrew
11	2169	Drive Wheel (Non Marking)
12	2016	Steering Arm Weld.
13	1971	Thrust Washer
	5913	Thrust Washer
14	5915	Bushing (Not Shown, 1 Required)
	6326	Bearing (1 Required)
15	5710	Pin
16	5736	Retaining Ring
17	5928	Retaining Ring
18	6124	Cap Screw
	5470	Washer




Figure 82. Front Drive Assembly, 2-Wheel Drive PM (215, 219)

Item	Part No.	Description
1	4159	Main Bracket, Front
2	2060	Tie Rod
3	5679	Rod End, Steering
	5680	Lock Nut
4	2074	L.H. Wheel Bracket
	2195	Trim
5	6134	Pipe Extender
6	6032	Drive Motor (HPI)
	6242	Seal Kit (HPI Motor)
	6307	Seal Kit (Char-Lynn Motor)
	6986	Castle Nut
7	4157	Pivot Plate
	5417	Capscrew
8	5874	Bearing (2 per Pivot Plate)
	5419	Retaining Ring
9	2389	Thrust Washer
10	2064	Front Whool (Nom Mark)
11	2838	Front Wheel (Non Marking)
	2837	Steering Cylinder w/Rod End Cylinder Rod
	5947	Seal Kit
12	2302	· · · ·
	5710	Steering Cylinder Bracket Clevis Pin
13	5916	Mounting Bolt
14	2073	R.H. Wheel Bracket
15	5996	Hose Drive O
16	5787	Hose, Drive Crossover Cotter Pin
17	6351	Hose Drive
18	5874	
	5432	Bearing (2 per Spindle)
19	6211	Grease Fitting
	5417	Capscrew (1/2" x 1-1/4")
20	5756	Capscrew (3/8" x 1-1/4")
1	5039	Bolt
2	5736	Capscrew
	5216	Retaining Ring
3	5419	Washer
		Retaining Ring





Figure 83. Front Drive Assembly, 2-Wheel Drive AM Models (216, 220)

Item	Part No.	Description		
1	4158	Front Drive Weldment		
2	2101	Tie Rod		
3	5981	Rod End, Steering		
3	6498	Lock Nut		
4	4010	L.H. Wheel Bracket		
-1	6247	Adj. Screw (Not Shown)		
	6248	Nut (Not Shown)		
5	6134	Pipe Extender		
6	6616	Drive Motor (HPI)		
O	6242	Seal Kit (HPI Motor)		
	6986	Castle Nut		
7	4156	Pivot Plate		
,	5874	Bearing (2 per Pivot Plate)		
8	6211	Capscrew		
9	2389	Thrust Washer		
10	2996	Front Wheel		
11	2838	Steering Cylinder w/Rod End		
11	2837	Cylinder Rod		
	5947	Seal Kit		
12	2302	Steering Cylinder Mount (Not Shown)		
13	4009	R.H. Wheel Bracket		
10	6247	Adj. Screw (Not Shown)		
	6248	Nut (Not Shown)		
14	5996	Hose Drive Crossover		
15	6351	Hose Drive		
16	5874	Bearing (2 per spindle)		
10	5432	Grease Fitting		
17	5693	Capscrew		
18	5033	Nut		
19	5736	Retaining Ring		
, 0	5216	Washer		
20	5419	Retaining Ring		
21	2195	Trim		



Item	Part No.	Description
1	4158	Main Bracket, Front
2	2101	Tie Rod
3	5981	Rod End, Steering
	6498	Lock Nut
4	2244	L.H. Wheel Bracket
5	6134	Pipe Extender
6	6210	Drive Motor (Char-Lynn Pictured) (HPI Also Available
	6307	Seal Kit (Char-Lynn Pictured)
	6242	Seal Kit (HPI)
	6986	Castle Nut
7	4156	Pivot Plate
	5874	Bearing (2 per Pivot Plate)
8	6211	Capscrew
9	2389	Thrust Washer
10	2309	Front Wheel
11	2838	Steering Cylinder w/Rod End
	2837	Cylinder Rod
	5947	Seal Kit
	6004	45° Fitting (Not Shown)
	6006	90° Fitting (Not Shown)
12	2243	R.H. Wheel Bracket
13	6351	Hose Drive
14	5874	Bearing (2 per Spindle)
	5432	Grease Fitting
15	5736	Retaining Ring
	5216	Washer
16	6211	Capscrew
	5012	Washer
17	5419	Retaining Ring
	2389	Washer
18	5693	Capscrew
	5012	Washer
	5033	Nut
19	6247	Adj. Screw
	6248	Lock Nut
20	2370	Trim
21	2438	Trim




Figure 85. Stabilizer Activating arm Assembly - Part Number 2130

Item	Part No.	Description
1	6504	Switch, Stabilizers
	5723	Adj. Bolt (Not Shown)
	5276	Nut (Not Shown)
2	6036	Harness, Stabilizers
3	2158	Switch Bracket
4	2159	Switch Cover
5	2134	Actuator Bar Weld, L.H.
6	2161	Actuator Bar Weld, R.H.
7	5925	Hex Lock Nut
8	5923	Washer, Belle Ville Spring
9	6034	Strain Relief, 90 Degree
10	6033	Strain Relief, Straight
11	2015	Bar, Pressure Compensating
12	5910	Rod End, Stabilizers P.M.
	6617	Rod End, AM (Not Shown)
	5989	Capscrew (Not Shown)
	5994	Washer (Not Shown)
	5990	Nut (Not Shown)
	1966	Pin (Not Shown)
	8096	Retaining Pin (Not Shown)
13	8289	Screw
14	5926	Cap Screw
15	6061	Expanpin




Figure 86. Rear Axle Assembly TM II (215, 220)

Item	Part No.	Description	
1	4045	Wheel, Rear w/Bearings	
2	2270	Brake Pad	
2	5736	Retaining Ring	
3	2260	Eccentric Brake	
4	2469	Rear Axle Weldment	
5	2262	Brake Activator Assy.	
6	2483	Brake Cylinder	
O	5947	Seal Kit	
7	5687	Spring, Brake	
8	5215	Capscrew	
9	2272	Clevis, Brake Cylinder	
10	6327	Washer, Inner	
11	6326	D.U. Bearings (2 Req.)	
12	1836	Washer, Outer	
13	5737	Castle Nut	
14	5738	Cotter Key	
15	5866	Bearing, Brake Rod (Nylon) (4 Req.)	




Figure 87. Rear Axle Assembly A.M. (216, 220)

Item	Part No.	Description	
1	4071	Wheel, Rear w/Bearings	
2	2270	Brake Pad	
-	5736	Retaining Ring	
3	4001	Eccentric Brake	
4	4006	Rear Axle Weldment	
5	2262	Brake Activator Assy.	
Ü	5215	Capscrew	
6	2483	Brake Cylinder	
Ü	5947	Seal Kit	
7	5687	Spring, Brake	
8	5737	Castle Nut	
9	5874	D.U. Bearing (2 req.)	
10	1835	Washer, Inner	
11	5738	Cotter Key	
12	1836	Washer, Outer	
13	5866	Bearing, Brake Rod (Nylon) (4 req.)	




Figure 88. Rear Axle Assembly P.M. (215, 219)

Item	Part No.	Description		
1	4046	Wheel, Rear w/Bearings		
2	2098	Eccentric Brake		
3	2066	Rear Axle Weldment		
4	1851	Adjusting Rod		
5	5687	Spring, Brake		
6	2483	Brake Cylinder		
	5947	Seal Kit		
7	1864	Clevis Brake Cylinder		
8	2262	Brake Activator Assy.		
9	5874	D.U. Bearing (2 Req.)		
10	5737	Castle Nut		
11	1835	Washer, Inner		
12	5738	Cotter Key		
13	1836	Washer, Outer		
14	5686	Spanner Bushing		
15	5866	Bearing, Brake Rod (Nylon) (4 Req.)		