




Service & Parts Manual

69ERT Series



ART_4265

ERT - Electric

3369ERT Serial Number Range 13200000 - 13200034
4069ERT Serial Number Range 13700000 - 13700034

Part # 43528
July 2026

Revision History

Date	Reason for Update
March 2019	New Release
August 2019	Added 43830, 43831, 43832, 43833 Updated descriptions of 43010, 43022, 43028, 43038
December 2020	Electrical Harnesses Added
November 2025	Updated items #1 and #4 for page 62.
April 2026	Added serial breaks and second row to item #6 for page 54. Added new style of Function Manifold on page 58.
July 2026	Updated description and added sub-components for item #15 for page 44. Updated description and added sub-components for item #3 for page 46.



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA
Toll Free: 1 - 877 - 632 - 5438
Phone: 1 - 559 - 842 - 1500
Fax: 1 - 559 - 842 - 1520
info@MECawp.com
www.MECawp.com

Table of Contents

Chapter 1 - Service	1
<i>Service Introduction</i>	1
Section 1 - MEC Operator Policy	2
<i>MEC Operator Policy</i>	2
Section 2 - Safety Symbols & General Safety Tips	3
<i>Safety Symbols & General Safety Tips</i>	3
Section 3 - Specifications	4
<i>3369 Specifications</i>	4
<i>4069 Specifications</i>	5
Section 4 - Troubleshooting	6
<i>69ERT Fault Codes</i>	6
Section 5 - Maintenance.	10
<i>Maintenance</i>	10
<i>Pre-Delivery Preparation Report</i>	11
<i>Maintenance Inspection Report</i>	12
<i>Checklist A Procedures</i>	13
<i>Checklist B Procedures</i>	17
<i>Checklist C Procedures</i>	23
<i>Checklist D Procedures</i>	24
<i>Checklist E Procedure</i>	29
Section 6 - Schematics	32
<i>69ERT Models - Electrical Manifold</i>	32
<i>69ERT Electrical Schematic</i>	34
<i>69ERT Hydraulic Schematic</i>	35
<i>Notes</i>	36
Chapter 2 - Parts	37
<i>Parts Introduction</i>	37
Section 7 - Chassis	38
<i>Steer Axle Assembly Installation</i>	38
<i>Steer Axle Assembly</i>	40
<i>Rear Axle Assembly Installation</i>	42
<i>Right Rear Wheel Assembly</i>	44
<i>Left Rear Wheel Assembly</i>	46
<i>Hydraulic Module Installation</i>	48
<i>Hydraulic Module Door Installation</i>	50
<i>Hydraulic Module Assembly</i>	52
<i>Function Manifold Assembly</i>	54
<i>Function Manifold - ERT Models</i>	56
<i>Function Manifold - ERT Models</i>	58
<i>Outrigger Manifold Assembly</i>	60

Ground Control Box Assembly	62
Hydraulic Tank Assembly	64
Pump Assembly	66
Filter Assembly	68
Battery Module Installation	70
Battery Module Door Installation	72
Battery Module Assembly	74
Motor Controller Assembly	76
Outriggers and Ladder Installation.	78
Outrigger Assembly (Option)	80
Chassis Accessory Installation	82
Electrical Accessory Assembly	84
Section 8 - Scissor	86
Scissor Assembly - 3369	86
Scissor Assembly - 4069	88
Slider Assembly	91
Hose Clamp Assembly	92
Hose Clamp Assembly - 4069.	93
Section 9 - Platform	94
Main Platform Assembly	94
Support Roller Assembly	96
Side Roller Assembly	98
Platform Extension Assembly	100
Platform Locking Device Assembly	103
Roller Assembly	104
Platform Control and Sheet Material Tray	106
Platform Control Box Assembly	108
Section 10 - Hydraulic System	110
Lower Lift Cylinder Assembly	110
Upper Lift Cylinder Assembly	112
Right Oscillate Cylinder Assembly.	114
Left Oscillate Cylinder Assembly	115
Steer Cylinder Assembly	116
Outrigger Cylinder Assembly (Option).	118
Hydraulic Hoses and Fittings-Function (3369ERT)	120
Hydraulic Hoses and Fittings-Function (4069ERT)	122
Hydraulic Hoses and Fittings-Outrigger (Option)	124
Section 11 - Electrical System	126
Electrical Harness	126
Power to Platform	129
Section 12 - Decals	131
ERT Machine Decals	131

Service Introduction

This Service section is designed to provide you, the customer, with the instructions needed to properly maintain the MEC self-propelled aerial work platform. When used in conjunction with the illustrated Parts section in this manual and the Operator's Manual (provided separately), this manual will assist you in making necessary adjustments and repairs, and identifying and ordering the correct replacement parts.

All parts represented here are manufactured and supplied in accordance with MEC quality standards. We recommend that you use genuine MEC parts to ensure proper operation and reliable performance.

To obtain maximum benefits from your MEC Aerial Work Platforms, always follow the proper operating and maintenance procedures. Only trained authorized personnel should be allowed to operate or service this machine. Service personnel should read and study the Operator's, and the Service and Parts Manuals in order to gain a thorough understanding of the unit prior to making any repairs.

MEC Operator Policy

Note: *The best method to protect yourself and others from injury or death is to use common sense. If you are unsure of any operation, **don't start** until you are satisfied that it is safe to proceed and have discussed the situation with your supervisor.*

Service personnel and machine operators must understand and comply with all warnings and instructional decals on the body of the machine, at the ground controls, and platform control console.



MODIFICATIONS OF THIS MACHINE FROM THE ORIGINAL DESIGN AND SPECIFICATIONS WITHOUT WRITTEN PERMISSION FROM MEC ARE STRICTLY FORBIDDEN. A MODIFICATION MAY COMPROMISE THE SAFETY OF THE MACHINE, SUBJECTING OPERATOR(S) TO SERIOUS INJURY OR DEATH.

MEC's policies and procedures demonstrate our commitment to Quality and our relentless ongoing efforts towards Continuous Improvement, due to which product specifications are subject to change without notice.

Any procedures not found within this manual must be evaluated by the individual to assure oneself that they are "proper and safe."

Your MEC Aerial Work Platform has been designed, built, and tested to provide many years of safe, dependable service. Only trained, authorized personnel should be allowed to operate or service the machine.

MEC, as manufacturer, has no direct control over machine application and operation. Proper safety practices are the responsibility of the user and all operating personnel.

If there is a question on application and/or operation, contact MEC Aerial Work Platforms:



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA
Toll Free: 1 - 877 - 632 - 5438
Phone: 1 - 559 - 842 - 1500
Fax: 1 - 559 - 842 - 1520
info@MECawp.com
www.MECawp.com

Safety Symbols & General Safety Tips

MEC manuals and decals use symbols, colors and signal words to help you recognize important safety, operation and maintenance information.



RED and the word **DANGER** – Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



ORANGE and the word **WARNING** – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



YELLOW with alert symbol and the word **CAUTION** – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



YELLOW without alert symbol and the word **CAUTION** – Indicates a potentially hazardous situation which, if not avoided, may result in property damage.



GREEN and the word **NOTICE** – Indicates operation or maintenance information.

Regular inspection and constant maintenance is the key to efficient economical operation of your aerial work platform. It will help to assure that your equipment will perform satisfactorily with a minimum of service and repair.

The actual operating environment of the machine governs the inspection schedule. Correct lubrication is an essential part of the preventative maintenance to minimize wear on working parts and ensure against premature failure. By maintaining correct lubrication, the possibility of mechanical failure and resulting downtime is reduced to a minimum.

- Never leave hydraulic components or hoses open. They must be protected from contamination (including rain) at all times.
- Never open a hydraulic system when there are contaminants in the air.
- Always clean the surrounding area before opening hydraulic systems.
- Use only recommended lubricants. Improper lubricants or incompatible lubricants may be as harmful as no lubrication.
- Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.

3369 Specifications

Height, Working Maximum	38 ft 10 in	12 m
Height, Platform Maximum	32 ft 10 in	10 m
Height, Stowed Maximum Rails Up	8 ft 6 in	2.59 m
Height, Stowed Maximum Rails Folded	5 ft 11 in	1.82 m
Width, Standard Tires	5 ft 9 in	1.76 m
Length, Platform Retracted Models Without Outriggers	10 ft 6 in	3.19 m
Length, Platform Retracted Models With Outriggers	12 ft 7 in	3.84 m
Length, Platform Extended Models Without Outriggers	14 ft 9 in	4.51 m
Length, Platform Extended Models With Outriggers	15 ft 9 in	4.81 m
Platform Dimensions Platform Length × Width	9 ft 5 in × 4 ft 11 in	2.88 × 1.52 m
Platform Extension Length	4 ft 8 in	1.43 m
Maximum Load Capacity	1,000 lb	454 kg
Maximum Wind Speed	28 mph	12.5 m/s
Wheelbase	7 ft 6 in	2.29 m
Turning Radius (Outside)	15 ft 1 in	4.60 m
Turning Radius (Inside)	6 ft 11 in	2.11 m
Ground Clearance	9 ½ in	24 cm
Weight	See Serial Label (Machine weights vary with option configurations)	
Controls	Proportional	
AC Outlet In Platform	Standard	
Maximum Hydraulic Pressure (Functions)	3,500 psi	240 bar
Tire Size - Standard Tires	26 × 12-16.5	
Airborne Noise Emissions	<80 dB Maximum sound level at normal operating workstations (A-weighted)	
Gradeability	40%	
Maximum Working Slope	X-1.5°, Y-3°	
Drive Speeds		
Stowed, Maximum	3.2 mph	5.0 km/h
Platform Raised, Maximum	0.3 mph	0.45 km/h
Floor Loading Information		
Tire Load, Maximum	4,254 lb	1,930 kg
Outrigger Load, Maximum	4,254 lb	1,930 kg
Tire Contact Pressure	137 psi	945.5 kPa
Outrigger Contact Pressure	87 psi	602 kPa
Occupied Floor Pressure	178 psf	8.5 kPa

Note: Floor loading information is approximate and does not incorporate different option configurations. It should be used only with adequate safety factors.

4069 Specifications

Height, Working Maximum	46 ft 4 in	14.3 m
Height, Platform Maximum	40 ft 4 in	12.3 m
Height, Stowed Maximum Rails Up	8 ft 11 in	2.74 m
Height, Stowed Maximum Rails Folded	6 ft 5 in	1.97 m
Width, Standard Tires	5 ft 9 in	1.76 m
Length, Platform Retracted Models Without Outriggers	10 ft 6 in	3.19 m
Length, Platform Retracted Models With Outriggers	12 ft 7 in	3.84 m
Length, Platform Extended Models Without Outriggers	14 ft 9 in	4.51 m
Length, Platform Extended Models With Outriggers	15 ft 9 in	4.81 m
Platform Dimensions Platform Length × Width	9 ft 5 in × 4 ft 11 in	2.88 × 1.52 m
Platform Extension Length	4 ft 8 in	1.43 m
Maximum Load Capacity	800 lb	363 kg
Maximum Wind Speed	28 mph	12.5 m/s
Wheelbase	7 ft 6 in	2.29 m
Turning Radius (Outside)	15 ft 1 in	4.60 m
Turning Radius (Inside)	6 ft 11 in	2.11 m
Ground Clearance	9 ½ in	24 cm
Weight	See Serial Label (Machine weights vary with option configurations)	
Controls	Proportional	
AC Outlet In Platform	Standard	
Maximum Hydraulic Pressure (Functions)	3,500 psi	240 bar
Tire Size - Standard Tires	26 × 12-16.5	
Airborne Noise Emissions	<80 dB Maximum sound level at normal operating workstations (A-weighted)	
Gradeability	40%	
Maximum Working Slope	X-1.5°, Y-3°	
Drive Speeds		
Stowed, Maximum	3.2 mph	5.0 km/h
Platform Raised, Maximum	0.3 mph	0.45 km/h
Floor Loading Information		
Tire Load, Maximum	4,872 lb	2,210 kg
Outrigger Load, Maximum	4,872 lb	2,210 kg
Tire Contact Pressure	154 psi	1,065 kPa
Outrigger Contact Pressure	98 psi	678 kPa
Occupied Floor Pressure	198 psf	9.5 kPa

Note: Floor loading information is approximate and does not incorporate different option configurations. It should be used only with adequate safety factors.

69ERT Fault Codes

Fault Code	Display	Description	Solution
01	Internal ECU Fault	Main ECU system fault	Replace ECU.
02	Platform ECU Fault	ECU/Platform communication fault	Check communications cable connections and other wiring. If that does not resolve the problem, try replacing the PCU or ECU.
03	MC PEDAL WIRE KO	Motor controller analog signals Fault	Check input analog signal.
04	MC COIL SHOR. MC-EB	Motor controller brake contactor end Fault	Check contactor and brake coil.
05	MC LOGIC FAILURE #3	Motor controller logic unit Fault	Replace motor controller.
06	MC CAPACITOR CHARGE	Motor controller capacitor charge Fault	Pre-charge resistance fault. Replace motor controller.
07	MC VMN LOW	Motor controller Power unit Fault	Check motor wiring, power unit of motor controller short circuit.
08	Floating Coil Left Fault	Left Floating Coil Fault	Check the connections to the coil's terminals and make sure they are tight. If so, check the coil itself to see if it is open or shorted.
09	Floating Coil Right Fault	Right Floating Coil Fault	Check the connections to the coil's terminals and make sure they are tight. If so, check the coil itself to see if it is open or shorted.
10	MC VACC OUT RANGE	Motor controller Analog signals Error	Analog value is out of the range, calibrate again.
11	MC STBY I HIGH	Motor controller Electrical current sensor Fault	Replace motor controller.
12	MC CONTACTOR OPEN	Motor controller Contactor Drive Fault	Check if contactor's contact point has been closed and coil's connection is abnormal.
13	MC SLIP_PROFILE	Motor controller SLIP setup Error	Parameter setting wrong at 'Hardwaresetting' option.
14	Angle Sensor Fault	Angle Sensor Fault	Restart system, check the wiring, reset sensor, replace sensor.
15	Pressure Sensor Fault	Pressure Sensor Fault	Restart system, check the wiring, reset sensor, replace sensor.
16	MC AUX DRIV.SHRT.	Motor controller Brake Drive Fault	Motor brake coil has short circuit, motor controller short circuit.
17	MC LOGIC FAILURE #1	Motor controller LOGIC unit 1 Fault	Voltage of A10 pin is abnormal, check battery voltage.
18	MC LOGIC FAILURE #2	Motor controller LOGIC unit 2 Fault	Replace motor controller.
19	MC POS. EB. SHORTED	Motor controller Brake Drive Fault	Motor brake coil has short circuit, motor controller short circuit
20	Chassis Start Sw Fault	Chassis Start Switch ON at power-up	Self-check fault, don't touch other button at power-on.
21	Chassis Choke Sw Fault	Chassis Choke Switch ON at power-up	Self-check fault, don't touch other button at power-on.
22	Chassis Up Sw Fault	Chassis Up Switch ON at power-up	Self-check fault, don't touch other button at power-on.

23	Chassis Lift Sw Fault	Chassis Lift Switch ON at power-up	Self-check fault, don't touch other button at power-on.
24	Chassis Down Sw Fault	Chassis Down Switch ON at power-up	Self-check fault, don't touch other button at power-on.
25	Left Turn Switch Fault	Platform Left Turn Switch ON at power-up	Self-check fault, don't touch other button at power-on.
26	Right Turn Switch Fault	Platform Right Turn Switch ON at power-up	Self-check fault, don't touch other button at power-on.
27	Drive Enable Sw Flt	Platform Drive Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
28	Off Neutral Drive Joystick	Platform Joystick not in neutral ON at power-up	Self-Check fault, don't touch joystick or other button at power-on.
31	Platform Choke Sw Fault	Platform Choke Switch ON at power-up	Self-check fault, don't touch other button at power-on.
32	Platform Start Sw Fault	Platform Start Switch ON at power-up	Self-check fault, don't touch other button at power-on.
33	Left Front Outrig Sw Flt	Platform Left Front Outrigger Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
34	Right Front Outrig Sw Flt	Platform Right Front Outrigger Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
35	Left Rear Outrig Sw Flt	Platform Left Rear Outrigger Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
36	Right Rear OutrigSw Flt	Platform Right Rear Outrigger Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
37	Auto Level Switch Fault	Platform Outrigger AutoLevel Enable Switch ON at power-up	Self-check fault, don't touch other button at power-on.
38	MC FORW + BACK	Input signal Fault	Receive forward and backward signal at the same time
39	MC INCORRECT START	Input signal Fault	Check motor controller.
40	MC VACC NOT OK	Analog signals Error	Analog value is out of the range, calibrate again.
41	MC CONTACTOR DRIVER	Contactor Drive Fault	Main contactor short circuit.
42	MC TH. PROTECTION	Motor controller temperature Fault	Controller temperature exceed 85 degrees.
43	Float Limit Switch Fault	Float limit switch fault	Check float limit switches (work at the same time), Check wires.
44	MC BATTERY LOW	Motor controller Voltage of Battery is Low	Check battery voltage, charger or replace battery.
45	MC EEPROM KO	Motor controller Memorizer Fault	Load software again or replace motor controller.
46	MC MOTOR TEMPERAT.	Motor temperature Fault	Motor temperature exceed 150 degrees.
47	MC WRONG BATTERY	Voltage setup Error	Voltage setting is wrong, battery voltage is abnormal (beyond $\pm 20\%$).

48	MC THERMIC SENS. KO	Motor controller temperature Fault	Temperature sensor is out of the range.
49	MC SMART DRIVER KO	Motor controller Smart driver Fault	Check parameter, check brake coil, check the pin 2 is directly connected to the negative pole, then disconnect the brake.
50	MC NO CAN MSG.	Motor controller Inner CAN bus lose	CAN bus lose, replace motor controller.
51	MC AUX DRIV.OPEN	Motor controller Brake Drive Fault	Brake port is disconnected.
52	MC ANALOG INPUT	Motor controller Logic unit Fault	Check input signal, or replace motor controller.
53	MC WATCHDOG	Motor controller Watchdog Fault	Replace motor controller.
54	Up Coil Fault	Lift up coil fault	Check wiring, replace coil.
55	Down Coil Fault	Lift down coil fault	Check wiring, replace coil.
56	Right Turn Coil Fault	Steer right coil fault	Check wiring, replace coil.
57	Left Turn Coil Fault	Steer left coil fault	Check wiring, replace coil.
58	MC WATCHDOG #2	Motor controller Watchdog Fault	Replace motor controller.
59	MC EMERGENCY	Motor controller A3 port abnormality	Check pin 3 signal.
60	MC POWER MOS SHORT	Motor controller Power unit short	Replace motor controller.
61	MC CONTACTOR CLOSED	Contactor drive Fault	Contactor's contact point has been closed, replace contactor
62	MC ENCODER ERROR	Motor Encoder Error	Motor Encoder signal abnormal, replace encoder
63	MC TILLER OPEN	Input signal Fault	Check input signal, or replace motor controller.
64	MC DEAD MAN ABSENT	Motor controller Deadman SW absent	Replace motor controller.
65	MC CURRENT SENS. KO	Motor controller Current sensor Fault	Replace motor controller.
66	MC PUMP VACC NOT OK	Motor controller Lift analog signals Error	Analog value is out of the range, calibrate again.
67	MC CURRENT GAIN	Motor controller Current sensor Fault	Replace motor controller.
68	MC LIFT + LOWER	Motor controller Input signal Fault	Check lift up and down input signal.
69	MC PUMP INC START	Motor controller received lift up analog value, without Deadman signal.	Motor controller received lift up analog value, without Deadman signal.
70	MC PUMP VMN LOW	Motor controller Pump Power unit Fault	Pump motor has open or loose contacts, motor controller defective.
71	MC PUMP VMN HIGH	Motor controller Pump Power unit Fault	Pump motor has open or loose contacts, motor controller defective.
72	MC PUMP I=0 EVER	Motor controller Pump sensor current =0	Pump unit current coil fault.
73	C WAITING FOR NODE	Motor controller Waiting for node	Check wires

74	MC PUMP I NO ZERO	Motor controller Pump sensor current is not 0	Replace motor controller.
75	MC COIL INTERRUPTED	Motor controller coil interrupted	Pump analog voltage exceeds actual voltage by 0.4V.
76	MC FLASH CHECKSUM	Motor controller Memorizer Fault	Replace motor controller, update software again.
77	MC KEY OFF SHORTED	Motor controller A10 Voltage Low	There are other loads on the circuit, check wires.
78	MC WRONG RAM	Memorizer Fault	Replace motor controller.
79	MC SENS MOT TEMP KO	Motor controller temperature Fault	Motor temperature sensor fault, replace sensor.
80	MC PHASE KO	Motor lose phase	Check walking motor wiring (include U, V, W phases)
81	Left Front Otrg Coil Flt	Left Front Outrigger Coil Fault	Check wiring, replace coil.
82	Left Rear Otrg Coil Flt	Left Rear Outrigger Coil Fault	Check wiring, replace coil.
83	Right Front Otrg Coil Flt	Right Front Outrigger Coil Fault	Check wiring, replace coil.
84	Right Rear Otrg Coil Flt	Right Rear Outrigger Coil Fault	Check wiring, replace coil.
85	Outrigger Ext Coil Flt	Outrigger Extend Coil Fault	Check wiring, replace coil.
86	Outrigger Ret Coil Flt	Outrigger Retract Coil Fault	Check wiring, replace coil.
87	MC PUMP VMN NOT OK	Motor controller Power unit Fault	Pump power unit fault.
88	MC AUX BATT. SHORT.	Motor controller Brake contactor Fault	Replace motor controller.
89	MC WRONG ZERO	Motor Voltage diagnose Fault	Replace motor controller.
90	MC WRONG CONFIG	Motor controller A18/ A21 signal Fault	Check pin 18 and 21.
91	MC INPUT MISMATCH	Motor controller Input signal mismatch	Check input signal.
92	MC MOTOR STALL	Motor controller encoder defective or has open circuit, motor plugging turns beyond 16s.	Replace encoder.
93	MC SPARE FAULT	Motor controller other faults	Replace motor controller.
96	MC DRIVER SHORTED	Motor controller contactor drive fault	Main contractor coil fault, has open or short circuit.
97	MC VMN HIGH	Motor controller power unit fault	Loose contact of motor wire, motor controller short circuit.
98	Platform Overload	Platform Overload Fault	Remove the excess load immediately.
LL	LL Tilt	Machine Tilted Beyond Safe Limits Fault	If the machine is tilted, find a way to make it level. If the machine is level, check the wiring to the tilt sensor and then the sensor itself.

Maintenance

Observe and Obey:

- Only routine maintenance items specified in this manual shall be performed by the operator.
- Scheduled maintenance inspections shall be completed by qualified service technicians, according to the manufacturer's specifications and the requirements specified in this manual.

Pre-Delivery Preparation Report

The Pre-Delivery Preparation Report contains checklists for each type of scheduled inspection.

Make copies of the Pre-Delivery Preparation Report to use for each inspection. Store completed forms as required.

Maintenance Schedule

There are five types of maintenance inspections that must be performed according to a schedule—daily, quarterly, semi-annually, annually, and two year. The Scheduled Maintenance Procedures Section and the Maintenance Inspection Report have been divided into five subsections— A, B, C, D, and E. Use the following chart to determine which group(s) of procedures are required to perform a scheduled inspection.

Inspection	Checklist
Daily or every 8 hours	A
Quarterly or every 250 hours	A+B
Semi-annually or every 500 hours	A+B+C
Annually or every 1,000 hours	A+B+C+D
Two year or every 2,000 hours	A+B+C+D+E

Maintenance Inspection Report

The Maintenance Inspection Report contains checklists for each type of scheduled inspection.

Make copies of the Maintenance Inspection Report to use for each inspection. Maintain completed forms for a minimum of 4 years or in compliance with your employer, jobsite and governmental regulations and requirements.

Pre-Delivery Preparation Report

Fundamentals

It is the responsibility of the dealer to perform the Pre-Delivery Preparation.

The Pre-Delivery Preparation is performed prior to each delivery. The inspection is designed to discover if anything is apparently wrong with a machine before it is put into service.

A damaged or modified machine must never be used. If damage or any variation from factory delivered condition is discovered, the machine must be tagged and removed from service.

Repairs to the machine may only be made by a qualified service technician, according to the manufacturer's specifications.

Scheduled maintenance inspections shall be performed by qualified service technicians, according to the manufacturer's specifications and the requirements listed in this manual.

Instructions

The Pre-Delivery Preparation consists of completing the Pre-Operation Inspection, the Maintenance items and the Function Tests.

Use this form to record the results. Place a check in the appropriate box after each part is completed.

If any inspection receives an N, remove the machine from service, repair and re-inspect it. After repair, place a check in the R box.

Instructions

- Make copies of this report to use for each inspection.
- Select the appropriate checklist(s) for the type of inspection to be performed.
- Place a check in the appropriate box after each inspection procedure is completed.
- Use the step-by-step procedures in this section to learn how to perform these inspections.
- If any inspection receives an "N", tag and remove the machine from service, repair and re-inspect it. After repair, place a check in the "R" box.

Legend
Y = Yes, Completed
N = No, Unable To Complete
R = Repaired

Pre-Delivery Preparation	Y	N	R
Pre-Operation Inspection completed			
Maintenance items completed			
Function tests completed			

Maintenance Inspection Report

	Daily or 8 hours Inspection:	A
	Quarterly or 250 hours Inspection:	A+ B
	Semi-annually or 500 hours Inspection:	A+B+C
	Annually or 1,000 hours Inspection:	A+B+C+D
	Two year or 2,000 hours Inspection:	A+B+C+D+E

Checklist A	Y	N	R
A-1 Inspect Manuals and Decals			
A-2 Perform Pre-Operation Inspection			
A-3 Check Battery			
A-4 Test Oscillate System			
A-5 Check Engine Oil Level			
A-6 Check Hydraulic Oil Level			
A-7 Check Engine Coolant Level			
A-8 Perform Function Tests			
Perform After 30 Days:			
A-9 Perform Engine Maintenance			
Perform After 40 Hours:			
A-10 Perform 30 Day Service			

Checklist B	Y	N	R
B-1 Inspect the Battery			
B-2 Inspect the Electrical Wiring			
B-3 Inspect the Tires and Wheels			
B-4 Check the Oil Level in the Drive Hubs			
B-5 Test the Emergency Stop			
B-6 Test the Key Switch			
B-7 Test the Automotive-style Horn			
B-8 Test the Down Limit Switch			
B-9 Test the Up Limit Switch			
Perform After 400 Hours:			
B-10 Perform Engine Maintenance			

Checklist C	Y	N	R
C-1 Check the Down Limit Switch Height			
Perform After 800 Hours:			
C-2 Perform Engine Maintenance			

Checklist D	Y	N	R
D-1 Replace Hydraulic Tank Return Filter Element			
D-2 Perform Engine Maintenance			
D-3 Replace the Drive Hub Oil			
D-4 Test the Drive Brakes			
D-5 Test the Drive Speed - Stowed Position			
D-6 Test the Drive Speed - Raised Position			
D-7 Perform Hydraulic Oil Analysis			
D-8 Fuel and Hydraulic Tank Cap Venting System			
D-9 Test the Flashing Beacons			

Checklist E	Y	N	R
E-1 Test or Replace the Hydraulic Oil			
E-2 Perform Engine Maintenance			
E-3 Clean the Fuel Tank			
E-4 Replace the Hydraulic Tank Breather Cap			

Model	_____	Inspected By (Print)	_____
Serial Number	_____	Inspector Signature	_____
Date	_____	Inspector Title	_____
Machine Owner	_____	Inspector Company	_____

Checklist A Procedures

A-1 Inspect the Manuals and Decals

Maintaining the operator's manual in good condition is essential to safe machine operation. Manuals are included with each machine and should be stored in the container provided in the platform. An illegible or missing manual will not provide safety and operational information necessary for a safe operating condition.

In addition, maintaining all of the safety and instructional decals in good condition is mandatory for safe machine operation. Decals alert operators and personnel to the many possible hazards associated with using this machine. They also provide users with operation and maintenance information. An illegible decal will fail to alert personnel of a procedure or hazard and could result in unsafe operating conditions.

1. Check to make sure that the operator's manual is present and complete in the storage container on the platform.
2. Examine the pages of manual to be sure that they are legible and in good condition.
 - **Result:** The operator's manual is appropriate for the machine and the manual are legible and in good condition.
 - **Result:** The operator's manual is not appropriate for the machine or the manual is not in good condition or is illegible. Remove the machine from service until the manual is replaced.
3. Open the operator's manual to the decals inspection section. Carefully and thoroughly inspect all decals on the machine for legibility and damage.
 - **Result:** The machine is equipped with all required decals, and all decals are legible and in good condition.
 - **Result:** The machine is not equipped with all required decals, or one or more decals are illegible or in poor condition. Remove the machine from service until the decals are replaced.
4. Always return the manual to the storage container after use.

A-2 Perform Pre-Operation Inspection

Completing a Pre-Operation Inspection is essential to safe machine operation. The Pre-Operation Inspection is a visual inspection performed by the operator prior to each work shift. The inspection is designed to discover if anything is apparently wrong with a machine before the operator performs the function tests. The Pre-Operation Inspection also serves to determine if routine maintenance procedures are required.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

A-3 Check the Battery

- New parts will be required to perform this procedure.

Proper battery condition is essential to good machine performance and operational safety. Improper fluid levels or damaged cables and connections can result in component damage and hazardous conditions.

**WARNING**

Electrocution hazard. Contact with hot or live circuits may result in death or serious injury. Remove all rings, watches and other jewelry.

**WARNING**

Bodily injury hazard. Battery contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

1. Put on protective clothing and eye wear.
2. Be sure that the battery cable connections are tight and free of corrosion.
3. Be sure that the battery hold-down bars are secure.
4. Remove the battery vent caps.
5. Check the battery acid level. If needed, replenish with distilled water to the bottom of the battery fill tube. Do not overfill.
6. Install the vent caps.

A-4 Test the Oscillate System

The oscillate system is designed so that all four tires maintain firm contact with the ground on unlevel terrain, improving traction and machine stability.

Proper axle oscillation is essential to safe machine operation. If the axle oscillation system is not operating correctly, the stability of the machine is compromised and it may tip over.

Test The Oscillate System (Stowed Position)

1. Drive the left steer tire up onto a 4 in (10 cm) high ramp.
 - **Result:** All four tires should maintain firm contact with the ground.
2. Drive the right steer tire up onto a 4 in (10 cm) high ramp.
 - **Result:** All four tires should maintain firm contact with the ground.

Note: Verify that there are no fault codes shown on ground control display.

Test The Oscillate System (Elevated Position)

1. Press the lift function select button. Raise the platform approximately 8 ft (2.4 m) from the ground.
2. Drive the left steer tire into a 4 in (10 cm) deep hole.
 - **Result:** All four tires should maintain firm contact with the ground.
3. Drive the right steer tire into a 4 in (10 cm) deep hole.
 - **Result:** All four tires should maintain firm contact with the ground.

Note: Verify that there are no fault codes shown on ground control display.

A-5 Check the Engine Oil Level

- Tools will be required to perform this procedure.

Maintaining the proper engine oil level is essential to good engine performance and service life.

Operating the machine with an improper oil level can damage engine components.

NOTICE

Check the oil level with the engine off.

1. Open the engine cover.
2. Release the latches on the engine tray and fully rotate out.
3. Check the oil level dipstick. Add oil as needed.

Oil Type	5W-30
Oil Type – Cold Conditions	0W-20

A-6 Check the Hydraulic Oil Level

- New parts will be required to perform this procedure.

Maintaining the hydraulic oil at the proper level is essential to machine operation. Improper hydraulic oil levels can damage hydraulic components. Daily checks allow the inspector to identify changes in oil level that might indicate the presence of hydraulic system problems.

NOTICE

Perform this procedure with the platform in the stowed position and the engine off.

1. Visually inspect the sight of hydraulic oil level from the side of the hydraulic oil tank.
 - **Result:** The hydraulic oil level should be within the top 2 in (5 cm) of the tank sight gauge.
2. Add oil if necessary. Do not overfill.

NOTICE

Original Hydraulic oil specifications ISO-46.

Customers shall choose the appropriate hydraulic oil according to the ambient temperature used.

- **Example:** ISO-32 for cold temperatures.

A-7 Check the Engine Coolant Level

- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

Maintaining the engine coolant at the proper level is essential to engine service life. Improper coolant level will affect the engine's cooling capability and damage engine components. Daily checks will allow the inspector to identify changes in coolant level that might indicate cooling system problems. Check the fluid level in the radiator. Add fluid as needed.

**WARNING**

Bodily injury hazard. Fluids in the radiator are under pressure and extremely hot. Use caution when removing cap and adding fluids.

A-8 Perform Function Tests

Completing the function tests is essential to safe machine operation. Function tests are designed to discover any malfunctions before the machine is put into service. A malfunctioning machine must never be used. If malfunctions are discovered, the machine must be tagged and removed from service.

Complete information to perform this procedure is available in the appropriate operator's manual. Refer to the Operator's Manual on your machine.

A-9 Perform Engine Maintenance

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

Engine specifications require that this procedure be performed every 30 days or monthly.

Required maintenance procedures and additional engine information is available in the engine operator's manual.

A-10 Perform 30 Day Service

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

The 30 day maintenance procedure is a one time procedure to be performed after the first 30 days or 40 hours of usage. After this interval, refer to the maintenance tables for continued scheduled maintenance.

Perform the following maintenance procedures:

- B-3 Inspect the Tires, Wheels and Castle Nut Torque
- B-4 Check the Oil Level in the Drive Hubs
- D-1 Replace the Hydraulic Tank Return Filter Element

Checklist B Procedures

B-1 Inspect the Battery

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first. Proper battery condition is essential to good machine performance and operational safety. Improper fluid levels or damaged cables and connections can result in component damage and hazardous conditions.



Electrocution / burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.



Bodily injury hazard. Battery contain acid. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

1. Put on protective clothing and eye wear.
2. Be sure that the battery cable connections are free of corrosion.

Note: Adding terminal protectors and a corrosion preventative sealant will help eliminate corrosion on the battery terminals and cables.

3. Be sure that the battery retainers and cable connections are tight.
4. Fully charge the battery. Allow the battery to rest 24 hours before performing this procedure to allow the battery cells to equalize.
5. Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.
6. Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:
 - Add 0.004 to the reading of each cell for every 10°F (5.5°C) above 80°F (26.7°C).
 - Subtract 0.004 from the reading of each cell for every 10°F (5.5°C) below 80°F (26.7°C).
 - **Result:** All battery cells display an adjusted specific gravity of 1.277 or higher. The battery is fully charged. Proceed to step 10.
 - **Result:** One or more battery cells display a specific gravity of 1.217 or below. Proceed to step 7.
7. Perform an equalizing charge OR fully charge the battery and allow the battery to rest at least 6 hours.
8. Remove the battery vent caps and check the specific gravity of each battery cell with a hydrometer. Note the results.
9. Check the ambient air temperature and adjust the specific gravity reading for each cell as follows:
 - Add 0.004 to the reading of each cell for every 10°F (5.5°C) above 80°F (26.7°C).
 - Subtract 0.004 from the reading of each cell for every 10°F (5.5°C) below 80°F (26.7°C).
 - **Result:** All battery cells display a specific gravity of 1.277 or greater. The battery is fully charged. Proceed to step 10.

- **Result:** One or more battery cells display a specific gravity from 1.269 to 1.218. The battery is still usable, but at a lower performance so will need to be recharged more often. Proceed to step 11.
 - **Result:** One or more battery cells display a specific gravity from 1.217 to 1.173. The battery is approaching the end of its life. Proceed to step 11.
 - **Result:** The difference in specific gravity readings between cells is greater than 0.1 OR the specific gravity of one or more cells is less than 1.172 or less. Replace the battery.
10. Check the battery acid level. If needed, replenish with distilled water to $\frac{1}{8}$ in (3 mm) below the bottom of the battery fill tube. Do not overfill.
 11. Install the vent caps and neutralize any electrolyte that may have spilled.

B-2 Inspect the Electrical Wiring

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining electrical wiring in good condition is essential to safe operation and good machine performance. Failure to find and replace burnt, chafed, corroded or pinched wires could result in unsafe operating conditions and may cause component damage.



Electrocution / burn hazard. Contact with electrically charged circuits could result in death or serious injury. Remove all rings, watches and other jewelry.

1. Inspect the following areas for burnt, chafed, corroded and loose wires:
 - Ground control panel
 - Hydraulic tray
 - Engine tray
 - Scissor arms
 - Platform controls
2. Inspect for a liberal coating of dielectric grease in the following locations:
 - Between the ECM and platform controls
 - All wire harness connectors
 - Level sensor
3. Turn the key switch to ground control and turn the ground red Emergency Stop button clockwise to the on position pull out the platform red Emergency Stop button to the on position.
4. Start the engine and raise the platform approximately 10 ft (3 m) from the ground.
5. Lift the safety arm, move it to the center of the scissor arm and rotate up to a vertical position.
6. Lower the platform onto the safety arm.



Crushing hazard. Keep hands clear of the safety arm when lowering the platform.

7. Inspect the center chassis area and scissor arms for burnt, chafed and pinched cables.
8. Inspect the following areas for burnt, chafed, corroded, pinched and loose wires:
 - ECU to platform controls

- Power to platform wiring
9. Raise the platform and return the safety arm to the stowed position.
 10. Lower the platform to the stowed position and turn the machine off.

B-3 Inspect the Tires and Wheels (including castle nut torque)

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the tires and wheels in good condition is essential to safe operation and good performance. Tire and/or wheel failure could result in a machine tip-over. Component damage may also result if problems are not discovered and repaired in a timely fashion.

1. Check the tire surface and sidewalls for cuts, cracks, punctures and unusual wear.
2. Check each wheel for damage, bends and cracks.
3. Remove the castle nut lock plate or cotter pin and check each nut for proper torque

Castle Nut Torque, Dry	300 ft lbs	406.7 Nm
Castle Nut Torque, Lubricated	225 ft lbs	305 Nm
Wheel Nut Torque	160 ft lbs	210 Nm

Note: Always replace the cotter pin with a new one when removing the castle nut or checking the torque of the castle nut.


4. Check each lug bolt for proper torque.
5. Install the castle nut lock plate using a new lock washer OR install a new cotter pin and secure.

B-4 Check the Oil Level in the Drive Hubs

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes. Failure to maintain proper drive hub oil levels may cause the machine to perform poorly and continued use may cause component damage.

1. Drive the machine to rotate the hub until the plugs are located one on top and the other at 90 degrees.



2. Remove the plug located at 90 degrees and check the oil level.
 - **Result:** The oil level should be even with the bottom of the side plug hole.
3. If necessary, remove the top plug and add oil until the oil level is even with the bottom of the side

plug hole.

4. Apply pipe thread sealant to the plug(s), and then install the plug(s) in the drive hub.
5. Repeat this procedure for each drive hub.

NOTICE

Original oil specifications EP-90.

B-5 Test the Emergency Stop

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

A properly functioning Emergency Stop is essential for safe machine operation. An improperly operating red Emergency Stop button will fail to shut off power and stop all machine functions, resulting in a hazardous situation.

As a safety feature, selecting and operating the ground controls will override the platform controls, except the platform red Emergency Stop button.

1. Start the engine from ground controls.
2. Push in the red Emergency Stop button at the ground controls to the off position.
 - **Result:** The engine should shut off and no machine functions should operate.
3. Start the engine from platform controls.
4. Push in the red Emergency Stop button to the off position.
 - **Result:** The engine should shut off and no machine functions should operate.

Note: The red Emergency Stop button at the ground controls will stop all machine operation, even if the key switch is switched to platform control.

B-6 Test the Key Switch

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Proper key switch action and response is essential to safe machine operation. The machine can be operated from the ground or platform controls and the activation of one or the other is accomplished with the key switch. Failure of the key switch to activate the appropriate control panel could cause a hazardous operating situation.

Perform this procedure from the ground using the platform controls. Do not stand in the platform.

1. Turn the ground red Emergency Stop button clockwise to the on position. Pull out the platform red Emergency Stop button to the on position.
2. Turn the key switch to ground controls and start the engine from ground controls.
3. Check any machine function from the platform controls.
 - **Result:** The machine functions should not operate.
4. Turn the key switch to platform controls and start the engine from platform controls.
5. Check the machine functions from the ground controls.
 - **Result:** The machine functions should not operate.
6. Turn the key switch to the off position.

- **Result:** The engine should stop and no functions should operate.

B-7 Test the Automotive-style Horn

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

The horn is activated at the platform controls and sounds at the ground as a warning to ground personnel. An improperly functioning horn will prevent the operator from alerting ground personnel of hazards or unsafe conditions.

1. Start the engine from platform controls.
2. Push down the horn button at the platform controls.
 - **Result:** The horn should sound.

Note: If necessary, the horn can be adjusted to obtain the loudest volume by turning the adjustment screw near the wire terminals on the horn.

B-8 Test the Down Limit Switch

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the limit switches is essential to safe operation and good machine performance. Operating the machine with a faulty limit switch could result in reduced machine performance and a potentially unsafe operating condition.

Perform these procedures with the machine on a firm, level surface that is free of obstructions.

1. Remove the platform controls from the platform.
2. Start the engine from the platform controls.
3. Press the engine high speed idle select button.
 - **Result:** The light will turn on. The machine is functioning properly.
 - **Result:** The light will turn off, replace the down limit switch.
4. Press the Lift function select button.
5. Raise the platform 13 ft (4 m).
6. Lift the safety arm, move it to the center of the scissor arm and rotate up to a vertical position.
7. Lower the platform until the safety arm rests securely on the link. Keep clear of the safety arm when lowering the platform.



Crushing hazard. Keep hands clear of the safety arm when lowering the platform.

8. Press the roller arm of the limit switch. Activate the switch contacts.
 - **Result:** The engine high speed idle select button light will turn off when press the drive speed button. The machine is functioning properly.
 - **Result:** The engine high speed idle select button light will turn on when press the drive speed button. The machine is functioning properly.

9. Raise the platform and return the safety arm to the stowed position.
10. Lower the platform to the stowed position.

B-9 Test the Up Limit Switch

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 250 hours or quarterly, whichever comes first.

Maintaining the limit switches is essential to safe operation and good machine performance.

Operating the machine with a faulty limit switch could result in reduced machine performance and a potentially unsafe operating condition.

Perform these procedures with the machine on a firm, level surface that is free of obstructions.

1. Start the engine from the ground controls.
2. Raise the platform approximately 13 ft (4 m) from the ground controls.
3. Lift the safety arm, move it to the center of the scissor arm and rotate up to a vertical position.
4. Lower the platform until the safety arm rests securely on the link. Keep clear of the safety arm when lowering the platform.



Crushing hazard. Keep hands clear of the safety arm when lowering the platform.

5. While raising the platform from the ground controls, push in the roller of the up limit switch to activate the limit switch.
 - **Result:** The platform stops rising. The machine is functioning properly.
 - **Result:** The platform continues to rise. Adjust or replace the up limit switch.
6. Raise the platform and rotate the safety arm to the home position.
7. Lower the platform to the stowed position.

B-10 Perform Engine Maintenance

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

Engine specifications require that this procedure be performed every 400 hours.

Required maintenance procedures and additional engine information is available in the engine operator's manual.

Checklist C Procedures

C-1 Check the Down Limit Switch Height

1. Turn the key switch to platform controls. Start the engine.
2. Raise the platform approximately 10 ft (3 m).
3. Lower the platform until the down limit switch activates and the platform stops lowering.
4. Push in the red Emergency Stop button to the off position.
5. Measure the distance between the working surface and the platform deck.

3369	5 ft 10 in to 6 ft 6 in	1.8 to 2.0 m
4069	6 ft 6 in to 7 ft 3 in	2.0 to 2.2 m

C-2 Perform Engine Maintenance

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

Engine specifications require that this procedure be performed every 800 hours.

Required maintenance procedures and additional engine information is available in the engine operator's manual.

Checklist D Procedures

D-1 Replace the Hydraulic Tank Return Filter Element

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

MEC requires that this procedure be performed every 1,000 hours or annually, whichever comes first.

Replacement of the hydraulic tank return filter is essential for good machine performance and service life. A dirty or clogged filter may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require that the filter be replaced more often.



Bodily injury hazard. Beware of hot oil. Contact with hot oil may cause severe burns.

1. Remove the filter with an oil filter wrench. Clean the area where the hydraulic oil filter meets the filter head.



Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

Note: The hydraulic filter is mounted on the hydraulic tank.

2. Apply a thin layer of fresh oil to the new oil filter gasket.
3. Install the new filter and tighten it securely by hand.
4. Use a permanent ink marker to write the date and number of hours from the hour meter on the filter
5. Clean up any oil that may have spilled during the replacement procedure.
6. Turn the ground red Emergency Stop button clockwise to the on position. Pull out the platform red Emergency Stop button to the on position. Start the engine.
7. Raise the platform approximately 3 ft (1 m).
8. Inspect the filter and related components to be sure that there are no leaks.

D-2 Perform Engine Maintenance

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

Engine specifications require that this procedure be performed every 1,000 hours or annually, whichever comes first.

Required maintenance procedures and additional engine information is available in the engine operator's manual.

D-3 Replace the Drive Hub Oil


- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- Dealer service will be required to perform this procedure

MEC specifications require that this procedure be performed every 1,000 hours or annually, whichever comes first.

Replacing the drive hub oil is essential for good machine performance and service life. Failure to replace the drive hub oil at yearly intervals may cause the machine to perform poorly and continued use may cause component damage.

1. Select the drive hub to be serviced. Drive the machine until one of the two plugs is at the lowest point.
2. Remove both plugs and drain the oil into a suitable container.

3. Drive the machine until one of the two plugs is at the highest point.



4. Fill the hub until the oil level is even with the bottom of the lowest plug hole.
5. Install the plugs into the drive hub.
6. Repeat this procedure for each drive hub.

D-4 Test the Drive Brakes

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 1,000 hours or yearly, whichever comes first.

Proper brake action is essential to safe machine operation. The drive brake function should operate smoothly, free of hesitation, jerking and unusual noise. Hydraulically-released individual wheel brakes can appear to operate normally when not fully operational.

Perform this procedure with the machine on a firm level surface that is free of obstructions, with the platform extension deck fully retracted and the platform in the stowed position.

1. Mark a test line on the ground for reference.
2. Start the engine from platform controls.
3. Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the test line.
4. Slowly move the joystick in the direction indicated by the blue arrow on the control panel until the machine begins to move, then return the joystick to the center position.
 - **Result:** The machine should move in the direction that the blue arrow points on the control panel, then come to a quick stop.

5. Slowly move the joystick in the direction indicated by the yellow arrow on the control panel until the machine begins to move, then return the joystick to the center position.
 - **Result:** The machine should move in the direction that the yellow arrow points on the control panel, then come to a quick stop.
6. Bring the machine to maximum drive speed before reaching the start line. Release the function enable switch on the joystick or release the joystick when your reference point on the machine crosses the test line.
7. Measure the distance between the test line and your machine reference point.

Braking Distance, Maximum		
High range on paved surface	3 ft 3 in	1 m

Note: The brakes must be able to hold the machine on any slope it is able to climb.

D-5 Test the Drive Speed - Stowed Position

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 1,000 hours or yearly, whichever comes first.

Proper drive functions are essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation, jerking and unusual noise over the entire proportionally controlled speed range.

Perform this procedure with the machine on a firm, level surface that is free of obstructions.

1. Create start and finish lines by marking two lines on the ground 40 ft (12.2 m) apart.
2. Turn the key switch to platform controls and Turn the ground red Emergency Stop button clockwise to the on position. Pull out the platform red Emergency Stop button to the on position.
3. Start the engine from the platform controls.
4. Lower the platform to the stowed position.
5. Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
6. Bring the machine to maximum reverse drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
7. Continue at full speed and note the time when your reference point on the machine passes over the finish line. The time should be less than 8.8 sec.

D-6 Test the Drive Speed - Raised Position

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed every 1,000 hours or yearly, whichever comes first.

Proper drive functions are essential to safe machine operation. The drive function should respond quickly and smoothly to operator control. Drive performance should also be free of hesitation, jerking and unusual noise over the entire proportionally controlled speed range.

Perform this procedure with the machine on a firm, level surface that is free of obstructions.

1. Create start and finish lines by marking two lines on the ground 40 ft (12.2 m) apart.
2. Turn the key switch to platform controls and turn the ground red Emergency Stop button clockwise to the on position. Pull out the platform red Emergency Stop button to the on position.
3. Start the engine from the platform controls.
4. Raise the platform approximately 8 ft (2.4 m) from the ground.
5. Choose a point on the machine; i.e., contact patch of a tire, as a visual reference for use when crossing the start and finish lines.
6. Bring the machine to top drive speed before reaching the start line. Begin timing when your reference point on the machine crosses the start line.
7. Continue at full speed and note the time when your reference point on the machine passes over the finish line. The time should be 80 to 90 seconds.

D-7 Perform Hydraulic Oil Analysis

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- Dealer service will be required to perform this procedure.

MEC requires that this procedure be performed every 1,000 hours or yearly, whichever comes first.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.

Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary.

If the hydraulic oil is not replaced at the two year inspection, replace the oil when it fails the test. See E-1, Test or Replace the Hydraulic Oil.

D-8 Inspect the Fuel and Hydraulic Tank Cap Venting System

- Tools will be required to perform this procedure.

MEC requires that this procedure be performed yearly or every 1,000 hours, whichever comes first. Perform this procedure more often if dusty conditions exist.

A free-breathing hydraulic tank cap is essential for good machine performance and service life. A dirty or clogged cap may cause the machine to perform poorly. Extremely dirty conditions may require that the cap be inspected more often.



Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

1. Remove the breather cap from the fuel tank.
2. Check for proper venting.
 - **Result:** Air passes through the breather cap. Proceed to step 4.

- **Result:** If air does not pass through the cap, clean or replace the cap. Proceed to step 3.

Note: When checking for positive tank cap venting, air should pass freely through the cap only in one direction from the tank.

3. Using a mild solvent, carefully wash the cap venting system. Dry using low pressure compressed air. Repeat this procedure beginning with step 2.
4. Install the fuel tank cap onto the fuel tank.
5. Remove the breather cap from the hydraulic tank.
6. Check for proper venting.
 - **Result:** Air passes through the fuel tank cap. Proceed to step 8.
 - **Result:** If air does not pass through the cap, clean or replace the cap. Proceed to step 7.

Note: When checking for positive tank cap venting, air should pass freely through the cap.

7. Using a mild solvent, carefully wash the cap venting system. Dry using low pressure compressed air. Repeat this procedure beginning with step 6.
8. Install the breather cap onto the hydraulic tank.

D-9 Test the Flashing Beacons

MEC requires that this procedure be performed every 1,000 hours or yearly, whichever comes first.

Flashing beacons are used to alert operators and ground personnel of machine proximity and motion. The flashing beacons are located on both sides of the machine.

1. Turn the ground red Emergency Stop button clockwise to the on position. Pull out the platform red Emergency Stop button to the on position.
2. Turn the key switch to ground controls and start the engine from ground controls.
 - **Result:** The beacons should flash.
3. Turn the key switch to platform controls and start the engine from platform controls.
 - **Result:** The beacons should flash.

Checklist E Procedure

E-1 Test or Replace the Hydraulic Oil

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

MEC requires that this procedure be performed every 2,000 hours or every two years, whichever comes first.

Replacement or testing of the hydraulic oil is essential for good machine performance and service life. Dirty oil and suction strainers may cause the machine to perform poorly and continued use may cause component damage. Extremely dirty conditions may require oil changes to be performed more often.

Note: Before replacing the hydraulic oil, the oil may be tested by an oil distributor for specific levels of contamination to verify that changing the oil is necessary. If the hydraulic oil is not replaced at the two year inspection, test the oil annually. Replace the oil when it fails the test.

Note: When removing a hose assembly or fitting, the O-Ring (if equipped) on the fitting and/or the hose end must be replaced. All connections must be torqued to specification during installation.

1. Push in the red Emergency Stop button to the off position.
2. Tag and disconnect the harnesses from the ground control box.
3. Remove the ground control box retaining fasteners and set aside. Remove the ground control box.
4. Locate the tank cover plate. Remove the tank cover plate mounting fasteners and remove the cover.
5. Place a drain pan or other suitable container under the hydraulic tank.
6. Remove the drain plug from the hydraulic tank and completely drain the tank.



Bodily injury hazard. Spraying hydraulic oil can penetrate and burn skin. Loosen hydraulic connections very slowly to allow the oil pressure to dissipate gradually. Do not allow oil to squirt or spray.

7. Tag, disconnect and plug the suction hose from the hydraulic tank. Cap the fitting.
8. Tag, disconnect and plug the return hose at the return filter. Cap the fitting on the filter.
9. Remove the return filter and head assembly from the tank. Cap and plug the fittings.
10. Loosen the tank strap retaining fastener in front of the tank. Move the strap to the side.
11. Remove the hydraulic tank from the machine.
12. Remove the suction strainer and clean using a mild solvent or replace.
13. Clean the inside of the hydraulic tank using a mild solvent.
14. Install the drain plug using thread sealer on the threads.
15. Install the suction strainer using thread sealer on the threads.
16. Install the hydraulic tank onto the machine.
17. Secure the tank with the tank strap. Do not over tighten.
18. Install the suction hose onto the tank.

19. Install the return filter and head assembly.

Note: Replace the return filter.

20. Install the return hose to the return filter.

21. Fill the tank with hydraulic oil until the fluid is within the top 2 in (5 cm) of the sight gauge. Do not overfill.

22. Clean up any oil that may have spilled. Properly discard the oil.

23. Operate all machine functions through a full cycle and check for leaks.

24. Check the oil level in the tank and add if needed.

25. Install the tank cover plate and install the tank cover plate mounting fasteners.

E-2 Perform Engine Maintenance

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

MEC requires that this procedure be performed every 2,000 hours or every two years, whichever comes first.

Required maintenance procedures and additional engine information is available in the engine operator's manual.

E-3 Clean the Fuel Tank

- Tools will be required to perform this procedure.
- New parts will be required to perform this procedure.
- A cold engine is required before performing this procedure.

MEC requires that this procedure be performed every 2,000 hours or 2 years, whichever comes first. Removing sediment from the fuel tank is essential to good engine performance and service life. A dirty fuel tank may cause the fuel filter to clog prematurely resulting in poor engine performance and possible component damage.



Explosion and fire hazard. Engine fuels are combustible. Perform this procedure in an open, well-ventilated area away from heaters, sparks, flames and lighted tobacco. Always have an approved fire extinguisher within easy reach.

Note: Immediately clean up any fuel that may have spilled during this procedure.

1. Using an approved hand-operated pump, drain the fuel tank into a suitable container.



Explosion and fire hazard. When transferring fuel, connect a grounding wire between the machine and pump or container.

Note: Be sure to only use a hand operated pump suitable for use with gasoline and/or diesel fuel.

2. Tag, plug and remove the fuel lines from the side of the tank.
3. Loosen the tank strap retaining fastener in front of the tank. Move the strap off to the side.
4. Remove the tank from the machine.
5. Tag and remove the fuel fittings from the fuel tank.

Note: Note the orientation of the fuel fittings before removing so when the fittings are installed they will be in the correct position.

6. Rinse out the inside of the tank using a mild solvent.
7. Install the fittings (removed in step 5) into the side of the tank.
8. Install the tank onto the machine.
9. Attach the fuel lines to the tank. Tighten the clamps.
10. Secure the tank with the tank strap. Tighten the retaining fastener. Do not over tighten.

E-4 Replace the Hydraulic Tank Breather Cap


- New parts will be required to perform this procedure.

MEC requires that this procedure be performed every 2,000 hours or 2 years, whichever comes first.


The hydraulic tank is a vented-type tank. The breather cap has an internal air filter that can become clogged or, over time, can deteriorate. If the breather cap is faulty or improperly installed, impurities can enter the hydraulic system which may cause component damage. Extremely dirty conditions may require that the cap be inspected more often.

1. Remove and discard the hydraulic tank breather cap.
2. Install a new cap onto the tank.


69ERT Models - Electrical Manifold



Identification	Description	Function.
C3	Check Valve	Provides single directional flow for Load Sense Port
C4	Check Valve	Provides single directional flow for Load Sense Port
E	Shuttle Valve	Provides single directional flow for Load Sense Port from Steer
C1	Check Valve	Prevents backflow to Pump
C2	Check Valve	Prevents flow loss from Accumulator
A	Accumulator	Provides reserve flow for Axle Circuit when pump is off
R1	Relief Valve	Main System Pressure Relief
R2	Relief Valve	Limits pressure to Lift Cylinder
R3	Relief Valve	Limits pressure to Axle Circuit
R4	Relief Valve	Limits pressure to Steer Left
R5	Relief Valve	Limits pressure to Steer Right
D1	Flow Regulator	Reduces flow to Axle Circuit
D2	Flow Regulator	Reduces flow to Steer Circuit
S1	Solenoid Valve	Provides flow to platform Lift Function
S2	Solenoid Valve	Connects accumulator to Axle Circuit when energized
S3	Solenoid Valve	Controls Axle Oscillation left
S4	Solenoid Valve	Controls Axle Oscillation right
S5	Solenoid Valve	Provided flow to Axle Circuit when required
S6	Solenoid Valve	Controls Steer direction



69ERT Hydraulic Schematic



Notes

Parts Introduction

This Parts sections consists of illustrated parts sections and is designed to provide you, the customer, with illustrations and the list of associated parts needed to properly maintain the MEC self-propelled aerial work platform. When used in conjunction with the Service section in this manual and the Operator's Manual (provided separately), this manual will assist you in making necessary adjustments and repairs, and identifying and ordering the correct replacement parts.

All parts represented here are manufactured and supplied in accordance with MEC quality standards.

We recommend that you use genuine MEC parts to ensure proper operation and reliable performance.

To obtain maximum benefits from your MEC Aerial Work Platforms, always follow the proper operating and maintenance procedures. Only trained authorized personnel should be allowed to operate or service this machine. Service personnel should read and study the Operator's, and the Service and Parts Manuals in order to gain a thorough understanding of the unit prior to making any repairs.

Steer Axle Assembly Installation




ILLUSTRATION No.
Art_5442


69ERT Series

Steer Axle Assembly Installation

Item	Part Number	Description	Qty.
1	43006	Frame Weldment	1
2	43007	Pin	1
3	41431	Pin	1
4	50002	WSHR M10 Standard Flat	1
5	53054	WSHR M10 Spring Washer	1
6	50034	HHCS M10 × 30	1
7	REF	Left Oscillate Cylinder Assembly (Refer to page 115)	1
8	43008	Washer	2
9	41105	Bearing	2
10	43009	Pin	4
11	42449	Pin	6
12	50000	WSHR M6 Standard Flat	6
13	53046	WSHR M6 Spring Washer	6
14	50445	HHCS M6 × 16	6
15	REF	Steer Axle Assembly (Refer to page 40)	1
16	REF	Right Oscillate Cylinder Assembly (Refer to page 114)	1

REF - Reference

Steer Axle Assembly



Item	Part Number	Description	Qty.
1	50332	HHCS M10 × 35	4
2	53054	WSHR M10 Spring Washer	4
3	50002	WSHR M10 Standard Flat	4
4	43024	Pin	4
5	43025	Pin	4
6	43026	Steer Axle Weldment	1
7	43017	Bearing	4
8	50445	HHCS M6 × 16	16
9	53046	WSHR M6 Spring Washer	16
10	50000	WSHR M6 Standard Flat	16
11	42449	Pin	4
12	43021	Pin	4
13	43018	Clevis Yoke	1
14	43019	Adjusting Screw	1
15	REF	Steer Cylinder Assembly (Refer to page 116)	1
16	53169	NHEX M24 × 40	1
17	43020	Tie Rod Weldment	1
18	43016	Bearing	4
19	43062	Steer Yoke Weldment	2
20	53250	Castle Nut M36 × 4mm	2
21	43063	Seal Washer	2
22	43064	Cap	2
23	43022	Right Front Non-Marking Wheel	1
	43833	Tire/Wheel, Black, Right Front	1
24	53213	NNYL Flange M18 × 1.5	16
25	43527	Washer	2
26	43483	Bearing	2
27	43013	Bolt	16
28	43484	Hub	2
29	43485	Bearing	2
30	43486	Seal	2
31	43487	Cotter Pin	2
32	43010	Left Front Non-Marking Wheel	1
	43832	Tire/Wheel, Black, Left Front	1

REF - Reference

Rear Axle Assembly Installation




ILLUSTRATION No.
Art_5450

69ERT Series

Rear Axle Assembly Installation



Item	Part Number	Description	Qty.
1	43006	Frame Weldment	1
2	43008	Washer	4
3	41105	Bearing	4
4	REF	Right Rear Wheel Assembly (Refer to page 44)	2
5	REF	Left Rear Wheel Assembly (Refer to page 46)	1
6	50034	HHCS M10 × 30	2
7	53054	WSHR M10 Spring Washer	2
8	50002	WSHR M10 Standard Flat	2
9	41431	Pin	2
10	43027	Pin	2

REF - Reference

Right Rear Wheel Assembly




ILLUSTRATION No.
Art_5451

69ERT Series

Right Rear Wheel Assembly

Item	Part Number	Description	Qty.
1	43488	Bumper	1
2	43032	Adjusting Plate	1
3	50285	NNYL M4	8
4	50284	WSHR M4 Standard Flat	4
5	50040	HHCS M12 × 35	2
6	53148	WSHR M12 Spring Washer	2
7	50003	WSHR M12 Standard Flat	2
8	50284	WSHR M4 Standard Flat	8
9	43030	Switch Plate	2
10	53113	SHCS M4 × 16	4
11	43031	Limit Switch	2
12	53115	SHCS M4 × 25	4
13	50266	NLUG 5/8-18	9
14	43038	Right Rear Non-Marking Wheel	1
	43830	Tire/Wheel, Black, Right Rear	1
15	43489	Motor, Drive Assy	1
--	46643	Reducer	1
--	46642	Motor	1
--	46644	Brake	1
16	43490	Rear Motor Housing Weldment	1
17	43491	Cover	1
18	43037	Nut	2
19	50028	HHCS M6 × 20	2
20	53046	WSHR M6 Spring Washer	2
21	50000	WSHR M6 Standard Flat	2
22	50478	HHCS 5/8-11 × 2	8
23	53149	WSHR M16 Spring Washer	8
24	50004	WSHR M16 Standard Flat	8

Left Rear Wheel Assembly




ILLUSTRATION No.
Art_5452

69ERT Series

Left Rear Wheel Assembly

Item	Part Number	Description	Qty.
1	43028	Left Rear Non-Marking Wheel	1
	43831	Tire/Wheel, Black, Left Rear	1
2	50266	NLUG 5/8-18	9
3	43489	Motor, Drive Assy	1
--	46643	Reducer	1
--	46642	Motor	1
--	46644	Brake	1
4	50003	WSHR M12 Standard Flat	2
5	53148	WSHR M12 Spring Washer	2
6	50040	HHCS M12 × 35	2
7	50285	NNYL M4	8
8	50284	WSHR M4 Standard Flat	4
9	43030	Switch Plate	2
10	50284	WSHR M4 Standard Flat	8
11	53113	SHCS M4 × 16	4
12	43031	Limit Switch	2
13	53115	SHCS M4 × 25	4
14	43032	Adjusting Plate	1
15	43488	Bumper	1
16	50478	HHCS 5/8-11 × 2	8
17	50004	WSHR M16 Standard Flat	8
18	53149	WSHR M16 Spring Washer	8
19	43490	Rear Motor Housing Weldment	1
20	43491	Cover	1
21	43037	Nut	2
22	50028	HHCS M6 × 20	2
23	53046	WSHR M6 Spring Washer	2
24	50000	WSHR M6 Standard Flat	2

Hydraulic Module Installation




ILLUSTRATION No.
Art_5453

69ERT Series

Hydraulic Module Installation



Item	Part Number	Description	Qty.
1	43492	Hydraulic Module Weldment	1
2	50003	WSHR M12 Standard Flat	6
3	50050	NNYL M12	4
4	43006	Frame Weldment	1
5	50000	WSHR M6 Standard Flat	4
6	50047	NNYL M6	2
7	43048	Lock	1
8	50214	HHCS M6 × 30	2
9	50003	WSHR M12 Standard Flat	2
10	50040	HHCS M12 × 35	4

Hydraulic Module Door Installation




ILLUSTRATION No.
Art_5454


69ERT Series

Hydraulic Module Door Installation

Item	Part Number	Description	Qty.
1	43493	Left Door	1
2	43057	Gas Shock	2
3	50048	NNYL M8	8
4	43058	Gas Shock Bracket	1
5	50031	HHCS M8 × 25	4
6	50001	WSHR M8 Standard Flat	8
7	43135	Hinge	1
8	50047	NNYL M6	40
9	50000	WSHR M6 Standard Flat	80
10	53231	PHMS M6 × 16	40
11	REF	Hydraulic Module Assembly (Refer to page 52)	1
12	43056	Gas Shock Bracket	1
13	43054	Hinge	1
14	43053	Magnet	2
15	43052	Control Door Plate	1
16	43050	Latch	1
17	53038	WSHR M5 Standard Flat	4
18	53043	WSHR M5 Spring Washer	4
19	53219	THMS M5 × 20	4

REF - Reference

Hydraulic Module Assembly



Item	Part Number	Description	Qty.
1	43442	Beacon	1
2	53124	SHCS M6 × 20	3
3	50000	WSHR M6 Standard Flat	15
4	50047	NNYL M6	15
5	REF	Function Manifold Assembly (Refer to page 54)	1
6	50038	HHCS M12 × 25	6
7	53148	WSHR M12 Spring Washer	9
8	50003	WSHR M12 Standard Flat	6
9	43492	Hydraulic Module Weldment	1
10	50048	NNYL M8	2
11	50001	WSHR M8 Standard Flat	6
12	--	--	--
13	--	--	--
14	--	--	--
15	REF	Ground Control Box Assembly (Refer to page 62)	1
16	53231	PHMS M6 × 16	6
17	43069	Hinge	1
18	REF	Hydraulic Tank Assembly (Refer to page 64)	1
19	43070	Rubber Pad	1
20	43071	Tank Strap	1
21	41112	Hydraulic Hoses Manifolds	1
22	43068	Hose (4069) (To Lower Lift Cylinder)	1
23	43067	Hose (4069) (To Upper Lift Cylinder)	1
24	50386	CSCS M6 × 25 4069ERT	2
25	43066	Hose (4069) (To Hydraulic Tank)	1
26	53055	WSHR M8 Spring Washer	4
27	53210	SHCS M8 × 25	4
28	REF	Pump Assembly (Refer to page 66)	1
29	50049	NNYL M10	2
30	50002	WSHR M10 Standard Flat	2
31	50002	WSHR M10 Standard Flat	2
32	50034	HHCS M10 × 30	2
33	REF	Filter Assembly (Refer to page 68)	1
34	REF	Outtrigger Manifold Assembly (Option) (Refer to page 60)	1
35	43494	Counterweight	1
36	53108	HHCS M12 × 65	3
37	50003	WSHR M12 Standard Flat	6
38	50050	NNYL M12	3

REF - Reference

Function Manifold Assembly




ILLUSTRATION No.
Art_5444

69ERT Series

Function Manifold Assembly



Item	Part Number	Description	Qty.
1	50033	HHCS M10 × 25	4
2	53054	WSHR M10 Spring Washer	4
3	50002	WSHR M10 Standard Flat	4
4	43044	Function Manifold Bracket	1
5	43045	Pressure Switch	1
6	43545	Function Manifold (Refer to page 56) 3369ERT (Serial #13200100 - 13200200) 4069ERT (Serial #13700100 - 13700242)	1
	45196	Function Manifold (Refer to page 58) 3369ERT (From Serial #13200201) 4069ERT (From Serial #13700243)	1
7	43085	Straight Fitting	1
8	43076	Straight Fitting	4
9	43124	Plug (Model Without Outriggers)	1
10	43078	Tee Fitting	2
11	43081	Tee Fitting	1
12	43077	Elbow	2
13	43082	Elbow	1
14	43267	Straight Fitting	1
15	43083	Straight Fitting (Model Without Outriggers)	1
		Straight Fitting (Model With Outriggers)	2

Function Manifold - ERT Models

3369ERT Serial #13200100 - 13200200 / 4069ERT Serial # 13700100 - 13700242




ILLUSTRATION No.
Art_5448

69ERT Series

Function Manifold

Item	Part Number	Description	Qty.
1	43469	Accumulator (A)	1
2	42480	Plug	2
3	43470	Valve Body	1
4	43429	Orifice	1
5	43471	Flow Control Valve (D1)	1
6	43472	Relief Valve (R3)	1
7	43473	Relief Valve (R4 R5)	2
8	43418	Check Valve (C3 C4)	2
9	42821	Plug	21
10	43402	Flow Control Valve (D2)	1
11	43419	Shuttle Valve (E)	1
12	43474	Nut	5
13	43475	Coil	6
14	43420	Solenoid Valve Spool (S6)	1
15	43407	Solenoid Valve Spool (S5)	1
16	43476	Coil	1
17	43477	Nut	1
18	43478	Solenoid Valve Spool (S2 S3 S4)	3
19	43479	Solenoid Valve Spool (S1)	1
20	43397	Relief Valve (R2)	1
21	43480	Relief Valve (R1)	1
22	43434	Plug	1
23	43439	Check Valve (C1 C2)	2
24	43119	Plug	1
25	43079	Plug	2

Function Manifold - ERT Models

3369ERT From Serial #13200201 / 4069ERT From Serial #13700243





ILLUSTRATION No.
Art_5448

69ERT Series

Function Manifold


Item	Part Number	Description	Qty.
1	46676	Accumulator (A)	1
2	42480	Plug	2
3	46677	Valve Body	1
4	43429	Orifice	1
5	43471	Flow Control Valve (D1)	1
6	43472	Relief Valve (R3)	1
7	46678	Relief Valve (R4, R5)	2
8	43418	Check Valve (C3, C4)	2
9	42821	Plug	22
10	43402	Flow Control Valve (D2)	1
11	43419	Shuttle Valve (E)	1
12	43414	Nut	2
13	43413	Coil	3
14	43420	Solenoid Valve Spool (S6)	1
15	43407	Solenoid Valve Spool (S5)	1
16	43406	Coil	1
17	43405	Nut	1
18	43478	Solenoid Valve Spool (S2, S3, S4)	3
19	45197	Coil	3
20	43474	Nut	3
21	43479	Solenoid Valve Spool (S1)	1
22	46679	Relief Valve (R2)	1
23	46680	Proportional Relief Valve (R1)	1
24	43410	Coil	1
25	43411	Nut	1
26	43434	Plug	2
27	43439	Check Valve (C1, C2)	2
28	43119	Plug	1
29	43079	Plug	2

Outrigger Manifold Assembly




Item	Part Number	Description	Qty.
1	50030	HHCS M8 × 20	3
2	53055	WSHR M8 Spring Washer	3
3	50001	WSHR M8 Standard Flat	3
4	43461	Outrigger Manifold Bracket	1
5	43083	Straight Fitting	4
6	43462	Outrigger Manifold	1
--	43463	Solenoid Valve	1
--	43464	Relief Valve	1
--	43465	Plug	1
7	43082	Elbow	1

Ground Control Box Assembly




Item	Part Number	Description	Qty.
1	49692	Controller ECU, Early (3369ERT - To Serial #13200034) (4069ERT - To Serial #13700034)	1
	42779	Controller ECU, Late (3369ERT - From Serial #13200035) (4069ERT - From Serial #13700035)	1
2	53038	WSHR M5 Standard Flat	6
3	50524	NNYL M5	4
4	43524	Decal, Ground Control Panel - Early (3369ERT - To Serial #13200034) (4069ERT - To Serial #13700034)	1
	42780	Decal, Ground Control Panel - Late (3369ERT - From Serial #13200035) (4069ERT - From Serial #13700035)	1
5	53220	PHMS M4 × 6 Bolt	4
6	43088	Terminal Strip 6	1
7	43093	Terminal Strip Base	2
8	53221	CSCS M4 × 16 Bolt	4
9	41334	Relay	4
10	53222	PHMS M5 × 8 Bolt	4
11	43496	Resistor Bracket	1
12	53043	WSHR M5 Spring Washer	2
13	53044	SHMS M5 × 10 Bolt	2
14	43497	Resistor	2
15	53076	PHMS M3 × 6 Bolt	4
16	50284	WSHR M4 Standard Flat	2
17	53062	WSHR M4 Spring Washer	2
18	53241	BHCS M4 × 16 Bolt	2
19	43498	PWM Convertor Module	1
20	43092	Terminal Strip 9	1
21	42352	Latch, Column	1
22	43499	Emergency Stop Switch	1
--	43096	NC Contact	1
--	43097	Base With 1 NC Contact	1
--	43098	Red Mushroom Head	1
23	43500	Circuit Breaker	1
24	43102	Decal, Key Switch Panel	1
25	41418	Key Switch	1
--	43100	Key	1
26	43501	Curtis Display	1
27	53219	THMS M5 × 20 Bolt	4
28	43502	Ground Control Box Weldment	1

Hydraulic Tank Assembly



Item	Part Number	Description	Qty.
1	41413	Nut	1
2	41167	Fitting	1
3	53215	WSHR M13 Standard Flat	2
4	41166	Fitting	1
5	42055	Air Cleaner	1
6	50359	SHCS M5 × 16	8
7	53043	WSHR M5 Spring Washer	8
8	50028	HHCS M6 × 20	20
9	53046	WSHR M6 Spring Washer	20
10	50000	WSHR M6 Standard Flat	20
11	43107	Cover Weldment	1
12	43108	Gasket	1
13	43109	Filler Cap	1
14	43110	Filter Web	1
15	43111	Level Gauge	1
16	43112	Elbow	2
17	43085	Straight Fitting	2
18	43113	Return Filter	1
--	42837	Filter Element	1
19	53038	WSHR M5 Standard Flat	4
20	43115	Tee Fitting (Model With Outriggers)	1
21	43114	Pipe	1
22	43268	Straight Fitting (Model With Outriggers)	1
23	43119	Plug	2
24	43120	Plug	1
25	43331	Straight Fitting	1
26	43121	Flange	1
27	43122	O-Ring	1
28	43123	Strainer	1
29	43124	Plug	1
30	43125	Hydraulic Tank Weldment	1

Pump Assembly



Item	Part Number	Description	Qty.
1	43346	Motor	1
2	43122	O-Ring	1
3	43354	Gear Pump	1
4	43451	Straight Fitting	1
5	50034	HHCS M10 × 30	2
6	53054	WSHR M10 Spring Washer	2
7	50002	WSHR M10 Standard Flat	2
8	43455	Straight Fitting	1
9	43456	Elbow	1
10	43457	Motor Bracket	1
11	50001	WSHR M8 Standard Flat	4
12	53055	WSHR M8 Spring Washer	4
13	50031	HHCS M8 × 25	4

Filter Assembly




ILLUSTRATION No.
Art_5446

69ERT Series

Filter Assembly



Item	Part Number	Description	Qty.
1	50033	HHCS M10 × 25	2
2	53054	WSHR M10 Spring Washer	2
3	50002	WSHR M10 Standard Flat	2
4	43458	Filter Bracket	1
5	43454	High Pressure Line Filter	1
--	47188	Element, Filter	1
6	43459	Elbow	1
7	43460	Straight Fitting	2

Battery Module Installation





ILLUSTRATION No.
Art_5458

69ERT Series

Battery Module Installation

Item	Part Number	Description	Qty.
1	43006	Frame Weldment	1
2	50050	NNYL M12	4
3	50003	WSHR M12 Standard Flat	6
4	50000	WSHR M6 Standard Flat	4
5	50047	NNYL M6	2
6	43048	Lock	1
7	50214	HHCS M6 × 30	2
8	43503	Battery Module Weldment	1
9	50040	HHCS M12 × 35	4
10	50003	WSHR M12 Standard Flat	2

Battery Module Door Installation



Item	Part Number	Description	Qty.
1	43135	Hinge	1
2	REF	Battery Module Assembly (Refer to page 74)	1
3	50048	NNYL M8	10
4	50001	WSHR M8 Standard Flat	12
5	50031	HHCS M8 × 25	6
6	43133	Gas Shock Bracket	1
7	43057	Gas Shock	2
8	43132	Right Door	1
9	43050	Latch	1
10	53219	THMS M5 × 20	4
11	53043	WSHR M5 Spring Washer	4
12	53038	WSHR M5 Standard Flat	4
13	53231	PHMS M6 × 16	34
14	50000	WSHR M6 Standard Flat	68
15	43134	Gas Shock Bracket	1
16	50047	NNYL M6	34

REF - Reference

Battery Module Assembly




ILLUSTRATION No.
Art_5460

69ERT Series


Battery Module Assembly



Item	Part Number	Description	Qty.
1	50047	NNYL M6	13
2	50000	WSHR M6 Standard Flat	13
3	53124	SHCS M6 × 20	3
4	43442	Beacon	1
5	53092	NNYL M3	2
6	43504	Charger Display	1
7	43505	Display Bracket	1
8	53214	THMS M3 × 10	2
9	43503	Battery Module Weldment	1
10	53219	THMS M5 × 20	8
11	50524	NNYL M5	8
12	53038	WSHR M5 Standard Flat	10
13	43141	Half-Round Batten	4
14	43506	Charger	1
15	50028	HHCS M6 × 20	4
16	50000	WSHR M6 Standard Flat	4
17	43507	Battery Keeper Plate	3
18	50001	WSHR M8 Standard Flat	16
19	50048	NNYL M8	16
20	43508	Threaded Rod	6
21	50332	HHCS M10 × 35	4
22	50002	WSHR M10 Standard Flat	4
23	50002	WSHR M10 Standard Flat	4
24	50049	NNYL M10	4
25	43509	Battery Box Weldment	1
26	43510	Battery	8
27	50001	WSHR M8 Standard Flat	4
28	REF	Motor Controller Assembly (Refer to page 76)	1
29	42071	Switch, Emergency	1
30	--	--	--
31	--	--	--
32	--	--	--
33	53224	THMS M5 × 12	2
34	53043	WSHR M5 Spring Washer	2
35	50032	HHCS M8 × 30	4
36	43511	DC Power Supply	1
37	50576	SHCS M4 × 12	4
38	53062	WSHR M4 Spring Washer	4
39	50284	WSHR M4 Standard Flat	4

REF - Reference

Motor Controller Assembly



Item	Part Number	Description	Qty.
1	43512	Mounting Plate	1
2	43513	Motor Controller	2
3	50000	WSHR M6 Standard Flat	8
4	53046	WSHR M6 Spring Washer	10
5	53197	SHCS M6 × 25	8
6	41092	Fuse Seat	1
7	53062	WSHR M4 Spring Washer	4
8	53185	PHMS M4 × 20	4
9	43515	Copper Bar 3	1
10	43516	350A Fuse Assembly	1
--	43517	350A Fuse	1
11	50445	HHCS M6 × 16	2
12	50000	WSHR M6 Standard Flat	2
13	43518	DC Contactor	1

Outriggers and Ladder Installation




ILLUSTRATION No.
Art_5462


69ERT Series

Outriggers and Ladder Installation

Item	Part Number	Description	Qty.
1	REF	Outrigger Assembly (Option) (Refer to page 80)	2
2	43222	Outrigger Mount Plate	4
3	50005	WSHR M20 Standard Flat	48
4	50052	NNYL M20	24
5	43006	Frame Weldment	1
6	43219	Counterweight (4069ERT Without Outriggers)	1
7	43220	Cover (4069ERT Without Outriggers)	1
8	50003	WSHR M12 Standard Flat	13
9	50050	NNYL M12	4
10	43218	Counterweight	1
11	43214	Ladder (3369 With Outriggers)	1
	43215	Ladder (3369 Without Outriggers)	1
	43216	Ladder (4069 With Outriggers)	1
	43217	Ladder (4069 Without Outriggers)	1
12	50035	HHCS M10 × 40	6
13	50002	WSHR M10 Standard Flat	6
14	50002	WSHR M10 Standard Flat	6
15	50049	NNYL M10	6
16	53207	SHCS M6 × 30	8
17	53046	WSHR M6 Spring Washer	8
18	43221	Hose Clamp	8
19	43223	Outrigger Mount Plate	4
20	50488	HHCS M20 × 70	24
21	50040	HHCS M12 × 35	2
22	53148	WSHR M12 Spring Washer	5
23	53247	HHCS M12 × 40	3
24	43519	Counterweight	1

REF - Reference


Outrigger Assembly (Option)



Item	Part Number	Description	Qty.
1	43224	Outrigger Housing	2
2	43225	Cover	2
3	43226	Cover	2
4	50000	WSHR M6 Standard Flat	12
5	53046	WSHR M6 Spring Washer	16
6	53138	SHCS M6 × 16	16
7	50000	WSHR M6 Standard Flat	4
8	43227	Switch Bracket	2
9	43228	Limit Switch	2
10	43233	Outrigger Yoke	1
11	43234	Screw	8
12	REF	Outrigger Cylinder Assembly (Refer to page 118)	2
13	50003	WSHR M12 Standard Flat	8
14	50050	NNYL M12	8
15	50002	WSHR M10 Standard Flat	8
16	53054	WSHR M10 Spring Washer	8
17	50215	HHCS M10 × 20	8
18	53154	HHCS M8 × 16	12
19	53055	WSHR M8 Spring Washer	12
20	50001	WSHR M8 Standard Flat	12

REF - Reference


Chassis Accessory Installation



Item	Part Number	Description	Qty.
1	43037	Nut	13
2	50000	WSHR M6 Standard Flat	18
3	53046	WSHR M6 Spring Washer	27
4	50445	HHCS M6 × 16	22
5	43235	Cover	1
6	50048	NNYL M8	2
7	50001	WSHR M8 Standard Flat	2
8	50048	NNYL M8	1
9	43236	Cover	1
10	43520	Hose Clamp	1
11	41415	Base Plate	1
12	50015	HHCS M8 × 50	1
13	43006	Frame Weldment	1
14	50001	WSHR M8 Standard Flat	2
15	50031	HHCS M8 × 25	2
16	43238	Switch Bracket	1
17	42402	Limit Switch	1
18	53038	WSHR M5 Standard Flat	4
19	53043	WSHR M5 Spring Washer	6
20	53116	SHCS M5 × 12	6
21	43522	Cover	2
22	50000	WSHR M6 Standard Flat	9
23	43239	Ground Strap	1
24	50028	HHCS M6 × 20	3
25	50214	HHCS M6 × 30	2
26	REF	Electrical Accessory Assembly (Refer to page 84)	1
27	43240	Cover	1

REF - Reference

Electrical Accessory Assembly



Item	Part Number	Description	Qty.
1	53116	SHCS M5 × 12	2
2	53038	WSHR M5 Standard Flat	2
3	53043	WSHR M5 Spring Washer	2
4	43241	Tilt Sensor	1
5	43242	Mounting Plate	1
6	42882	Alarm	1
7	50445	HHCS M6 × 16	3
8	53046	WSHR M6 Spring Washer	3
9	50000	WSHR M6 Standard Flat	3
10	41075	Horn	1

Scissor Assembly - 3369




ILLUSTRATION No.
Art_5422

69 Series

Scissor Assembly - 3369



Item	Part Number	Description	Qty.
1	43244	Platform Slider	2
2	50049	NNYL M10	12
3	50352	HHCS M10 × 80	12
4	43245	Pin	4
5	41105	Bearing	24
6	43246	Spacer Sleeve 2	4
7	43247	Washer	12
8	43248	Circlips	12
9	43249	Bearing	4
10	43250	Spacer Sleeve 1	2
11	43251	Platform Pivot Weldment	1
12	43252	Outer Arm 4	1
13	50332	HHCS M10 × 35	2
14	43253	Washer	2
15	43254	Outer Arm 3	1
16	43255	Inner Arm 3	1
17	43256	Outer Arm 2	1
18	43257	Inner Arm 2	1
19	REF	Lower Lift Cylinder Assembly (Refer to page 110)	1
20	43258	Hose	1
21	43259	Outer Arm 1	1
22	43546	Hose Clamp Assembly (Refer to page 92)	1
23	43260	Bearing	2
24	50050	NNYL M12	6
25	50003	WSHR M12 Standard Flat	12
26	43261	Switch Bracket	1
27	50352	HHCS M10 × 80	2
28	43262	Pin	2
29	43263	Pin	2
30	43264	Chassis Link Pivot Weldment	1
31	43265	Switch Bracket	1
32	50215	HHCS M10 × 20	2
33	50023	HHCS M12 × 50	6
34	42074	Limit Switch	2
35	53065	SHCS M4 × 30	4
36	53113	SHCS M4 × 16	4
42	REF	Slider Assembly (Refer to page 91)	2
43	43269	Pin	4
44	41431	Pin	6
45	50033	HHCS M10 × 25	6
46	43270	Inner Arm 1	1
47	41114	Block	24
48	50049	NNYL M10	4
49	43272	Safety Arm Bushing	2
50	43273	Safety Arm	2
51	43274	Pin	8
52	43275	Pin	2
53	43276	Inner Arm 4	1

REF - Reference

Scissor Assembly - 4069




ILLUSTRATION No.
Art_5423

69 Series


Scissor Assembly - 4069

Item	Part Number	Description	Qty.
1	43244	Platform Slider	2
2	43276	Inner Arm 4	1
3	50049	NNYL M10	20
4	50352	HHCS M10 × 80	16
5	43245	Pin	6
6	41105	Bearing	32
7	43246	Spacer Sleeve 2	6
8	43247	Washer	16
9	43248	Circlips	16
10	43249	Bearing	4
11	43250	Spacer Sleeve 1	2
12	43251	Platform Pivot Weldment	1
13	43252	Outer Arm 4	1
14	43274	Pin	10
15	50332	HHCS M10 × 35	3
16	43253	Washer	3
17	43275	Pin	3
18	43277	Outer Arm 3	1
19	43278	Inner Arm 3	1
20	43256	Outer Arm 2	1
21	43257	Inner Arm 2	1
22	REF	Lower Lift Cylinder Assembly (Refer to page 110)	1
23	43546	Hose Clamp Assembly (Refer to page 92)	1
24	43270	Inner Arm 1	1
25	43260	Bearing	2
26	50050	NNYL M12	6
27	50003	WSHR M12 Standard Flat	12
28	43261	Switch Bracket	1
29	50352	HHCS M10 × 80	2
30	43262	Pin	2
31	43263	Pin	2
32	43264	Chassis Link Pivot Weldment	1
33	43265	Switch Bracket	1
34	50215	HHCS M10 × 20	2
35	50023	HHCS M12 × 50	6
36	42074	Limit Switch	2
37	53065	SHCS M4 × 30	4
38	53113	SHCS M4 × 16	4
39	--	--	--
40	--	--	--
41	--	--	--
42	--	--	--
43	--	--	--
44	REF	Slider Assembly (Refer to page 91)	2
45	43259	Outer Arm 1	1

46	43269	Pin	4
47	41431	Pin	7
48	50033	HHCS M10 × 25	6
49	43547	Hose Clamp Assembly - 4069 (Refer to page 93)	2
50	41114	Block	32
51	50049	NNYL M10	4
52	43272	Safety Arm Bushing	2
53	43273	Safety Arm	2
54	43279	Pin	1
55	REF	Upper Lift Cylinder Assembly (Refer to page 112)	1
56	50002	WSHR M10 Standard Flat	4
57	53230	CSCS M10 × 40	4
58	43280	Pin Fixing Plate	2
59	43281	Outer Arm 4	1
60	43282	Inner Arm 4	1

REF - Reference


Slider Assembly



Item	Part Number	Description	Qty.
1	50047	NNYL M6	2
2	53226	CSCS M6 × 16	4
3	43283	Upper Slider	2
4	43284	Slider Foot Weldment	1
5	41105	Bearing	2
6	43285	Lower Slider	1
7	50289	HHCS M6 × 40	2




Hose Clamp Assembly



Item	Part Number	Description	Qty.
1	50014	HHCS M8 × 40	2
2	53055	WSHR M8 Spring Washer	2
3	50001	WSHR M8 Standard Flat	2
4	43286	Base Plate	1
5	43287	Hose Clamp	2



Hose Clamp Assembly - 4069



Item	Part Number	Description	Qty.
1	50048	NNYL M8	1
2	50001	WSHR M8 Standard Flat	1
3	43288	Hose Clamp	2
4	43289	Base Plate	1
5	50057	HHCS M8 × 45	1

Main Platform Assembly




ILLUSTRATION No.
Art_5427


69 Series

Main Platform Assembly

Item	Part Number	Description	Qty.
1	43290	Right Main Rail	1
2	43291	Right Door Rail	1
3	41127	Hinge A	1
4	53227	HHCS M6 × 14	21
5	41128	Hinge B	1
6	43294	Entry Gate	1
7	50021	HHCS M10 × 55	1
8	41125	Spring	1
9	41124	Latch Handle	1
10	50049	NNYL M10	1
11	43297	Left Door Rail	1
12	43298	Lock Pin	2
13	53067	SHCS M5 × 40	2
14	50524	NNYL M5	2
15	43299	Inserted Pin Rod	2
16	43300	Left Main Rail	1
17	53129	SHCS M8 × 60	8
18	50048	NNYL M8	8
19	43301	Rivet	50
20	43302	Main Platform Deck Plate 1	2
21	43303	Main Deck Weldment	1
22	43304	Main Platform Deck Plate 2	1
23	REF	Support Roller Assembly (Refer to page 96)	1
24	REF	Side Roller Assembly (Refer to page 98)	4
25	43305	Adjusting Plate	4
26	REF	Support Roller Assembly (Refer to page 96)	1
27	50040	HHCS M12 × 35	10
28	50050	NNYL M12	12
29	41059	Wire Clip	4
30	53113	SHCS M4 × 16	4
31	43307	Extension Deck Lock Tooth	1
32	43308	Roller Track	2
33	53228	BHCS M6 × 10	16

REF - Reference

Support Roller Assembly



Item	Part Number	Description	Qty.
1	43309	Pin	1
2	43310	Roller Bracket 2	1
3	43311	Shim	2
4	41131	Bearing	2
5	43312	Roller	1
6	43313	Roller Bracket	1
7	50051	NNYL M16	1

Side Roller Assembly




ILLUSTRATION No.
Art_5429

69 Series

Side Roller Assembly

Item	Part Number	Description	Qty.
1	43314	Pin	1
2	43315	Roller Bracket	1
3	50048	NNYL M8	1
4	50002	WSHR M10 Standard Flat	2
5	43316	Bearing	2
6	43317	Roller	1

Platform Extension Assembly




ILLUSTRATION No.
Art_5430

69 Series


Platform Extension Assembly

Item	Part Number	Description	Qty.
1	43318	Front Rail	1
2	53223	THMS M5 × 16	4
3	50524	NNYL M5	9
4	43319	Manual Box	1
5	43320	Bumper	2
6	53129	SHCS M8 × 60	6
7	50048	NNYL M8	12
8	43322	Right Extension Rail	1
9	50383	HHCS M10 × 70	4
10	50049	NNYL M10	10
11	50047	NNYL M6	9
12	43323	Catch Clip	1
13	50000	WSHR M6 Standard Flat	1
14	50117	HHCS M6 × 25	1
15	REF	Platform Locking Device Assembly (Refer to page 103)	1
16	41120	Bumper	2
17	53179	HHCS M5 × 20	3
18	50332	HHCS M10 × 35	4
19	43325	Locating Plate 1	1
20	43326	Lock Tooth Seat	1
21	43327	Lock Tooth	1
22	50031	HHCS M8 × 25	2
23	43328	Lock Seat	1
24	50039	HHCS M12 × 30	2
25	50050	NNYL M12	2
26	43329	Extension Deck Weldment	1
27	43330	Platform Extension Deck Plate 1	1
28	50051	NNYL M16	1
29	REF	Roller Assembly (Refer to page 104)	2
30	50018	HHCS M8 × 80	6
31	REF	Side Roller Assembly (Refer to page 98)	4
32	50226	BHCS M6 × 65	8
33	43332	Washer	2
34	41131	Bearing	4
35	43333	Roller	2
36	43334	Roller Bracket	1
37	43335	Pin	1
38	43336	Locating Plate 2	1
39	43337	Lock Pin	1
40	53224	THMS M5 × 12	1
41	43338	Platform Extension Deck Plate 2	1
42	43301	Rivet	47
43	43339	Rail Spacer	2
44	50294	HHCS M6 × 45	2
45	50047	NNYL M6	10

46	43340	Inserted Pin	2
47	43341	Left Extension Rail	1
48	43299	Inserted Pin Rod	2
49	53067	SHCS M5 × 40	2
50	43298	Lock Pin	2
51	53227	HHCS M6 × 14	4


REF - Reference

Platform Locking Device Assembly




Item	Part Number	Description	Qty.
1	43342	Tie Rod Weldment	1
2	50021	HHCS M10 × 55	1
3	43343	Connection Rod	1
4	50383	HHCS M10 × 70	4
5	43344	Roller Bracket	1
6	41131	Bearing	2
7	43333	Roller	1
8	43345	Pin	1
9	50049	NNYL M10	2
10	43348	Cover	3
11	43347	Handle	1

Roller Assembly



Item	Part Number	Description	Qty.
1	43349	Roller Bracket	1
2	50297	BHCS M10 × 25	2
3	43350	Washer	2
4	41131	Bearing	2
5	43351	Roller	1
6	43352	Pin	1

Platform Control and Sheet Material Tray



Item	Part Number	Description	Qty.
1	53248	CARB M8 × 45	1
2	43321	Platform Control Box Mount Bracket	1
3	43548	Platform Control Box Assembly (Refer to page 108)	1
4	42500	Locating Plate	1
5	43453	Handle	1
6	50048	NNYL M8	1
7	53231	PHMS M6 × 16	4
8	50040	HHCS M12 × 35	2
9	50050	NNYL M12	4
10	50049	NNYL M10	4
11	50002	WSHR M10 Standard Flat	4
12	50033	HHCS M10 × 25	4
13	42880	Sheet Material Tray	1
14	53247	HHCS M12 x 40	2

Platform Control Box Assembly




ILLUSTRATION No.
Art_5433

69 Series

Platform Control Box Assembly



Item	Part Number	Description	Qty.
1	43353	Joystick	1
2	43525	Decal, Platform Control Panel	1
3	43355	Enclosure	1
4	41568	Alarm	1
5	43357	Main Board	1
6	43358	Cover Bottom	1
7	41157	Emergency Stop Switch	1

Lower Lift Cylinder Assembly




ILLUSTRATION No.
Art_5434

69 Series

Lower Lift Cylinder Assembly

Item	Part Number	Description	Qty.
1	43360	Lower Lift Cylinder	1
2	43361	Washer	2
3	41167	Fitting	1
4	41166	Fitting	1
5	41413	Nut	1
6	42480	Plug	2
7	--	--	--
8	--	--	--
9	43083	Straight Fitting	1
10	41363	Solenoid Valve Spool	1
11	43466	Coil - ERT Models Only	1
12	43364	Nut	1
13	50576	SHCS M4 × 12	1
14	43365	Cable Connector	1
15	43366	Emergency Down Cable Assembly	1
16	41162	Lowering Knob	1
17	53138	SHCS M6 × 16	2
18	53046	WSHR M6 Spring Washer	2
19	50000	WSHR M6 Standard Flat	2
20	41164	Valve Cover	1
21	43369	Check Valve	1
22	42821	Plug	1
23	43370	Orifice	1
24	43371	Seal Kit	1

Upper Lift Cylinder Assembly




ILLUSTRATION No.
Art_5435


69 Series

Upper Lift Cylinder Assembly - 4069




Item	Part Number	Description	Qty.
1	42795	Nut	1
2	43372	Solenoid Valve Spool	1
3	43467	Coil - ERT Models Only	1
4	43369	Check Valve	1
5	42821	Plug	1
6	43374	Orifice	1
7	41169	Relief Valve	1
8	43376	Upper Lift Cylinder	1
9	43361	Washer	2
10	41167	Fitting	1
11	41166	Fitting	1
12	41413	Nut	1
13	42480	Plug	1
14	43083	Straight Fitting	1
15	43377	Seal Kit	1

Right Oscillate Cylinder Assembly




Item	Part Number	Description	Qty.
1	53226	CSCS M6 × 16	2
2	43382	Protect Cover	1
3	43378	Counterbalance Valve Spool	2
4	43076	Straight Fitting	2
5	43383	Right Oscillate Cylinder	1
6	43381	Seal Kit	1

Left Oscillate Cylinder Assembly



Item	Part Number	Description	Qty.
1	43378	Counterbalance Valve Spool	2
2	43379	Left Oscillate Cylinder	1
3	43076	Straight Fitting	2
4	43380	Protect Cover	1
5	53226	CSCS M6 × 16	2
6	43381	Seal Kit	1

Steer Cylinder Assembly



Item	Part Number	Description	Qty.
1	43384	Dustproof Sleeve	1
2	43385	Clamp	1
3	43076	Straight Fitting	2
4	43386	Steer Cylinder	1
5	43077	Elbow	1
6	43387	Seal Kit	1

Outrigger Cylinder Assembly (Option)




ILLUSTRATION No.
Art_5439

69 Series

Outrigger Cylinder Assembly (Option)

Item	Part Number	Description	Qty.
1	43388	Outrigger Cylinder	1
2	43389	Elbow	2
3	43390	Retainer	1
4	53210	SHCS M8 × 25	4
5	53055	WSHR M8 Spring Washer	8
6	43391	Outrigger Footpad	1
7	43392	Seal Kit	1
8	43393	Pilot-Operated Check Valve	1
9	43394	Valve Body	1
10	53211	SHCS M8 × 55	4
11	43395	Solenoid Valve Spool	1
12	43468	Coil - ERT Model	1
13	42795	Nut	1

Hydraulic Hoses and Fittings-Function (3369ERT)




ILLUSTRATION No.
Art_5493

69ERT Series

Hydraulic Hoses and Fittings-Function (3369ERT)

Item	Part Number	Description	Qty.
1	43659	Hose Assembly	1
2	43695	Hose Assembly	1
3	43661	Hose Assembly	1
4	43662	Hose Assembly	2
5	43663	Hose Assembly	2
6	43696	Hose Assembly	1
7	43697	Hose Assembly	1
8	43698	Hose Assembly	1
9	43699	Hose Assembly	1
10	43076	Straight Fitting	10
11	43083	Straight Fitting	2
12	43267	Straight Fitting	1
13	43460	Straight Fitting	2
14	43331	Straight Fitting	1
15	43085	Straight Fitting	3
16	43451	Straight Fitting	1
17	43455	Straight Fitting	1
18	43268	Straight Fitting (Model With Outriggers)	1
19	43078	Tee Fitting	2
20	43077	Elbow	3
21	43459	Elbow	2
22	43456	Elbow	1
23	43115	Tee Fitting (Model With Outriggers)	1
24	43112	Elbow	2
25	43120	Plug	1
26	43119	Plug	2
27	42480	Plug	1
28	43124	Plug	1

Hydraulic Hoses and Fittings-Function (4069ERT)




ILLUSTRATION No.
Art_5494

69ERT Series

Hydraulic Hoses and Fittings-Function (409ERT)

Item	Part Number	Description	Qty.
1	43659	Hose Assembly	1
2	43695	Hose Assembly	1
3	43661	Hose Assembly	1
4	43662	Hose Assembly	2
5	43663	Hose Assembly	2
6	43696	Hose Assembly	1
7	43697	Hose Assembly	1
8	43698	Hose Assembly	1
9	43699	Hose Assembly	1
10	43076	Straight Fitting	10
11	43083	Straight Fitting	3
12	43267	Straight Fitting	1
13	43460	Straight Fitting	2
14	43331	Straight Fitting	1
15	43085	Straight Fitting	3
16	43451	Straight Fitting	1
17	43455	Straight Fitting	1
18	43268	Straight Fitting (Model With Outriggers)	1
19	43078	Tee Fitting	2
20	43077	Elbow	3
21	43459	Elbow	2
22	43456	Elbow	1
23	43115	Tee Fitting (Model With Outriggers)	1
24	43112	Elbow	2
25	43120	Plug	1
26	43119	Plug	2
27	42480	Plug	2
28	43124	Plug	1
29	43670	Hose Assembly	1
30	43081	Tee Fitting	1
31	43082	Elbow	1

Hydraulic Hoses and Fittings-Outrigger (Option)





ILLUSTRATION No.
Art_5495

69ERT Series

Hydraulic Hoses and Fittings-Outrigger (Option)

Item	Part Number	Description	Qty.
1	43700	Hose Assembly	1
2	43701	Hose Assembly	1
3	43702	Hose Assembly	1
4	43703	Hose Assembly	1
5	43674	Hose Assembly	2
6	43675	Hose Assembly	2
7	43677	Hose Assembly	2
8	43678	Hose Assembly	6
9	43389	Elbow	8
10	43083	Straight Fitting	5
11	43679	Tee Fitting	2
12	43081	Tee Fitting	4
13	43082	Elbow	5
14	43680	Straight Fitting	4

Electrical Harness






ILLUSTRATION No.
Art_5496b

69ERT Series


Electrical Harness



Item	Part Number	Description	Qty.
1	43704	Ground Control Box Harness	1
2	43705	Transit Harness	1
3	43682	Outrigger Harness 3	1
4	43685	Outrigger Harness 2	1
5	43683	Outrigger Harness 1	1
6	43706	EV Harness	1
7	43707	Motor Controller Harness	1
8	REF	Ground Control Box Assembly (Refer to page 62)	1
9	REF	Motor (Refer to page 66)	1
10	REF	Motor Controller (Refer to page 76)	2
11	REF	Motor (Refer to page 44, page 46)	2
12	REF	DC Power Supply (Refer to page 74)	1
13	REF	Battery (Refer to page 74)	8
14	REF	Charger (Refer to page 74)	1
15	REF	DC Contactor (Refer to page 76)	1
16	REF	Power Switch (Refer to page 74)	1
17	REF	350A Fuse Assembly (Refer to page 76)	1
18	REF	Coil (Outrigger) (Refer to page 118)	4
19	REF	Limit Switch (Outrigger) (Refer to page 80)	4
20	REF	Limit Switch (Oscillate) (Refer to page 44, page 46)	4
21	REF	Horn (Refer to page 84)	1
22	REF	Alarm (Refer to page 84)	1
23	REF	Limit Switch (Lift Down) (Refer to page 86)	2
24	REF	Limit Switch (Lift Up) (Refer to page 82)	1
25	REF	Tilt Sensor (Refer to page 84)	1
26	REF	Beacon (Refer to page 52, page 74)	2
27	--	--	--
28	--	--	--
29	REF	Coil (Lowering) (Refer to page 110, page 112)	2
30	REF	Platform Control Box Assembly (Refer to page 106)	1
31	REF	Function Manifold (Refer to page 56)	1
32	REF	Outrigger Manifold (Refer to page 60)	1
33	REF	Pressure Switch (Refer to page 54)	1
34	47212	Harness, Sensors, 3369RT/ERT	1
	44488	Harness, Sensors, 4069RT/ERT	1
35	41152	Coil Cord	1
36	44486	Harness, Comm Cable 3369RT/ERT	1
	44021	Harness, Comm Cable 4069ERT	1
--	44025	Harness, Lowering Valves 4069ERT	1


REF - Reference






Power to Platform



Item	Part Number	Description	Qty.
1	43690	AC Plug	1
2	43691	Circuit Breaker (Option)	1
4	43692	Wire Cable, Platform AC Power (3369RT)	1
	43693	Wire Cable, Platform AC Power (4069RT)	1
5	43694	AC Socket	1

ERT Machine Decals



1  91850 Qty - 4	2  90732 Qty - 2	3 mec 3369 ERT 3369ERT (Only) 94856 Qty - 4	mec 4069 ERT 4069ERT (Only) 93052 Qty - 4	4  91553 Qty - 1
5  90725 Qty - 2	6 HYDRAULIC OIL  6873 Qty - 1	7  9052 Qty - 1	8 POWER TO PLATFORM 90751 Qty - 1	9  90719 Qty - 1
10 www.mecawp.com 92416 Qty - 1	11  91973 Qty - 4	12  94872 Qty - 2	13  3369ERT (Only) 94868 Qty - 2	14  4069ERT (Only) 94870 Qty - 2
14  8911 Qty - 1	15  90722 Qty - 1	16  90721 Qty - 1	17  43525 Qty - 1	18 LOCATE CONTROL BOX HERE FOR NORMAL OPERATION OF THIS UNIT 7155 Qty - 1
19  9910 Qty - 4	20 BATTERY CHARGER 90750 Qty - 1	21  8779 Qty - 2	22  43524 Qty - 1	23  43102 Qty - 1
24  94120 Qty - 2	25  94528 Qty - 2	25 UHMV Strip 3" x 1/8" (80mm x 3mm) Length 9 ft (2.8m) 94899 Qty - 1	26  91744 Qty - 1	

Item	Part Number	Description	Qty.
1	91850	Decal, Caution Triangle Overhead Clearance	4
2	90732	Decal, Warning No Powerwash	2
3	94856	Decal, 3369ERT	4
	93052	Decal, 4069ERT	4
4	91553	Decal, Serial Plate, ANSI Slab	1
5	90725	Decal, Tire Replacement	2
6	6873	Decal, Hydraulic Oil	1
7	9052	Decal, Main Lockout Switch	1
8	90751	Decal, Power To Platform	1
9	90719	Decal, MEC Oval	1
10	92416	Decal, Website	1
11	91973	Decal, Tie Down	4
12	94872	Decal, Warning, Sheet Material Rack 300 LBS	2
13	94868	Decal, 1000 LBS Capacity - 3369 Models	2
	94870	Decal, 800 LBS Capacity - 4069 Models	2
14	8911	Decal, Manuals Inside Icon	1
15	90722	Decal, Warning Panel	1
16	90721	Decal, Danger Tip Over	1
17	43525	Platform Control Panel (69ERT)	1
18	7155	Decal, Locate Control Box Here	1
19	9910	Decal Hand Crush Hazard	4
20	90750	Decal, Battery Charger	1
21	8779	Decal, Warning Battery Explosive	2
22	43524	Ground Control Panel (69ERT)	1
23	43102	Decal, Key Switch Panel	1
24	94120	Decal, Drive/Lift Side for Slabs (Black)	2
	94528	Decal, Drive/Lift Side for Slabs (Gray)	2
25	94899	UHMW Strip 3" x 1/8" (80mm x 3mm), length 9 ft (2.8m)	1
26	91744	Battery Indicator 48V	1

Notes

Notes



MEC Parts Order Form

Phone: 559-842-1523

Fax: 559-400-6723

Email: Parts@mecawp.com

Please fill out completely

Date: _____

Ordered By: _____

Account: _____

Your Fax No.: _____

Bill to: _____

Ship to: _____

Purchase Order Number _____

Ship VIA _____

** All orders MUST have a Purchase Order Number

**Fed Ex shipments require Fed Ex account number

Part Number	Description	Quantity	Price

All back-ordered parts will be shipped when available via the same ship method as original order unless noted below:

- ☐ Ship complete order only - No Backorders
- ☐ Ship all available parts and contact customer on disposition of back-ordered parts
- ☐ Other (Please specify)



Limited Owner Warranty

MEC Aerial Platform Sales Corp. warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered. MEC Aerial Platform Sales Corp. further warrants the structural weldments of the main frame and scissor arms to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered. Excluded from such warranty is the battery(s) which carries a ninety (90) day warranty from described purchase date. Warranty claims within such warranty period shall be limited to repair or replacement, MEC Aerial Platform Sales Corp's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC Aerial Platform Sales Corp's then current flat rate, provided the defective part in question is shipped prepaid to MEC Aerial Platform Sales Corp. and is found upon inspection by MEC Aerial Platform Sales Corp. to be defective in material and/or workmanship. MEC Aerial Platform Sales Corp. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty. The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded. No Dealer, Sales Representative, or other person purporting to act on behalf of MEC Aerial Platform Sales Corp. is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC Aerial Platform Sales Corp. any liability or obligation which exceeds MEC Aerial Platform Sales Corp's obligations under this warranty.



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA

Toll Free: 1 - 877 - 632 - 5438

Phone: 1 - 559 - 842 - 1500

Fax: 1 - 559 - 842 - 1520

info@MECawp.com

www.MECawp.com