

**Operation and
Maintenance Manual
with Parts Catalog for**

Quadrex



Models

25SRT & 33SRT

**Semi-Rough
Terrain
and**

25E & 33E

**Electric
Aerial Work
Platforms**



Aerial Work Platforms

TABLE OF CONTENTS

Table of Contents	i	Maintenance Schedule	4-9
Section I. Operation and Operator Maintenance		Maintenance Procedures	4-10
1. Safety	1-1	Cap Screw Replacement	4-10
Use of Notes, Cautions and Warnings	1-1	LPG Tank Changing	4-10
General Operating Rules, Safety and		Replacing Batteries - Models	
Limitations	1-1	25E & 33E	4-11
Operator Qualifications	1-1	Hydraulic System Bleeding	4-11
Safety Features	1-1	Hydraulic Oil Filter Replacement	4-12
Maintenance Locks	1-2	Bleeding Axle Lock	
Tip Protection System	1-3	Hydraulic System	4-12
2. Introduction	2-1	Brake Adjustment	4-13
Description	2-1	Gasoline Engine Service	
Quadrex Specifications	2-2	and Adjustment	4-13
3. Operation	3-1	Optional Electric Generator	
Controls and Indicators - Models 25SRT		Maintenance Procedures -	
and 33SRT Dual Fuel Units	3-1	Models 25SRT/33SRT	4-13
Controls and Indicators - Models 25E		Generator Service and Adjustment	4-13
and 33E Electric Units	3-4	Belt Replacement	4-13
Equipment Operation - Models 25SRT		5. Troubleshooting	5-1
and 33SRT Dual Fuel Units	3-9	Troubleshooting Table	5-1
Equipment Operation - Models 25E and		Schematics, Layouts and Diagrams	5-3
33E Electric Units	3-10	Section II. Parts Catalog	
Extending or Retracting Optional		6. Locator Views and Decals	6-1
Extended Platform - SRT or E Models ...	3-13	Parts Catalog Locator View -	
Stowing and Erecting Platform Railings -		25SRT/33SRT	6-2
SRT or E Models	3-13	Parts Catalog Locator View - 25E/33E	6-3
4. Operator Maintenance	4-1	Decals - 25SRT/33SRT	6-4
Quadrex Models 25SRT and 33SRT		Decals - 25E/33E	6-5
Dual Fuel Aerial Work Platform		7. Hydraulic Valves	7-1
Walk-a-round Inspection	4-1	Hydraulic Line Layout	7-2
Quadrex Models 25E and 33E		Primary Manifold	7-3
Electric Aerial Work Platform		Secondary Manifold	7-4
Walk-a-round Inspection	4-5	Manifold Block	7-5
Lubrication	4-9		

**WARNING**

DO NOT perform preliminary installations, operate, service, replace, adjust or maintain equipment on this machine until you have *thoroughly* read and understood the Safety section of this manual, and have read and understood all the sections of this manual that apply to the job you are doing on this machine.

Failure to heed all warnings posted on this machine and written in this manual, could cause death, serious injury or property damage.

MEC QUADREX

8. Control Box Assemblies	8-1	Compartment Bases	12-3
Upper Control Box Assembly -		Lower Electric Cabinet	12-4
Dual Fuel Units	8-2	Lower Control Station	12-5
Standard Upper Control Box		Fuel Tanks Assembly	12-7
Assembly - Electric Units	8-3	Hydraulic Fluid Reservoir	12-8
Optional Upper Control Box		Battery Box Assembly	12-9
Assembly - Electric Units	8-4	Engine Assembly	12-10
9. Platform and Railings	9-1	Engine Panels and Generator Option	12-11
Main Platform Rails	9-2	Emergency Down Control and	
Main Platform	9-3	Axle Lock Height Limit Switch	12-12
Extended Platform Rails	9-4	Height Limit Switch Assembly - 10732 ...	12-13
Extended Platform	9-5	13. Compartments - Electric Units	13-1
Extended Platform Rail Lock Assemblies	9-6	Compartments and Panels	13-2
Tip Alarm Assembly - 10775	9-7	Compartment Bases	13-3
Speed Limit Switch	9-8	Lower Electric Cabinet	13-4
10. Scissors Lift Mechanism	10-1	Lower Control Station	13-5
Beam Section - 25 Feet	10-2	Motors Assembly and Battery Charger	13-6
Beam Section - 33 Feet	10-3	Motors Assembly	13-7
Hose Guide	10-4	Battery Charger and Panel Assembly	13-8
Scissors Lift Cylinder	10-5	Battery Charger	13-9
11. Axle Assembly	11-1	Hydraulic Fluid Reservoir	13-10
Front Axle Assembly	11-2	Battery Box Assemblies	13-11
Front Wheel Hub and Bearing - 7900	11-3	14. Outriggers	14-1
Steering Cylinder - 10329	11-4	Outrigger Control Box	14-2
Rear Axle Assembly	11-5	Outrigger Junction Box	14-3
Oscillating Axle Mount	11-6	Outrigger Posts	14-4
Brake Cylinder - 2483	11-7	Outrigger Manifolds	14-5
Axle Lock Mechanism	11-8	15. Miscellaneous	15-1
Rear Step	11-9	Clamps, Fasteners and Trim	15-2
Tires	11-10	Repair Kits and O-rings	15-3
12. Compartments - Dual Fuel Units	12-1	Numerical Part Number Index	15-4
Compartments and Panels	12-2		

SECTION I

OPERATION AND OPERATOR MAINTENANCE

This section provides valuable safety information, equipment description, explanation of controls and indicators, how to operate the equipment, how to troubleshoot the equipment, and when and how to service the equipment.

CHAPTER 1 SAFETY

USE OF NOTES, CAUTIONS AND WARNINGS

NOTE - Additional information to further explain instructions.

CAUTION - Failure to follow instruction could cause damage to equipment.

WARNING - Failure to follow instruction could cause death, personal injury and property damage.

DANGER - Failure to follow instruction will cause death, personal injury and property damage.

GENERAL OPERATING RULES, SAFETY AND LIMITATIONS

MEC designs Quadrex work platforms to be safe and reliable. They are rugged and maneuverable, but must be used only for purposes and in ways intended. That is to raise personnel and tools to overhead work areas.

Respect your machine; do not neglect or misuse it.

Inspect your machine before using. **Do not** use machine if it is not working properly in any way.

Check job site for unsafe working conditions. **Do not** operate on uneven or soft terrain. **Do not** raise platform if machine is on an incline.

Use machine only for purposes for which it was designed.

Never take chances. **Do not** use machine if your physical condition is uncertain in any way or if you are taking prescription drugs which might impair or limit your mental or physical capabilities.

Do not exceed the load capacity of the platform.

Do not smoke while charging or changing an LPG tank or filling gasoline tank.

Do not enter or exit platform while machine is in motion.

An operator of any type of work platform is subject to certain hazards that cannot be protected by mechanical means. It is therefore essential that operators be competent, careful, physically and mentally fit and thoroughly trained in safe operation of this machine.



DO NOT operate machine near power lines. Platform and enclosures are not insulated.

Failure to follow this warning will cause death or personal injury.

OPERATOR QUALIFICATIONS

Quadrex machines must be operated and maintained by qualified personnel only!

To qualify for operation and maintenance of this unit, an individual must read and thoroughly understand this manual. If a proposed operator or maintenance person fails to understand any segment of this manual, his or her supervisor can clarify the misunderstanding through written correspondence or a phone call to:

Mayville Engineering Co., Inc.
Aerial Work Platforms
715 South Street
Mayville, WI 53050
Phone: 414-387-4500

SAFETY FEATURES

1. Automatic Parking Brake


The Automatic Parking Brake is a spring-actuated, normally-on system. The brake is released during drive by hydraulic pressure built up in the drive circuit. A brake valve is used to maintain release during drive and an orifice is employed to control the braking function.

2. Emergency Stop

The Emergency Stop (Figures 1-1 and 1-2) is located on the upper control box assembly on the platform and on the lower control panel on the side of machine.


3. Emergency Down

The Emergency Down control (Figure 1-3) is located in center of lower beam weldment above the front axle. Pull control handle on cable to allow platform to descend to the stowed position.




MEC1-1

Figure 1-1. Emergency Stop - Upper Control Box Assembly



MEC1-2

Figure 1-2. Emergency Stop - Lower Control Panel



EMERGENCY DOWN CONTROL

MEC1-3

Figure 1-3. Emergency Down Control

MAINTENANCE LOCKS


WARNING

MAINTENANCE LOCKS MUST BE INSTALLED when maintaining or servicing machine with platform fully or partially extended.

Working through beams on scissors lifting device creates a hazardous situation which could cause death or personal injury.


FOLLOW MAINTENANCE LOCKS PROCEDURE!

1. Remove load from platform.
2. Using lower control panel, raise platform until both maintenance locks (1, Figure 1-4) can be pivoted fully upright.
3. While persons A and B hold each maintenance lock upright, person C slowly lowers platform using lower control panel until each lock (1, Figure 1-5) engages pivot pin (2). Persons A and B move clear.
4. Person C lowers platform until both locks fully engage pins and weight of platform and scissors rests completely on both maintenance locks.




MEC1-4

Figure 1-4. Positioning Maintenance Locks



MEC1-5

Figure 1-5. Maintenance Locks in Place

 WARNING
<p>DO NOT SERVICE EXTENDED OR PARTIALLY EXTENDED MACHINE UNTIL THE PRECEDING PROCEDURE IS ACCOMPLISHED.</p>

TIP PROTECTION SYSTEM


A tip sensor is incorporated in the machine to detect when the machine is tipped to a 4-1/2 degree angle or greater. The system will warn the operator of this out-of-level condition. The operator must either reposition the machine to a more level position or use the optional hydraulic outriggers to level the unit, if so equipped.

CHAPTER 2 INTRODUCTION

DESCRIPTION


Quadrex aerial work platforms (Figures 2-1 and 2-2) are hydraulically operated units driven by either an electric motor or a gasoline engine. The platform is raised and lowered by a hydraulic cylinder mounted inside a scissors mechanism. All units are steered by

a hydraulic cylinder, which is controlled from the upper control box assembly on the platform. Auxiliary lift controls and engine (dual fuel series) are located at the lower control panel on the side of the unit. The emergency lowering control is located between the scissor arms at the front of the unit.



MEC2-1

**Figure 2-1. 25SRT and 33SRT Gas Engine
Driven Quadrex Aerial Work Platforms**



MEC2-2

**Figure 2-2. 25E and 33E Electric Motor
Driven Quadrex Aerial Work Platforms**

QUADREX SPECIFICATIONS

Important dimensional, capacity and capability information is provided for your information. The following illustration contains letter callouts which correspond to letters in the Specifications Chart on the next page to permit you to clearly identify the data you require. Because we constantly strive to improve our products, we may make changes to these specifications without issuing a notice to you.




Figure 2-3. Quadrex Specification Attribute Identities

SPECIFICATIONS DATA

MODELS	SEMI-ROUGH TERRAIN				ELECTRIC			
	33SRT		25SRT		33E		25E	
MEASUREMENTS								
Height								
A. Work Height	39'	(11.9m)	31'	(9.5m)	39'	(11.9m)	31'	(9.5m)
B. Platform Hgt. (Max.)	33'	(10.06m)	25'	(7.62m)	33'	(10.06m)	25'	(7.62m)
C. Platform Hgt. (Min.)	62.5"	(1.6m)	54.5"	(1.38m)	63.5"	(1.61m)	55.5"	(1.41m)
D. Overall Height	104.5"	(2.65m)	96.5"	(2.45m)	105.5"	(2.68m)	97.5"	(2.48m)
E. Guardrail Height	42"	(1.07m)	42"	(1.07m)	42"	(1.07m)	42"	(1.07m)
Load Capacity								
W/O Ext. Platform	1500#	(680.4kg)	2000#	(907.2kg)	1500#	680.4kg)	2000#	(907.2kg)
With Ext. Platform	1250#	(567kg)	1750#	(793.8kg)	1250#	(567kg)	1750#	(793.8kg)
Dimensions								
F. Platform Size	74" W x 132" L (1.89m W x 3.35m L)				67.8 Square Feet (56.7 square meters)			
G. Overall Length	138"	(3.5m)	138"	(3.5m)	138"	(3.5m)	138"	(3.5m)
H. Overall Width	81.5"	(2.07m)	81.5"	(2.07m)	75.5"	(1.92m)	75.5"	(1.92m)
I. Wheel Track	69.5"	(1.77m)	69.5"	(1.77m)	60"	(1.52m)	60"	(1.52m)
J. Wheel Base	92"	(2.34m)	92"	(2.34m)	92"	(2.34m)	92"	(2.34m)
K. Ground Clearance	9.5"	(0.24m)	9.5"	(0.24m)	11.5"	(0.29m)	11.5"	(0.29m)
L. Rollout Ext. Plt. (Opt.)	48" Long (1.22m)				Adds 23 Square Feet (19 square meters)			
M. Axle Pivot Distance	6"	(0.15m)	6"	(0.15m)	6"	(0.15m)	6"	(0.15m)
Gradeability	25%		25%		25%		25%	
Speed								
Lift/Lower	38/45 Seconds				44/45 Seconds			
Travel	0.5;1.0;2.0 Mph (0.81;1.61;3.22 Kph)				0.5;1.5;3.0 Mph (0.81;2.42;4.84 Kph)			
Turning Radius								
Inside	131"	(3.33m)	131"	(3.33m)	127"	(3.22m)	127"	(3.22m)
Outside	230"	(5.84m)	230"	(5.84m)	213"	(5.41m)	213"	(5.41m)
Gross Wgt. (Approx.)	6380#	(2894kg)	6080#	(2758kg)	6740#	(3057kg)	6440#	(2921kg)
Hydraulic Tank Cap.	12 U.S. Gallons (45.5 liters) (use standard 10W hydraulic oil, non-detergent)							
Fuel Tank Capacity	6 U.S. Gallons/33#LP (23 liters/15kg)				Eight 220 Amp Hour Batteries			
Power	18 HP (13.4kw) Kohler Engine Air Cooled - Dual Fuel				48VDC Electric Motor			
Drive Axle	2 Wheel Rear Drive, Oscillating Rear Axle, Front Wheel Steering							
Tire Size	26" x 12" x 12" Pneumatic Super Terra Grip Tires Filled With Tiretyte II Sealant				8.75" x 16.5" LT, 29.2" Diameter Pneumatic			

MEC QUADREX

Introduction

Tires on Quadrex machines must be replaced with manufacturer's replacement tires to maintain stability factor of the machine. **LUG NUTS TO BE TORQUED TO 75-85 FT. LBS. AND CHECKED WEEKLY.**

Torque Specifications




Hydraulic Valve: Valve to manifold - 12 ft. lbs.
Valve nut to valve - 5 in. lbs.

Hydraulic Drive Motor Castle Nut: 300 ft. lbs.
then next slot on castle nut and install cotter pin

Recommended Fuels (Dual Fuel Series)

LPG: Natural Gas Processors Association
specification HD 5

Gasoline: Normal unleaded or leaded gasoline

			
Bolts	Grade 2	Grade 5	Grade 8
1/4-20	49 in. lbs.	76 in. lbs.	9 ft. lbs.
5/16-18	8 ft. lbs.	13 ft. lbs.	18 ft. lbs.
3/8-16	15 ft. lbs.	23 ft. lbs.	33 ft. lbs.
7/16-14	24 ft. lbs.	37 ft. lbs.	52 ft. lbs.
1/2-13	37 ft. lbs.	57 ft. lbs.	80 ft. lbs.

CHAPTER 3 OPERATION

This chapter provides identification of all controls and indicators on the Quadrex models 25SRT and 33SRT dual fuel and 25E and 33E electric aerial work platforms and provides specific instructions on how to operate the units. The 25SRT/33SRT dual fuel units are covered first and the 25E/33E electric units are covered second.


CONTROLS AND INDICATORS - MODELS 25SRT AND 33SRT DUAL FUEL UNITS

All controls and indicators provided on the dual fuel units are identified by a number and pointed out in an illustration. The name and a description of each control and indicator is provided after the number.

Lower Control Panel Controls and Indicators (Figure 3-1)

This control panel is used for initial start-up of the unit and during performance of the daily walk-a-round checks before operating the machine.

1. EMERGENCY STOP Switch Press cover which actuates switch. All electrical power is turned off and engine and hydraulic power is shut down. To reset switch, raise cover and move switch handle to opposite position.
2. UP/DOWN Switch Controls movement of platform. UP position energizes hydraulic system to raise platform. DOWN position energizes hydraulic system to lower platform. Switch will return to center or neutral position when released.
3. ON/OFF Key Switch Controls electrical power to engine. ON position allows flow of electrical power. OFF position breaks electrical circuit.




MEC3-1

Figure 3-1. Lower Control Panel Controls and Indicators - 25SRT/33SRT Dual Fuel Units

- | | |
|---------------------------|---|
| 4. CIRCUIT BREAKER Switch | Provides circuit protection to engine electrical system. When pushed in, electrical power will flow. When "tripped" (switch sticking out), circuit is interrupted. |
| 5. Operation Hour Meter | Optional indicator records the number of hours the unit has been operated. |
| 6. START/STOP Switch | In START position, the engine starter is engaged to start engine. When released, starter will disengage and switch will move to center or run position where engine will run continuously. In STOP position, engine will stop running. |
| 7. PLATFORM/BASE Switch | In PLATFORM position, the upper control box assembly is completely activated. In BASE position, all throttle control at the upper control box is deactivated. |
| 8. FUEL SELECTION Switch | Controls flow of fuel to engine. GAS position allows gasoline to flow to engine. OFF position keeps all fuel from flowing to engine. LPG position allows Liquefied Petroleum Gas (LPG) to flow to engine. |
| Low Engine Oil Alarm | Not shown. Located behind plate to the left of EMERGENCY STOP switch. Sounds when engine oil level is low. LOW OIL light on upper control box assembly will illuminate at the same time. Power for drive, lift and steer functions is shut down and fuel flow to engine is stopped. |

Upper Control Box Assembly Controls and Indicators (Figure 3-2)

This control box is located on the platform and is the primary station used during normal operation of the unit. This set of controls may be used while the operator is walking along side the unit or while the operator is on the platform. They are also used during performance of the daily walk-a-round checks.



MEC3-2

Figure 3-2. Upper Control Box Assembly Controls and Indicators - 25SRT/33SRT Dual Fuel Units

Operation


MEC QUADREX

- | | |
|---------------------------|---|
| 1. EMERGENCY STOP Switch | Press cover which actuates switch. All electrical power is turned off and engine and hydraulic power is shut down. To reset switch, raise cover and move switch handle to opposite position. |
| 2. OFF/RUN/START Switch | In START position, the engine starter is engaged to start engine. When released, starter will disengage and switch will move to RUN position where engine will run continuously. In OFF position, engine will stop running. |
| 3. LOW OIL Light | Illuminates when engine oil level is too low. Low engine oil alarm in lower control panel sounds at the same time. Power for drive, lift and steer functions is shut down and fuel flow to engine is stopped. |
| 4. SAFETY Switch | Must be actuated and held in MOTION position when operating platform or driving unit. Switch will return to center or neutral position when released. |
| 5. FORWARD/REVERSE Switch | Controls direction of movement. FORWARD position causes unit to move forward. REVERSE position causes the unit to move backwards. Switch will return to center or neutral position when released. |
| 6. STEERING Switch | Controls steering angle of front wheels. Turns front steer wheels left in LEFT position and turns wheels right in RIGHT position. Switch will return to center or neutral position when released. |
| 7. Amber Warning Light | Light illuminates when an out-of-level condition exists. |
| 8. Tip Warning Alarm | Alarm sounds when an out-of-level condition exists and platform is raised above ten feet. Refer to Chapter 1, Safety. |
| 9. THROTTLE Switch | Controls engine speed. UP - CONTINUOUS - Engine operates continuously at high speed. This setting must be used when using the optional generator. CENTER - IDLE - Engine operates at idle. DOWN - AUTOMATIC - Engine operates at idle or high speed as needed depending on switch settings on control box. |
| 10. TORQUE ON/OFF Switch | ON position provides more power in drive mode. FAST DRIVE is not available when TORQUE is ON. Normal power in OFF position. |
| 11. UP/DOWN Switch | Controls movement of platform. UP position energizes hydraulic system to raise platform. DOWN position energizes hydraulic system to lower platform. Switch will return to center or neutral position when released. |
| 12. SPEED CONTROL Switch | Provides multiple speeds for driving and lifting platform. Three driving speeds - FAST DRIVE, MEDIUM DRIVE and SLOW DRIVE - are available. Fast platform lift speed is attained by placing switch in FAST DRIVE (lift) position. Normal lift speed is attained by placing switch in MEDIUM DRIVE (lift) position or SLOW DRIVE (lift) position. |

Battery Box Service Controls (Figure 3-3)

The battery box is located behind the engine on the right side of the unit and contains a pair of engine control switches to be used by a service technician when performing troubleshooting of the engine.

1. **START/STOP Switch**
In START position, the engine starter is engaged to start engine. When released, starter will disengage and switch will move to center or run position where engine will run continuously. In OFF position, engine will stop running.
2. **Throttle Switch**
Controls engine speed. Up - IDLE - Engine operates at idle. Down - RUN - Engine operates continuously at high speed.



MEC3-3

Figure 3-3. Battery Box Service Controls - 25SRT/33SRT Dual Fuel Units


CONTROLS AND INDICATORS - MODELS 25E AND 33E ELECTRIC UNITS

All controls and indicators provided on the electric units are identified by name and pointed out in an illustration. A description of each control and indicator is also provided.

Lower Control Panel Controls and Indicators (Figure 3-4)

This control panel is used for initial start-up of the unit and during performance of the daily walk-a-round checks before operating the machine.

1. **Operation Hour Meter**
Records the number of hours the unit has been operated.
2. **EMERGENCY STOP Switch**
Press cover which actuates switch. All electrical power is turned off and engine and hydraulic power is shut down. To reset switch, raise cover and move switch handle to opposite position.
3. **UP/DOWN Switch**
Controls movement of platform. UP position energizes hydraulic system to raise platform. DOWN position energizes hydraulic system to lower platform. Switch will return to center or neutral position when released.



MEC3-4


Figure 3-4. Lower Control Panel Controls and Indicators - Model 25E/33E Electric Units

- | | |
|-----------------------------|--|
| 4. ON/OFF Key Switch | Controls electrical power to engine. ON position allows flow of electrical power. OFF position breaks electrical circuit. |
| 5. CIRCUIT BREAKER Switch | Provides circuit protection to engine electrical system. When pushed in, electrical power will flow. When "tripped" (switch sticking out), circuit is interrupted. |
| 6. BATTERY CHARGE Indicator | Shows the approximate amount of electrical charge contained in the batteries. |
| 7. ELECTRICAL Plug - 115V | Point of connection for extension cord to supply 115V power to electrical receptacle at side of platform floor. Powers 115V tools used by personnel on the platform. |

Upper Control Box Assembly Controls and Indicators - Standard (Figure 3-5)

This control box is located on the platform and is the primary station used during normal operation of the unit. This set of controls may be used while the operator is walking along side the unit or while the operator is on the platform. They are also used during performance of the daily walk-a-round checks.


- | | |
|--------------------------|--|
| 1. EMERGENCY STOP Switch | Press cover which actuates switch. All electrical power is turned off and engine and hydraulic power is shut down. To reset switch, raise cover and move switch handle to opposite position. |
|--------------------------|--|



MEC3-5

Figure 3-5. Standard Upper Control Box Assembly Controls and Indicators - 25E/33E Electric Units

- | | |
|---------------------------|--|
| 2. Amber Warning Light | Light illuminates when an out-of-level condition exists. |
| 3. Tip Warning Alarm | Alarm sounds when an out-of-level condition exists and platform is raised above ten feet. Refer to Chapter 1, Safety. |
| 4. SAFETY Switch | Must be actuated and held in MOTION position when operating platform or driving unit. Switch will return to center or neutral position when released. |
| 5. FORWARD/REVERSE Switch | Controls direction of movement. FORWARD position causes unit to move forward. REVERSE position causes the unit to move backwards. Switch will return to center or neutral position when released. |
| 6. STEERING Switch | Controls steering angle of front wheels. Turns front steer wheels left in LEFT position and turns wheels right in RIGHT position. Switch will return to center or neutral position when released. |
| 7. TORQUE ON/OFF Switch | ON position provides more power for driving. FAST DRIVE is available when TORQUE is ON. Normal power in OFF position. |
| 8. UP/DOWN Switch | Controls movement of platform. UP position energizes hydraulic system to raise platform. DOWN position energizes hydraulic system to lower platform. Switch will return to center or neutral position when released. |



MEC3-6

Figure 3-6. Optional Upper Control Box Assembly Controls and Indicators - 25E/33E Electric Units

9. **SPEED CONTROL Switch** Provides multiple speeds for driving and lifting platform. Three driving speeds - FAST DRIVE, MEDIUM DRIVE and SLOW DRIVE - are available. Fast platform lift speed is attained by placing switch in FAST DRIVE (lift) position. Normal lift speed is attained by placing switch in MEDIUM DRIVE (lift) position or SLOW DRIVE (lift) position.

Upper Control Box Assembly Controls and Indicators - Optional (Figure 3-6)


This control box is located on the platform and is the primary station used during normal operation of the unit. This set of controls may be used while the operator is walking along side the unit or while the operator is on the platform. They are also used during performance of the daily walk-a-round checks.

1. **HIGH SPEED ON/OFF Switch** High ground speed achieved at maximum movement of joystick in the FORWARD or REVERSE directions when switch placed in ON position. TORQUE ON/OFF switch must be in OFF position to obtain third speed.
2. **Amber Warning Light** Illuminates if platform is not level and platform is being raised.
3. **Tip Warning Alarm** Alarm sounds if platform is not level and platform is being raised.
4. **TORQUE ON/OFF Switch** ON position provides more power for driving. HIGH SPEED is not available when TORQUE is ON. Normal power in OFF position.
5. **EMERGENCY STOP Switch** Press cover which actuates switch. All electrical power is turned off and engine and hydraulic power is shut down. To reset switch, raise cover and move switch handle to opposite position.

- | | |
|----------------------------|--|
| 6. FAST/NORMAL Switch | Provides fast speed for raising platform in the FAST position. In the NORMAL position, the normal speed is obtained. |
| 7. UP/DOWN Switch | Controls movement of platform. UP position energizes hydraulic system to raise platform. DOWN position energizes hydraulic system to lower platform. Switch will return to center or neutral position when released. |
| 8. SAFETY Switch | Must be actuated and held in MOTION position when raising or lowering platform. Switch will return to center or neutral position when released. |
| 9. Joystick Control Handle | Controls direction of movement. FORWARD position causes unit to move forward. REVERSE position causes the unit to move backwards. Handle returns to center or neutral position when released. |
| 10. Enable Bar | Must be pressed to activate control capabilities of the joystick. Has same functions as SAFETY switch. |
| 11. STEER Switch | Controls steering angle of front wheels. Front wheels will turn left when LEFT side of rocker switch is pressed. Front wheels will turn right when RIGHT side of rocker switch is pressed. Switch will return to center or neutral position when released. |

Battery Charger Assembly Controls and Indicators (Figure 3-7)

The battery charger controls and indicators are located in the face of the battery charger box assembly on the left side of the unit.




MEC3-7

Figure 3-7. Battery Charger Assembly Controls and Indicators - 25E/33E Electric Units

- | | |
|------------------------------------|--|
| 1. Timer Switch | Controls amount of time during which charging of the batteries will take place. Settings range from 1 hour to 16 hours. |
| 2. Pilot Light | Illuminates when timer switch is turned ON and stays until timer switch moves to OFF position. |
| 3. Charge Rate Ampere Meter | Indicates the rate of charge to the batteries in amperes. |
| 4. Fuse | Provides charging system protection from electrical shorts. |
| 5. Charging Input Power Receptacle | Power cable from source of charging electricity connects at this point of input to the charger and batteries. Input must be 115 Volt, 60 Hertz, 1 Phase. |

EQUIPMENT OPERATION - MODELS 25SRT AND 33SRT DUAL FUEL UNITS



WARNING

Before operating this machine, operator **MUST** carefully read Chapter 1, Safety, at the beginning of this manual. Failure to follow safety precautions may result in death or serious injury.

Starting Engine At Lower Control Panel

1. Raise EMERGENCY STOP switch (1, Figure 3-2) cover and move switch handle to left position on upper control box assembly.
2. Raise EMERGENCY STOP switch (1, Figure 3-1) cover and move switch handle to up position on lower control panel.
3. Turn ON/OFF key switch (3) to ON position.

NOTE

FUEL SELECTION switch on lower control panel must be in either the LPG or GAS position when starting engine. When changing from one fuel to another, place switch in the OFF position while the engine is running. When the engine starts to hesitate, switch to the alternate fuel position.

4. Place FUEL SELECTION switch (8) in desired position - GAS or LPG.
5. Place PLATFORM/BASE switch (7) to BASE position.

6. Place START/STOP switch (6) in START position and hold until engine begins running. Release switch.

Starting Engine At Upper Control Box Assembly

1. At the lower control panel, raise EMERGENCY STOP switch (1, Figure 3-1) cover and move switch handle to up position.
2. Turn ON/OFF key switch (3) to ON position.

NOTE

FUEL SELECTION switch on lower control panel must be in either the LPG or GAS position when starting engine. When changing from one fuel to another, place switch in the OFF position while the engine is running. When the engine starts to hesitate, switch to the alternate fuel position.

3. Place FUEL SELECTION switch (8) in desired position - GAS or LPG.
4. Place PLATFORM/BASE switch (7) to PLATFORM position.
5. At the upper control box assembly, raise EMERGENCY STOP switch (1, Figure 3-2) cover and move switch handle to left position.

NOTE

When starting dual fuel engine from upper control box assembly, LOW OIL light will come on and warning buzzer will sound. Once engine is running, LOW OIL light will go out and buzzer will stop after oil pressure is attained. If LOW OIL light stays on and buzzer continues to sound after engine starts, the engine will automatically shut off. Refer to Chapter 5, Troubleshooting.

6. Place OFF/RUN/START switch (2) in START position and hold until engine begins running. Release switch. LOW OIL light (3) will come on and warning buzzer will sound until proper engine oil pressure is attained.

Driving Unit Forward and Backward

NOTE

The machine will operate in slow speed drive when the platform is raised above approximately six feet.

1. Place SPEED CONTROL switch (12, Figure 3-2) in desired position - FAST DRIVE, MEDIUM DRIVE or SLOW DRIVE.
2. Place THROTTLE switch (9) in desired position - CONTINUOUS, IDLE or AUTOMATIC.
3. If ascending a grade and more power is needed, place TORQUE ON/OFF switch (10) in ON position. SPEED CONTROL switch (12) must be in MEDIUM DRIVE or SLOW DRIVE. FAST DRIVE is not available when using TORQUE ON/OFF switch.
4. Move and hold FORWARD/REVERSE switch (5) to FORWARD position to drive forward or to REVERSE position to drive backward. Releasing either the SAFETY switch (4) or the FORWARD/REVERSE switch (5) will stop movement.
5. Move and hold SAFETY switch (4) in either of two MOTION positions. Quadrex will drive. Releasing either the FORWARD/REVERSE switch (5) or the SAFETY switch (4) will stop movement.
6. As needed, move STEERING switch (6) to LEFT position and hold to turn left or move STEERING switch to RIGHT position and hold to turn right. Move STEERING switch to opposite position to straighten wheels after a turn is completed. SAFETY switch (4) must be in MOTION position to obtain steering action. Steering while moving requires the FORWARD/REVERSE switch (5) to be activated also.

Operating Platform At Lower Control Panel

1. Place PLATFORM/BASE switch (7, Figure 3-1) to BASE position.
2. Move and hold UP/DOWN switch (2) to UP position to raise platform. To stop movement, release switch.

3. Move and hold UP/DOWN switch (2) to DOWN position to lower platform. To stop movement, release switch.

Operating Platform At Upper Control Box Assembly

1. Place SPEED CONTROL switch (12, Figure 3-2) in FAST DRIVE/LIFT position for Fast lift or in SLOW DRIVE (lift) or MEDIUM DRIVE (lift) for Normal lift.
2. Place THROTTLE switch (9) in desired position - CONTINUOUS, IDLE or AUTOMATIC.
3. Move and hold UP/DOWN switch (11) to UP position to raise platform or to DOWN position to lower platform. Releasing either the SAFETY switch (4) or the UP/DOWN switch (11) will stop movement.
5. Move and hold SAFETY switch (4) in either of two MOTION positions. Platform will move. Releasing either the UP/DOWN switch (11) or the SAFETY switch (4) will stop movement.

Generator Option Operation

Refer to GENERATOR MANUAL.

EQUIPMENT OPERATION - MODELS 25E AND 33E ELECTRIC UNITS

WARNING

Before operating this machine, operator MUST carefully read Chapter 1, Safety, at the beginning of this manual. Failure to follow safety precautions may result in death or serious injury.

Power Up At Lower Control Panel

1. Raise EMERGENCY STOP switch (1, Figure 3-5 or 5, Figure 3-6) cover and move switch handle to left position or up position on upper control box assembly.
2. Raise EMERGENCY STOP switch (2, Figure 3-4) cover and move switch handle to up position on lower control panel.
3. Turn ON/OFF key switch (4) to ON position.

Power Up At Upper Control Box Assembly

1. At the lower control panel, raise EMERGENCY STOP switch (2, Figure 3-4) cover and move switch handle to up position.
2. Turn ON/OFF key switch (4) to ON position.
3. At the upper control box assembly, raise EMERGENCY STOP switch (1, Figure 3-5 or 5, Figure 3-6) cover and move switch handle to left position or up position.

Driving Unit Forward and Backward At Standard Upper Control Box Assembly

NOTE

The machine will operate in slow speed drive when the platform is raised above approximately six feet.

1. Place SPEED CONTROL switch (9, Figure 3-5) in desired position - FAST DRIVE, MEDIUM DRIVE or SLOW DRIVE.
2. If ascending a grade and more power is needed, place TORQUE ON/OFF switch (7) in ON position. SPEED CONTROL switch (9) must be in MEDIUM DRIVE or SLOW DRIVE. FAST DRIVE is not available when using TORQUE ON/OFF switch.
3. Move and hold FORWARD/REVERSE switch (5) to FORWARD position to drive forward or to REVERSE position to drive backward. Releasing either the SAFETY switch (4) or the FORWARD/REVERSE switch (5) will stop movement.
4. Move and hold SAFETY switch (4) in either of two MOTION positions. Quadrex will drive. Releasing either the FORWARD/REVERSE switch (5) or the SAFETY switch (4) will stop movement.
5. As needed, move STEERING switch (6) to LEFT position and hold to turn left or move STEERING switch to RIGHT position and hold to turn right. Move STEERING switch to opposite position to straighten wheels after a turn is completed. SAFETY switch (4) must be in MOTION position to obtain steering action. Steering while moving requires the FORWARD/REVERSE switch (5) to be activated also.

Driving Unit Forward and Backward At Optional (Joystick) Upper Control Box Assembly

NOTE

The machine will operate in slow speed drive when the platform is raised above approximately six feet.

1. Place HIGH SPEED ON/OFF switch (1, Figure 3-6) in ON position to obtain high speed. The TORQUE ON/OFF switch (4) must be in OFF position.
2. If ascending a grade and more power is needed, place TORQUE ON/OFF switch (4) in ON position. HIGH SPEED drive is not available when TORQUE ON/OFF switch is in ON position.
3. Grasp joystick control grip (9) making sure enable bar (10) is depressed. Pivot joystick forward to move forward. Pivot joystick back to move backwards. Movement of joystick has three "steps" - slow speed, medium speed and high speed. Slow and medium speeds are always available. High speed is only available when HIGH SPEED ON/OFF switch (1) is in ON position and TORQUE ON/OFF switch (4) is in OFF position. Releasing the enable bar or joystick control grip will stop movement of unit.
4. As needed, depress and hold left side of STEER switch (11) to turn left or depress and hold right side of STEER switch to turn right. Wheels must be straightened after a turn by depressing STEER switch to opposite position. Wheels will not straighten by themselves after a turn is completed. Joystick enable bar must be depressed to obtain steering action. Steering may be performed while moving - joystick in a forward or reverse position.

Operating Platform At Lower Control Panel

1. Move and hold UP/DOWN switch (3, Figure 3-4) to UP position to raise platform. To stop movement, release switch.
2. Move and hold UP/DOWN switch (3) to DOWN position to lower platform. To stop movement, release switch.

Operating Platform At Standard Upper Control Box Assembly

1. Place SPEED CONTROL switch (9, Figure 3-5) in FAST DRIVE/LIFT position for Fast lift or in SLOW DRIVE (lift) or MEDIUM DRIVE (lift) for Normal lift.

2. Move and hold UP/DOWN switch (8) to UP position to raise platform or to DOWN position to lower platform. Releasing either the SAFETY switch (4) or the UP/DOWN switch (8) will stop movement.

3. Move and hold SAFETY switch (4) in either of two MOTION positions. Platform will move. Releasing either the UP/DOWN switch (8) or the SAFETY switch (4) will stop movement.

Operating Platform At Optional (Joystick) Upper Control Box Assembly

1. Place FAST/NORMAL switch (6, Figure 3-6) in desired position - FAST or NORMAL.

2. Move and hold UP/DOWN switch (7) to UP position to raise platform or to DOWN position to lower platform. Releasing either the SAFETY switch (8) or the UP/DOWN switch (7) will stop movement.

3. Move and hold SAFETY switch (8) in either of two SAFETY positions. Platform will move. Releasing either the UP/DOWN switch (7) or the SAFETY switch (8) will stop movement.

Batteries



WARNING

NEVER SMOKE OR USE OTHER COMBUSTIBLES NEAR BATTERY OR WHILE SERVICING BATTERY OR OTHER COMPONENTS. PROVIDE PLENTY OF VENTILATION AS PRESENCE OF HYDROGEN FUMES COULD LEAD TO EXPLOSION.

The Quadrex 25E/33E units are equipped with 8 heavy-duty, deep-cycle batteries. Battery care and maintenance depends upon the frequency of their use.

Battery wiring and water level should be checked daily. If unit is not used daily, check and fill batteries after every 15 hours of use or when recharging. Do not overfill batteries. Do not allow batteries to remain discharged. Do not run batteries dead. Put battery on charge when approximately 80% discharged. This is measured as a hydrometer reading of 1.500 at 80° F (26.6° C).

The following paragraphs contain notes and procedures for checking and filling batteries and charging batteries.

Checking and Filling Batteries



CAUTION

DO NOT OVERFILL. When battery cells are filled too full, battery fluid will expand as it warms from charging and will seep out of the battery. When water is then added, the solution is weakened and a loss of ampere hour capacity results.

NEVER add acid to battery. The solution is at its proper strength when the battery is manufactured. Use distilled water and maintain proper fluid level. When required, add water to battery **AFTER** charging, unless water level is below the top of the plates.

Check and fill batteries, after every 15 hours of use or when recharging, as follows:

1. Open battery tray cover.
2. If there is any dirt or corrosion on battery, wash with a solution of 5 teaspoons baking soda per quart of warm water.
3. Remove battery caps and check fluid.
4. Fill, as needed, as follows:
 - a. **Before** charging, fluid must be above plates in battery.
 - b. **After** charging, fill to split ring. **Do not overfill.**
5. Coat terminals with petroleum jelly or equivalent coating.

Charging Batteries

Surrounding temperature has a considerable effect on the power reserve in a battery.

A battery 100% charged at 80° F (26.6° C):
 --drops to 65% at 32° F (0° C)
 --drops to 40% at 0° F (-32° C)

Operation

MEC QUADREX

A battery 46% charged at 80° F (26.6° C):
--drops to 32% at 31° F (-1° C)
--drops to 21% at 0° F (-32° C)

Whenever battery temperature reaches 125° F (93° C), the charging rate should be reduced or the battery taken off charge and cooled to room temperature.

Monthly equalizing charges of 25% over the regular charge are recommended. The equalizing charge must be delivered at a low rate to eliminate excessive gassing.

Bring batteries to a full charge as soon as possible after a period of continual use. A full charge is measured by a hydrometer reading of 1.265 at 80° F (26.6° C).

Lead plates in discharged batteries will harden and become sulfated, which will shorten battery life as much as overcharging. Sulfated batteries fail to deliver rated capacity or to fully charge.

Several long, slow charges (at a low rate to avoid gassing) and fast discharges are then necessary to correct the sulfation and hardened plates.

Do not overcharge battery as this causes the battery to boil dry.



WARNING

NEVER SMOKE OR USE OTHER COMBUSTIBLES NEAR BATTERY OR WHILE SERVICING BATTERY OR OTHER COMPONENTS. PROVIDE PLENTY OF VENTILATION AS PRESENCE OF HYDROGEN FUMES COULD LEAD TO EXPLOSION.

1. Open battery tray cover.
2. Remove battery caps, check fluid level and fill, if needed, to top of plates only.
3. Reinstall battery caps before charging.
4. Turn timer switch (1, Figure 3-7) to OFF position.
5. Connect AC cord to 115V AC receptacle.
6. Insert DC plug of power cord into charging input power receptacle (5).

7. Turn timer switch (1) to ON position for a 16 hour charging period or to a lesser amount of time as desired. Pilot light (2) will illuminate and charge rate ampere meter (3) will indicate a charge rate. Charger will turn off automatically when timer runs out.

8. When charging is complete, place timer switch (1) in OFF position and disconnect power cable from receptacle (5).

9. Remove battery caps, check that fluid level is up to split ring and reinstall caps.

EXTENDING OR RETRACTING OPTIONAL EXTENDED PLATFORM - SRT OR E MODELS



WARNING

Do not use extended platform without railings in place and lock pins completely engaged in lock channel holes.

1. Move lock lever (1, Figure 3-8) down to release lock pin (2) on each side of extended platform railing from lock channel.
2. Pull rail handle (3) out of handle clip (4) on each side of platform and rotate handle up to level.
3. Push or pull on both rail handles (3) to extend or retract platform to desired position.
4. Make sure lock pin (2) is aligned with hole in lock channel (5) and pull lock lever (1) up to engage pin in channel. Be sure lock pin is fully engaged.
5. Rotate each rail handle (3) down and press into handle clip (4).

STOWING AND ERECTING PLATFORM RAILINGS - SRT OR E MODELS

NOTE

If your unit is equipped with the optional extended platform, perform all steps except step 6. If your unit is equipped with the standard railings, skip steps 1 thru 5 and begin with step 6.

1. Remove safety snap pins (1, Figure 3-9) from side railing and lock assembly.
2. Lift side railing so top railing support (2) clears other top rail and swing rear of side railing to the front.
3. Lift side railing off hinge brackets. Lay railing down on platform with extension handle toward front and hinge brackets down on floor.

4. Repeat preceding steps to remove other railing.
5. Pull top rail of front railing toward you and lay down on top of side railings.
6. Remove safety snap pins (1, Figure 3-10) from outside of front railing and pull top rail toward you and lay railing down on platform floor.
7. Remove safety snap pins (1, Figure 3-10) from outside of rear railing and pull top rail toward you and lay railing down on platform floor.

8. Pull up on both hinge locks (2) on vertical posts of side railing. Pull on top rail and lay railing down on top of other railings.
9. Reassemble railings by following the reverse order of this procedure. Make sure all safety snap pins, hinge locks and railing supports are securely engaged and/or locked in place.
10. Follow the reverse of this procedure to erect the platform railings.




Figure 3-8. Extended Platform Lock Assemblies and Extension Handles





Figure 3-9. Safety Snap Pins and Railing Supports - Extended Platform



MEC3-10

Figure 3-10. Safety Snap Pins and Hinge Locks - Standard Platform

CHAPTER 4 OPERATOR MAINTENANCE


This chapter contains information for the operator about the specific use of the equipment. Preventive maintenance information is presented first in the Walk-a-round Check for models 25SRT/33SRT and models 25E/33E aerial platform units. Next, a schedule of operator level maintenance tasks is presented followed by instructions for those operator tasks. Last, a schedule of maintenance activities, some of which should be performed by your dealer, is provided.

QUADREX MODELS 25SRT AND 33SRT DUAL FUEL AERIAL WORK PLATFORM WALK-A-ROUND INSPECTION

The Walk-a-round Check shall be performed by the operator prior to using the unit for the first time of the day or by a new operator even if the unit has been used during any part of the day. The Walk-a-round Check is critical to ensuring the safe operation of the platform.


When performing the Walk-a-round Check, visually inspect for obvious damage to the specific part of the unit including loose or missing fasteners; frayed, broken or leaking hydraulic lines; and worn, broken or frayed insulation on power cables. Also, check for bent structural members (beams, frame, platform, etc.). A machine which has been overloaded will have bent structural members and fatigued pivot pins. Begin the Check standing at the center of the rear of the unit. The number of the check in the listing matches a corresponding number in an illustration to help the operator understand and locate the check to be performed.

1. Capacity Decals on Rear of Platform (Figure 4-1) - Check that two decals are in place on rear edge of platform floor--one at each corner--and are intact and legible.
2. Maintenance Lock - Check lock for secure attachment to pivot pin collar and is not bent. Check receiver channels for damage. Check that decal is in place on side of pivot pin collar and is legible.
3. Broken Welds on Scissor Pivot Collars - Check for broken welds on scissors where each pivot pin collar is attached.



MEC4-1


Figure 4-1. 25SRT/33SRT Walk-a-round Checks 1 Thru 3



MEC4-2

Figure 4-2. 25SRT/33SRT Walk-a-round Checks 4 Thru 17


4. Broken or Missing Retaining Rings on Scissor Pivot Pins (Figure 4-2) - Check for missing or broken retaining rings on exposed ends of pivot pins.
5. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
6. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
7. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
8. Engine Oil Level - Oil level should be between L mark and F mark.
9. Battery Water Level - **Weekly** - Water should be up to the split ring. Use only distilled water.
10. Hydraulic Fluid Level - **Weekly** - Fluid level should be three inches below top of filler neck.
11. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
12. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
13. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
14. Broken or Missing Retaining Rings on Scissor Pivot Pins - Check for missing or broken retaining rings on exposed ends of pivot pins.
15. Maintenance Lock - Check lock for secure attachment to pivot pin collar and is not bent. Check receiver channels for damage. Check that decal is in place on side of pivot pin collar and is legible.
16. Emergency Down Decal - Check that emergency down decal is in place on bottom pivot pin beside EMERGENCY DOWN control and is legible.
17. Broken Welds on Scissor Pivot Collars - Check for broken welds on scissors where each pivot pin collar is attached.



MEC4-3

Figure 4-3. 25SRT/33SRT Walk-a-round Checks 18 Thru 32

18. Broken or Missing Retaining Rings on Scissor Pivot Pins (Figure 4-3) - Check for missing or broken retaining rings on exposed ends of pivot pins.
19. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
20. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
21. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
22. Lower Control Panel - Check for obvious damage to switches, indicators and guards. Check that three decals are in place on the control box and are legible.
23. LPG Warning Decal - Check that decal is in place on cabinet next to gasoline tank and is legible.
24. Gasoline Tank Fuel Level - Gasoline should be just below filler neck.
25. Fuel Leaks - Check for any visible or audible fuel leaks. Check for LPG smell below tank.
26. LPG Tank Fuel Level - Gage should indicate a level appropriate for task(s) to be performed.
27. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
28. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
29. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
30. Broken or Missing Retaining Rings on Scissor Pivot Pins - Check for missing or broken retaining rings on exposed ends of pivot pins.
31. Rear Steps - Check rear steps on bumper for obvious damage and loose or missing fasteners. Check bottom step for security and broken welds.
32. Rear Gate - Check rear gate for loose or missing fasteners and obvious damage. Check that latch is secure and operates properly.



MEC4-4

Figure 4-4. 25SRT/33SRT Walk-a-round Checks 33 Thru 40

Mount platform.

33. Platform Railings (Figure 4-4) - Check all railings for secure and proper installation and obvious damage. Check that top rail is not bent to a height of less than 39 inches.
34. Decals on Panel on Front Rail - Check that four decals are in place on panel of front platform railing and all four are intact and legible.
35. Manual Tube - Check that all manuals are in tube on front railing.
36. Upper Control Box Assembly - Check for obvious damage to switches, indicators and guards. Check that four decals are in place on the control box and are legible.
37. Raise EMERGENCY STOP cover and place switch to left position.

Dismount from platform.

38. Check Operation of EMERGENCY DOWN control using lower control panel:
 - a. Turn key switch 90 degrees to right.
 - b. Raise EMERGENCY STOP switch cover and place switch in up or top position.
 - c. Place PLATFORM/BASE switch to BASE position.
 - d. Place FUEL SELECTION switch to GAS or LPG position as desired.
 - e. Place START/STOP switch in START position and hold until engine starts.
 - f. Place UP/DOWN switch in UP position and hold to raise platform 10 to 15 feet above you. Release switch.
 - g. Pull EMERGENCY DOWN control out and hold. Platform should lower all the way.

- h. Press EMERGENCY STOP - unit shuts down quickly and completely.
- i. Raise EMERGENCY STOP switch cover and place switch in up or top position.
- j. Place PLATFORM/BASE switch to PLATFORM position.

Mount Platform.

39. Test upper control box assembly controls and indicators:
- a. Steer left and right.
 - b. Drive forward/reverse in slow, medium and fast with torque off.
 - c. Operate brakes on a grade.
 - e. Drive forward/reverse in slow and medium with torque on.
 - f. Check fast drive speed cutout when platform is raised.



WARNING

ALL PIVOT AREAS OF SCISSORS AND LIFT CYLINDER MUST BE CHECKED FOR WEAR. A LOUD SCRAPING NOISE MEANS THE D.U. BEARINGS ARE DAMAGED AND NEED REPLACING. FAILURE TO DO SO WILL RESULT IN EXTENSIVE DAMAGE TO STRUCTURAL MEMBERS AND BUSHINGS WHICH WOULD CREATE A HAZARDOUS CONDITION AND COULD RESULT IN INJURY OR DEATH TO PERSONNEL.


- g. Raise platform to full extension using slow and fast speeds.
 - h. Lower platform to full compression.
 - i. Emergency stop working properly (unit shuts down quickly and completely).
40. Raise EMERGENCY STOP switch cover and place switch in left position.

QUADREX MODELS 25E AND 33E ELECTRIC AERIAL WORK PLATFORM WALK-A-ROUND INSPECTION

The Walk-a-round Check shall be performed by the operator prior to using the unit for the first time of the day or by a new operator even if the unit has been used during any part of the day. The Walk-a-round Check is critical to ensuring the safe operation of the platform.

When performing the Walk-a-round Check, visually inspect for obvious damage to the specific part of the unit including loose or missing fasteners; frayed, broken or leaking hydraulic lines; and worn, broken or frayed insulation on power cables. Also, check for bent structural members (beams, frame, platform, etc.). A machine which has been overloaded will have bent structural members and fatigued pivot pins. Begin the Check standing at the center of the rear of the unit. The number of the check in the listing matches a corresponding number in an illustration to help the operator understand and locate the check to be performed.


- 1. Capacity Decals on Rear of Platform (Figure 4-5) - Check that two decals are in place on rear edge of platform floor--one at each corner--and are intact and legible.
- 2. Maintenance Lock - Check lock for secure attachment to pivot pin collar and is not bent. Check receiver channels for damage. Check that decal is in place on side of pivot pin collar and is legible.



MEC4-5

Figure 4-5. 25E/33E Walk-a-round Checks 1 Thru 3


3. Broken Welds on Scissor Pivot Collars - Check for broken welds on scissors where each pivot pin collar is attached.
4. Broken or Missing Retaining Rings on Scissor Pivot Pins (Figure 4-6) - Check for missing or broken retaining rings on exposed ends of pivot pins.
5. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
6. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
7. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
8. Battery Water Level - **Weekly** - Water should be up to the split ring in each cell.
9. Battery Disconnect Decal - Decal in place on battery tray cover and legible.
10. Hydraulic Fluid Level - **Weekly** - Fluid level should be three inches below top of filler neck.
11. Battery Charger Label - Label in place on battery charger door and legible.
12. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
13. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
14. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
15. Broken or Missing Retaining Rings on Scissor Pivot Pins - Check for missing or broken retaining rings on exposed ends of pivot pins.
16. Emergency Down Decal - Check that emergency down decal is in place on bottom pivot pin beside EMERGENCY DOWN control and is legible.
17. Broken Welds on Scissor Pivot Collars - Check for broken welds on scissors where each pivot pin collar is attached.



MEC4-6

Figure 4-6. 25E/33E Walk-a-round Checks 4 Thru 18

18. Maintenance Lock - Check lock for secure attachment to pivot pin collar and is not bent. Check receiver channels for damage. Check that decal is in place on side of pivot pin collar and is legible.
19. Broken or Missing Retaining Rings on Scissor Pivot Pins (Figure 4-7) - Check for missing or broken retaining rings on exposed ends of pivot pins.
20. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
21. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
22. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
23. Lower Control Panel - Check for obvious damage to switches, indicators and guards. Check that decal is in place on the control box and is legible.
24. Battery Water Level - Water should be up to the split ring in each cell.
25. Battery Disconnect Decal - Decal in place on battery tray cover and is legible.
26. Tire Condition - Check tire inflation pressure is correct. Check for excessive wear and damage to tire.
27. Wheel Condition - Check wheel for bent rim and loose or missing lug nuts.
Weekly - Torque nuts to 75-85 ft. lbs. (102-115 N·m).
28. Tire Pressure Decal on Frame - Check that decal is in place on frame behind tire and is legible.
29. Broken or Missing Retaining Rings on Scissor Pivot Pins - Check for missing or broken retaining rings on exposed ends of pivot pins.
30. Rear Steps - Check rear steps on bumper for obvious damage and loose or missing fasteners. Check bottom step for security and broken welds.
31. Rear Gate - Check rear gate for loose or missing fasteners and obvious damage. Check that latch is secure and operates properly.



MEC4-7

Figure 4-7. 25E/33E Walk-a-round Checks 19 Thru 39

Mount platform.

- 32. Platform Railings - Check all railings for secure and proper installation and obvious damage. Check that top rail is not bent to a height of less than 39 inches.
- 33. Decals on Panel on Front Rail - Check that four decals are in place on panel of front platform railing and all four are intact and legible.
- 34. Manuals Tube - Check that all manuals are in tube on front railing.
- 35. Upper Control Box Assembly - Check for obvious damage to switches, indicators and guards. Check that five decals are in place on the control box and are legible.
- 36. Raise EMERGENCY STOP cover and place switch to left position or up position.

Dismount from platform.

- 37. Check Operation of EMERGENCY DOWN control using lower control panel:
 - a. Turn key switch 90 degrees to right.
 - b. Raise EMERGENCY STOP switch cover and place switch in up or top position.
 - c. Place UP/DOWN switch in UP position and hold until platform is 10 to 15 feet above you. Release switch.
 - g. Pull EMERGENCY DOWN control out and hold. Platform should lower all the way.
 - h. Press EMERGENCY STOP - unit shuts down quickly and completely.
 - i. Raise EMERGENCY STOP switch cover and place switch in up or top position.

Mount Platform.

38. Test upper control box assembly controls and indicators:
- Steer left and right.
 - Drive forward/reverse in slow, medium and fast with torque off.
 - Operate brakes on a grade.
 - Drive forward/reverse in slow and medium with torque on.
 - Check fast drive speed cutout when platform is raised.



WARNING

ALL PIVOT AREAS OF SCISSORS AND LIFT CYLINDER MUST BE CHECKED FOR WEAR. A LOUD SCRAPING NOISE MEANS THE D.U. BEARINGS ARE DAMAGED AND NEED REPLACING. FAILURE TO DO SO WILL RESULT IN EXTENSIVE DAMAGE TO STRUCTURAL MEMBERS AND BUSHINGS WHICH WOULD CREATE A HAZARDOUS CONDITION AND COULD RESULT IN INJURY OR DEATH TO PERSONNEL.

- Raise platform to full extension using slow and fast speeds.
 - Lower platform to full compression.
 - Emergency stop working properly (unit shuts down quickly and completely).
39. Raise EMERGENCY STOP switch cover and place switch in left position or up position.

LUBRICATION

The Quadrex aerial work platform has a few items which must be lubricated and are identified in Table 4-1. The interval for performing the lubrication is also provided.

Table 4-1. Lubrication Chart

<u>Item</u>	<u>Location/Action</u>	<u>Interval</u>	<u>Lubricant</u>
Platform Rollers	2 under platform & 2 on top of platform	Monthly	Moly Lith 202 Multi-purpose Grease or equivalent
Cylinder Pins	2 on axle lock cylinder on LH side & 2 on axle lock cylinder on RH side	Monthly	Moly Lith 202 Multi-purpose Grease or equivalent
Engine Oil	SRT only - Drain and Refill	Every 25 hrs	Motor Oil
Engine Oil Filter	SRT only - Replace	Every 25 hrs	Motor Oil
Wheel Bearings	Clean and Repack	Annually	Wheel Bearing Grease
King Pin Bearings	Clean and Repack	Annually	Wheel Bearing Grease

MAINTENANCE SCHEDULE

The schedule of maintenance tasks for Quadrex models 25SRT/33SRT and 25E/33E aerial work platforms which can and should be performed by the operator are presented in Table 4-2. Where appropriate, the interval for performing each task is also provided.

Figure 4-2. Maintenance Schedule

Item	Action	Interval
Battery Terminal Connections	Clean & coat with grease	Monthly
Commutator and Brushes	Inspect	Annually
Hydraulic Oil Filter	Replace	Annually
Control System Terminal and Plugs	Inspect and repair	Every 6 months
Control System Cords	Inspect and repair or replace	Every 6 months

MAINTENANCE PROCEDURES

Cap Screw Replacement

Any cap screw replacement should be of same grade or greater than original. If any questions, call the factory for verification. Grade markings for cap screw grades 2, 5, and 8 (shown below) are based on SAE j429. Markings may be raised or depressed (manufacturer's option).

Grade 2



Grade 5



Grade 8



NOTE

Replacement tank should contain fuel manufactured to Natural Gas Processors Association Specification HD-5.

- Position new tank so that valve outlet aligns with fuel hose fitting (2).
- Connect fuel hose fitting (2) to tank valve.
- Close tank strap latch (3).
- Open shutoff valve (1) and check for leaks. Repair leaks immediately.

LPG Tank Changing




WARNING

FLAMMABLE LIQUIDS

Do not smoke or use other combustibles while changing LPG tanks. Do not change tanks near flames or sparks. Escaping fumes could cause explosion if ignited by flame or spark.


- Close shutoff valve (1, Figure 4-8) on top of fuel tank.
- Start engine on LPG and run until engine stops to purge fuel line.
- Disconnect fuel hose fitting (2) from tank valve.
- Release latch (3) on tank strap and remove tank (4).



MEC4-8

Figure 4-8. LPG Tank Changing


Replacing Batteries - Models 25E & 33E


WARNING

ELECTRIC SERIES MACHINES SPECIAL MAINTENANCE CONCERNS

To minimize the risk of fire, electric shock or explosion, the following maintenance procedures and inspections are particularly important for electrically powered machines:

- 1. Keep machine clear of lubricants and other combustible material.**
- 2. Inspect wiring regularly for frayed or deteriorated insulation. Immediately replace or repair a wire harness, or individual wire, that has frayed or deteriorated insulation.**
- 3. Check brakes at the recommended intervals, and make adjustments when required.**


WARNING


NEVER SMOKE OR USE COMBUSTIBLES NEAR UNIT WHEN SERVICING BATTERIES. PROVIDE PLENTY OF VENTILATION. PRESENCE OF HYDROGEN FUMES COULD LEAD TO AN EXPLOSION!

1. Lower platform completely.
2. Disconnect BATTERY DISCONNECT halves (1, Figure 4-9) behind battery tray (2).
3. Remove mounting bolts (3) and battery tray top (4).
4. Tag and identify each cable or lead wire in battery tray to ensure proper connection to new batteries.
5. Remove terminal covers, loosen battery cable clamp bolts and remove clamps from battery posts.
6. Note orientation of each battery in battery tray.

7. Remove batteries from tray and install new batteries making sure battery posts are in proper positions.
8. Install battery cables to posts and tighten clamp screws.
9. Coat terminals with petroleum jelly or equivalent coating and install battery terminal covers
10. Connect BATTERY DISCONNECT halves (1).
11. Install battery tray top (4) and mounting bolts (3).
12. Check fluid level in each battery cell. As needed, add distilled water to raise level to split ring.

Hydraulic System Bleeding

The Quadrex hydraulic system is self-bleeding. After the system has been drained, such as during the replacement of a hydraulic system component, actuate the platform full up and down for six cycles and recheck the reservoir fluid level between each cycle. Fill to a point three inches below top of filler neck.



MEC4-9

Figure 4-9. Battery Replacement

Hydraulic Oil Filter Replacement

The hydraulic oil filter in the hydraulic system should be changed each year. The filter is located inside the compartment directly adjacent to the hydraulic oil reservoir on each model machine. While holding a drain pan beneath the filter, simply unscrew the old filter and install a new one. Check oil level in reservoir and add oil as necessary to bring level to a point three inches below the filler neck.

Bleeding Axle Lock Hydraulic System

NOTE

A special tool is needed to perform this procedure. A drawing of tool with all pertinent information is provided in Figure 4-15. Also, a 5/8" dia. X 5-1/4" long bolt and matching nut and a 3/16" inside diameter X 12 feet long black rubber hose are needed.

1. Remove lock nut (1, Figure 4-10) and upper cylinder pin (2) and pull axle locking cylinder (3) out of brackets (4).




Figure 4-10. Axle Lock Parts

2. Insert bolt (1, Figure 4-11)(5/8" X 5-1/4") through bottom hole of tool and through brackets (2) and install a 5/8" nut (3). Do not overtighten nut - tool should pivot freely on pin.
3. Insert upper cylinder pin (4) through upper hole of tool and through upper end (5) of cylinder. Secure with lock nut (6). Do not overtighten lock nut - tool should pivot freely on bolt.




Figure 4-11. Bleed Tool Mounting

4. Identify, tag and disconnect lead wires (1, Figure 4-12) from drive function solenoid valve coils in bottom front of lower electrical cabinet.




Figure 4-12. Drive Function Coil Wires

5. Install one end of a black rubber hose (3/16" inside dia. X 12 feet) into filler neck of hydraulic fluid tank. Install other end of hose on bleed valve (7, Figure 4-11) on top of cylinder. Open bleed valve.
6. Person A removes upper control box assembly from platform and prepares to drive unit forward while walking beside unit. Person A sets controls for slowest possible ground speed - SLOW SPEED, TORQUE switch to OFF, and THROTTLE CONTROL to IDLE.

7. While person A drives unit forward, person B pulls up on bleed tool and pushes down on bleed tool. Person B cycles lock cylinder up and down until all air is expelled and only oil comes out. Person B closes bleed valve. Person A releases control switches to stop unit.
8. Repeat this procedure to bleed other lock cylinder.
9. Remove hose from bleed valve (7) and raise to a height above hydraulic tank. Secure hose to platform and let fluid drain into hydraulic tank.
10. Connect lead wires (1, Figure 4-12) to solenoid valve coils and remove tags.
11. Align bolt hole in upper end (5, Figure 4-11) of lock cylinder as best as possible with holes in brackets (2) using bleed tool. Remove lock nut (6) and upper cylinder pin (4) from lock cylinder and bleed tool.
12. Remove nut (3) and bolt (1) from brackets (2) and bleed tool.
13. Place top of lock cylinder (3, Figure 4-10) between brackets (4) and install upper cylinder pin (2) and secure with lock nut (1).

Brake Adjustment



WARNING

THIS PROCEDURE REQUIRES THAT BRAKES BE INOPERABLE WHILE IN DRIVE MODE. ONLY PERFORM THIS PROCEDURE ON A LEVEL SURFACE WITH ENOUGH CLEARANCE IN FRONT OF MACHINE SO IT WILL ROLL TO A STOP OR WITH A BARRIER TO STOP THE UNIT.

1. Person A removes upper control box assembly from platform and prepares to drive unit forward while walking beside unit. Person A sets controls for slowest possible ground speed - SLOW SPEED, TORQUE switch to OFF, and THROTTLE CONTROL to IDLE.
2. When person A drives unit forward, person B pulls manual brake release ring (1, Figure 4-13) out to release brakes. Person A releases controls and lets unit coast to a stop.

3. Place chocks in front of and behind both front wheels.
4. Raise rear of machine enough that both tires and wheels are not touching floor.

NOTE

Both rear wheel brakes are independently applied. Both have to be adjusted at the same time.

5. Using a standard automotive brake adjustment tool, insert one end of tool in vertical slot (2) behind rear axle. Engage tool blade between stars and pry to turn star wheel.

5. Tighten star wheel until star wheel cannot be moved anymore. Then loosen star wheel 20 clicks or graduations of the star.

NOTE

The machine is designed to have the brake on whenever it is not being driven. Properly adjusted brakes should hold machine on an incline which it is capable of climbing.

6. Lower machine to floor, remove wheel chocks and drive unit to test brakes. Repeat procedure as necessary to obtain proper adjustment.

Gasoline Engine Service and Adjustment

Refer to ENGINE OWNER'S MANUAL.

OPTIONAL ELECTRIC GENERATOR MAINTENANCE PROCEDURES - MODELS 25SRT/33SRT

Generator Service and Adjustment

Refer to GENERATOR OPERATING MANUAL.

Belt Replacement

1. Remove bolts (1, Figure 4-14) and access cover (2).
2. Loosen nut and bolt that holds belt guide (3).
3. Remove old belt and place new belt on pulleys.




Figure 4-13. Brake Adjustment

4. Inspect pulley alignment. If necessary, align pulleys as follows:
 - a. Loosen set screw on pulley(s) that is out of alignment.
 - b. Slide pulley(s) on shaft until aligned with idler pulley.
 - c. Tighten set screw(s).
5. Position belt guide (3) and tighten bolt and nut.
6. Install access cover (2) and bolts (1).




Figure 4-14. Generator Belt Replacement




Figure 4-15. Axle Lock Cylinder Bleed Tool

CHAPTER 5 TROUBLESHOOTING

The troubleshooting data presented is directed toward the operator and deals with those items or situations which can be encountered by an operator and the determination of a remedy to the condition is within the capability of the operator. The troubleshooting sequence in the table is presented in a logical order beginning with the most likely and ending with the least likely.

TROUBLESHOOTING TABLE

Condition	Possible Cause	Remedy
	<u>MODELS 25SRT/33SRT</u>	
No functions at lower control panel.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	Engine not running.	Start engine.
No functions at upper control box assembly.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	Engine not running.	Start engine.
Platform will not lift using lower control panel.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	Engine not running.	Start engine.

TROUBLESHOOTING TABLE - Continued

Condition	Possible Cause	Remedy
	<u>MODELS 25SRT/33SRT-Continued</u>	
Platform will not lift using upper control box assembly.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold UP/DOWN switch in UP position to raise platform.
	Engine not running.	Start engine.
Machine will not drive.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold FORWARD/REVERSE switch in FORWARD or REVERSE position to drive machine.
	Engine not running.	Start engine.
Machine will not steer.	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold FORWARD/REVERSE switch in FORWARD or REVERSE position to drive machine.
	Engine not running.	Start engine.

TROUBLESHOOTING TABLE - Continued

Condition	Possible Cause	Remedy
	<u>MODELS 25SRT/33SRT-Continued</u>	
High engine speed not available at upper control box assembly.	PLATFORM/BASE switch on lower control panel in BASE position.	Place PLATFORM/BASE switch in PLATFORM position.
Engine will not run.	FUEL SELECTION switch in OFF position.	Place FUEL SELECTION switch in GAS or LPG position.
	Fuel shutoff valve on LPG tank closed.	Open fuel shutoff valve on LPG tank.
	Fuel tank(s) is empty.	Fill gasoline tank or install full LPG fuel tank.
Note: Refer to engine Owner's Manual for more troubleshooting information.		
	<u>MODELS 25E/33E</u>	
No functions at lower control panel.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
No functions at upper control box assembly.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped".	Reset circuit breaker.
Platform will not lift using lower control panel.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.

TROUBLESHOOTING TABLE - Continued

Condition	Possible Cause	Remedy
	<u>MODELS 25E/33E - Continued</u>	
Platform will not lift using lower control panel. - Continued	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
Platform will not lift using upper control box assembly.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold UP/DOWN switch in UP position to raise platform.
Machine will not drive.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold FORWARD/REVERSE switch in FORWARD or REVERSE position to drive machine.
Machine will not steer.	SAFETY switch not being held in MOTION position.	Place and hold SAFETY switch in MOTION position and, at the same time, place and hold FORWARD/REVERSE switch in FORWARD or REVERSE position to drive machine.


TROUBLESHOOTING TABLE - Continued

Condition	Possible Cause	Remedy
	<u>MODELS 25E/33E - Continued</u>	
Electric motors will not run.	EMERGENCY STOP switch on lower control panel or upper control box assembly is activated.	Raise cover and move switch handle to hinge side of switch cover.
	Key switch on lower control panel in OFF position.	Place key switch in ON position.
	Circuit breaker on lower control panel is "tripped."	Reset circuit breaker.
	Batteries not charged.	Charge batteries.
Battery charger not operating.	Power supply cable not connected to 115V receptacle and battery charger receptacle.	Connect power supply cable input end to 115V receptacle and output end to battery charger receptacle.
	Timer switch not on.	Turn timer switch on to desired position but at least to one hour setting.
	Fuse in battery charger blown.	Replace fuse.
	Battery cables loose or not connected at posts.	Clean and check all battery cable connections. Check Battery Disconnect connections behind battery tray boxes.
	Battery charger pilot light burned out.	Replace pilot light.
Battery charger pilot light on; charge rate ampere meter reads zero.	Batteries are fully charged.	Check optional Battery Charge Indicator or check specific gravity of battery.
	Charge rate ampere meter has failed.	Replace ampere meter.

SCHEMATICS, LAYOUTS AND DIAGRAMS


Electrical schematics, harness layouts, cabling layouts, and hydraulic schematic diagrams are furnished to help a well-trained millwright or maintenance person diagnose an undesired condition.

Figure 5-1. Quadrex 25SRT/33SRT
Dual Fuel Electrical Schematic




ART190

Figure 5-2. Quadrex 25E/33E Electrical Schematic - Standard Upper Control Box




ART303

Figure 5-3. Quadrex 25E/33E Electrical Schematic - Optional Joystick Upper Control Box




ART197

Figure 5-4. Quadrex 25SRT/33SRT Dual Fuel Electrical Harness Layout




ART345

Figure 5-6. Quadrex 25E/33E Electrical Harness Layout




ART346

Figure 5-6. Quadrex 25E/33E Battery and Motor Cabling Layout



ART343

Figure 5-6. Quadrex Hydraulic Schematic

ART154
BM5104

SECTION II


PARTS CATALOG

This section provides a separate chapter for each major division of the equipment. Each chapter contains illustrations of the major assemblies of each division with part numbers pointed out on the illustrations. A numerical index is provided at the end of this section which contains part descriptions.

CHAPTER 6
LOCATOR VIEWS AND DECALS


Figure No.	Figure Title	Page No.
6-1	Parts Catalog Locator View - 25SRT/33SRT	6-2
6-2	Parts Catalog Locator View - 25E/33E	6-3
6-3	Decals - 25SRT/33SRT	6-4
6-4	Decals - 25E/33E	6-5

Figure 6-1. Parts Catalog Locator View - 25SRT/33SRT



MEC6-1

Figure 6-2. Parts Catalog Locator View - 25E/33E



MEC6-2

Figure 6-3. Decals - 25SRT/33SRT





Figure 6-4. Decals - 25E/33E




ART335

**CHAPTER 7
HYDRAULIC VALVES**


Figure No.	Figure Title	Page No.
7-1	Hydraulic Line Layout.....	7-2
7-2	Primary Manifold	7-3
7-3	Secondary Manifold	7-4
7-4	Manifold Block	7-5

Figure 7-1. Hydraulic Line Layout




ART285

Figure 7-2. Primary Manifold




ART211

Figure 7-3. Secondary Manifold



ART-212

Figure 7-4. Manifold Block



ART246

CHAPTER 8
CONTROL BOX ASSEMBLIES

Figure No.	Figure Title	Page No.
8-1	Upper Control Box Assembly - Dual Fuel Units	8-2
8-2	Standard Upper Control Box Assembly - Electric Units	8-3
8-3	Optional Upper Control Box Assembly - Electric Units	
	Sheet 1 of 5	8-4
	Sheet 2 of 5	8-5
	Sheet 3 of 5	8-6
	Sheet 4 of 5	8-7
	Sheet 5 of 5	8-8

Figure 8-1. Upper Control Box Assembly - Dual Fuel Units






Figure 8-2. Standard Upper Control Box Assembly - Electric Units



ART-333

Figure 8-3. Optional Upper Control Box Assembly - Electric Units (Sheet 1 of 5)



ART187

Figure 8-3. Optional Upper Control Box Assembly - Electric Units (Sheet 2 of 5)

ART258




Figure 8-3. Optional Upper Control Box Assembly - Electric Units (Sheet 3 of 5)




Figure 8-3. Optional Upper Control Box Assembly - Electric Units (Sheet 4 of 5)



**ART219**

Figure 8-3. Optional Upper Control Box Assembly - Electric Units (Sheet 5 of 5)




SHOWN FROM BACKSIDE

ART-255

**CHAPTER 9
PLATFORM AND RAILINGS**

Figure No.	Figure Title	Page No.
9-1	Main Platform Rails	9-2
9-2	Main Platform	9-3
9-3	Extended Platform Rails	9-4
9-4	Extended Platform	9-5
9-5	Extended Platform Rail Lock Assemblies	9-6
9-6	Tip Alarm Assembly - 10775	9-7
9-7	Speed Limit Switch	9-8

Figure 9-1. Main Platform Rails



ART131

Figure 9-2. Main Platform

ART293





Figure 9-3. Extended Platform Rails



ART130

Figure 9-4. Extended Platform




Figure 9-5. Extended Platform Rail Lock Assemblies






Figure 9-6. Tip Alarm Assembly - 10775



ART-349

Figure 9-7. Speed Limit Switch




ART300

**CHAPTER 10
SCISSORS LIFT MECHANISM**

Figure No.	Figure Title	Page No.
10-1	Beam Section - 25 Feet	10-2
10-2	Beam Section - 33 Feet	10-3
10-3	Hose Guide	10-4
10-4	Scissors Lift Cylinder	10-5

Scissors Lift Mechanism

Figure 10-1. Beam Section - 25 Feet



Scissors Lift Mechanism

MEC QUADREX

Figure 10-2. Beam Section - 33 Feet






Figure 10-3. Hose Guide



681325
684874

Figure 10-4. Scissors Lift Cylinder



7519 WIRE HARNESS DOWN (NOT SHOWN)

6458 (NOT SHOWN) RETURN HOSE EMERGENCY
DOWN - 18 FT LONG.

RETURN HOSE CYLINDER VENT - 11 FT LONG
(ORDER HOSE IN 1 FT INCREMENTS)

7576 SEAL KIT LIFT CYLINDER (SERV.)

ART292

**CHAPTER 11
AXLE ASSEMBLY**

Figure No.	Figure Title	Page No.
11-1	Front Axle Assembly	11-2
11-2	Front Wheel Hub and Bearing - 7900	11-3
11-3	Steering Cylinder - 10329	11-4
11-4	Rear Axle Assembly	11-5
11-5	Oscillating Axle Mount	11-6
11-6	Brake Cylinder - 2483	11-7
11-7	Axle Lock Mechanism	11-8
11-8	Rear Step	11-9
11-9	Tires	11-10

Figure 11-1. Front Axle Assembly




ART254
BM5136

Figure 11-2. Front Wheel Hub and Bearing - 7900



ART302

Figure 11-3. Steering Cylinder - 10329



ART344

Figure 11-4. Rear Axle Assembly

ART287






Figure 11-5. Oscillating Axle Mount




BM4932

Figure 11-6. Brake Cylinder - 2483




ART164

Figure 11-7. Axle Lock Mechanism




ART332

Figure 11-8. Rear Step




ART348

Figure 11-9. Tires



QUAD ELECTRIC

7700 W/ PUNCTURE SEALANT *
 7701 FOAM FILLED
 7870 SOLID RUBBER
 7923 SOLID RUBBER - NON MARRING



QUAD SRT

7283 RIGHT HAND W/ PUNCTURE SEALANT *
 7290 LEFT HAND W/ PUNCTURE SEALANT *
 8087 RIGHT HAND - FOAM FILLED
 8088 LEFT HAND - FOAM FILLED

*** NOTE: PUNCTURE SEALANT IS
 TYRETYTE II TIRE SEALANT. FOR
 MORE INFORMATION:**

**TYRETYTE INTL. TIRE SEALANT
 P.O. BOX 506
 CAMPBELL, CA 95009
 (408) 993-1010**

ART378
 BM5259

CHAPTER 12
COMPARTMENTS - DUAL FUEL UNITS

Figure No.	Figure Title	Page No.
12-1	Compartments and Panels.....	12-2
12-2	Compartment Bases	12-3
12-3	Lower Electric Cabinet	12-4
12-4	Lower Control Station.....	12-5
12-5	Fuel Tanks Assembly	12-7
12-6	Hydraulic Fluid Reservoir	12-8
12-7	Battery Box Assembly	12-9
12-8	Engine Assembly.....	12-10
12-9	Engine Panels and Generator Option	12-11
12-10	Emergency Down Control and Axle Lock Height Limit Switch	12-12
12-11	Height Limit Switch Assembly - 10732	12-13

Figure 12-1. Compartments and Panels

ART-288





Figure 12-2. Compartment Bases



ART321

Figure 12-3. Lower Electric Cabinet




ART301
BM4935

Figure 12-4. Lower Control Station



ART304


Figure 12-5. Fuel Tanks Assembly



ART324
BM4857


Figure 12-6. Hydraulic Fluid Reservoir

FIG. 3




ART379
BM5302

Figure 12-7. Battery Box Assembly



ART-323
BM4853

Figure 12-8. Engine Assembly




6853 ENGINE
 6942 AIR FILTER (NOT SHOWN)
 6979 SOLENOID/START (NOT SHOWN)
 7945 SUCTION HOSE (NOT SHOWN)

OIL SWITCH
 35 COM / 16 NC / 21 NO
 THROTTLE
 6 — — — 38 KILL (WHITE)
 — — — + BLACK
 A +

CHOKE
 35 — — — 36 L.P.
 21 — — — 16


ART361

Figure 12-9. Engine Panels and Generator Option




ART-262
BM4822

Figure 12-10. Emergency Down Control and Axle Lock Height Limit Switch



ART210

Figure 12-11. Height Limit Switch Assembly - 10732




ART319

CHAPTER 13
COMPARTMENTS - ELECTRIC UNITS

Figure No.	Figure Title	Page No.
13-1	Compartments and Panels	13-2
13-2	Compartment Bases	13-3
13-3	Lower Electric Cabinet	13-4
13-4	Lower Control Station	13-5
13-5	Motors Assembly and Battery Charger	13-6
13-6	Motors Assembly	13-7
13-7	Battery Charger and Panel Assembly	13-8
13-8	Battery Charger	13-9
13-9	Hydraulic Fluid Reservoir	13-10
13-10	Battery Box Assemblies	13-11

Figure 13-1. Compartments and Panels



681337

Figure 13-2. Compartment Bases

ART321





Figure 13-3. Lower Electric Cabinet



ART284

Figure 13-4. Lower Control Station






Figure 13-5. Motors Assembly and Battery Charger



ART206
BM4931

Figure 13-6. Motors Assembly



ART144

Figure 13-7. Battery Charger and Panel Assembly


ART-208
BM4925

Figure 13-8. Battery Charger




Figure 13-9. Hydraulic Fluid Reservoir





Figure 13-10. Battery Box Assemblies





ART-209
BM4924

**CHAPTER 14
OUTRIGGERS**


Figure No.	Figure Title	Page No.
14-1	Outrigger Control Box	14-2
14-2	Outrigger Junction Box.....	14-3
14-3	Outrigger Posts	14-4
14-4	Outrigger Manifolds	14-5

Figure 14-1. Outrigger Control Box




ART308

Figure 14-2. Outrigger Junction Box




ART309
BM4938

Figure 14-3. Outrigger Posts



ART338

Figure 14-4. Outrigger Manifolds



ART312
BM5163

**CHAPTER 15
MISCELLANEOUS**

Figure No.	Figure Title	Page No.
15-1	Clamps, Fasteners and Trim	15-2
15-2	Repair Kits and O-rings	15-3
15-3	Numerical Part Number Index	15-4

Figure 15-1. Clamps, Fasteners and Trim




Figure 15-2. Repair Kits and O-rings

REPAIR KITS

<u>Part Number</u>	<u>Part Name</u>	<u>Description of Item</u>
5475	Seal Kit	Fits 2-way cartridge valves, part numbers 5434, 5435, 6316, 6973, 6974, 6975, 7765 and 10915.
5476	Seal Kit	Fits 3-way cartridge valves, part numbers 5954, 6976 and 7445.
6161	Spring & O-ring Kit	Fits 4-way block valves, part number 7976.
6806	Seal Kit	Fits counterbalance valve, part number 6712.
6675	Swivel O-ring Kit	Fits 90 degree swivel hose fitting, part number 7466.
5947	Cylinder Seal Kit	Fits brake and steering cylinder, part numbers 2483 and 10329.
7578	Seal Kit	Fits hydraulic drive motor, part number 7300P.
7574	Cylinder Seal Kit	Fits axle locking cylinder, part number 7147.
4041	Brush & Spring Kit	Fits electric motor, part number 7479.

INDIVIDUAL O-RINGS

<u>Part Number</u>	<u>Size</u>
7563	7/16-20
7564	9/16-18
7565	3/4-16
7566	7/8-14
7882	7/8 x 1-1/8
7901	2-1/4 x 2-1/2

Figure 15-3. Numerical Part Number Index

This figure is a numerically sequenced (lowest to highest) listing of all Quadrex 25SRT/33SRT and 25E/33E part numbers with a part description or nomenclature. This listing is provided for your convenience since the parts catalog illustrations reflect only the part number.

A peculiarity of the part description is the use of a coding scheme for descriptions of "commercial standard" items, such as, nuts, washers, screws, etc. An explanation of the coding scheme, which is an industry standard, is not provided because of its size and complexity. However, should you need clarification of the description coding for an item, please feel free to call us at 1-414-387-4500.

Part No.	Description	Part No.	Description
1313	SWITCH GUARD	3782	DIRECTIONAL CAM - JS
2170	PULL HANDLE	3788	COVER ASS'Y - MANUAL TUBE
2483	BRAKE CYLINDER ASSY.	3794	CONTROL GRIP - JOYSTICK
2485	CYLINDER WELDMENT - BRAKE	4056	STOP SLEEVE
2493	CYLINDER HEAD	4171	SWITCH GUARD - END
2494	PISTON, CYLINDER	4268	WRAPPER WELDMENT - EE SERIES
2504	CYLINDER ROD - BRAKE	4269	COVER-CONTROL BOX-EE SERIES
2987	HOLD DOWN ROD	4271	FRONT & BOTTOM PANEL-EE SERIES
3103	INNER BRAKE ACT - REP BY 8467	4566	ROD HOLD DOWN
3110	ROLLER, BASE	4678	SPACER WASHER - PLATFORM
3199	JUMPER CONTACTOR	4773	WASHER
3219	LOWER BRACKET - MAINT LOCK	5005	NUT, HEX KEPS 5/16-18ZN
3419	GAS TANK	5033	NUT, HEX KEPS 1/2-13ZN (REP 8457)
3428	COVER - GENERATOR PANEL	5039	NUT, HEX, KEPS 3/8-16 ZN
3436	HOLD DOWN BAR - BATTERY	5202	BTCAPHEXFG0.500 131.00Z5 2AN
3447	WRAPPER WELDMENT	5204	BTCAPHEXFG0.312 181.00Z5 2AN
3450	FRONT & BOTTOM PANEL	5216	WASHER, FLAT 1/2 ZN
3451	COVER - CONTROL BOX	5230	SWITCH, TOGGLE
3466	BACK PLATE - RELAY BOARD	5232	BUSHING, STRAIN RELIEF 18/3
3470	GENERATOR	5275	SWITCH, TOGGLE
3578	GROUND BRACKET - DIODES	5276	NUT, HEX 1/4-20 ZN
3648	BEARING - BRAKE ROD	5290	PIN, COTTER 5/32 X 1.50
3751	CENTERING BRACKET - JOYSTICK	5355	WASHER, FLAT 1.00X.406X.100 ZN
3759	PLATE BOTTOM - CONTROL BOX JS	5363	BTMACHEXWR #6 321.00Z5 2AN
3763	SPACER STEP - JOYSTICK	5364	NUT, HEX, KEPS #6-32 ZN
3764	SPACER PLATE - JOYSTICK	5385	BTMACSELF #8 320.38Z5 Y
3765	STRAP PLATE - JOYSTICK	5417	BTCAPHEXFG0.375 161.25Z5 2AN
3766	TOP PLATE WELDM'T-JOYSTICK	5432	GREASE FITTING
3768	WASHER, ORING SPACER-JOYSTICK	5434	VALVE, CHECK-IN LINE
3769	BRKT. RELAY "C" BOARD-JOYSTICK	5435	VALVE, MANUAL PULL
3770	SPRING, SPEED LEVEL, JOYSTICK	5527	CLIP
3771	WASHER RETAINING - JOYSTICK	5556	TIMER KNOB
3772	COVER WELDM'T - JOYSTICK	5630	SWITCH SLOW SPD-EM STOP ON/OFF
3773	CONTROL BOX WELDMENT-JOYSTICK	5636	BTMACSTRND #6 320.25Z2 2AN
3780	ARM WELDMENT - ASSEMBLY	5642	TIMER
3781	CAM, SPEED CONTROL - JS	5643	TIMER DIAL PLATE

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
5694	SWITCH	6434	BTCAPHEX 0.375 162.00Z5 2AN
5710	PIN,CLEVIS 1/2 X 1 1/4	6435	BTCAPHEX 0.500 132.50Z5 2AN
5723	BTMACSELFT0.250 200.75Z5 Y	6455	BTCAPSELFT0.250 200.50Z5 Y
5736	RING,RET.,EXT., 1/2 SHAFT	6456	CORD GRIP - STEEL
5738	PIN,COTTER 3/16 X 1-1/2	6458	RETURN LINE HOSE
5785	WASHER,FLAT 5/8 ZN	6459	NPTF BAYONET FITTING,5/16X1/4
5866	BEARING	6463	LOCK NUT (NYLON) ZINC 1/2-13
5875	WASHER,LOCK,INT.TH 1/2	6504	SWITCH, OUTRIGGER
5901	WASHER, CAM THRUST	6510	FITTING, ELBOW 1/2X1/2 NPT L.P
5912	BEARING CAM, 16DU24	6511	TEE 1/2X1/2X1/2 NPT L.P.
5916	BTCAPSOCKET0.500 134.00B8 2AN	6557	DECAL - EMERGENCY DOWN
5918	RET. RNG-EXT-HD-100-SP-P	6633	FLEX LOCK NUT
5920	PIN COTTER 1/8 X 1.00 ZN	6655	1/4" STREET TEE-STEEL
5936	SWITCH-KEY	6669	BEARING-32DU32
5947	SEAL KIT FOR 5677 & 5678	6676	WHEEL LUG BOLT 1/2-20 THREAD
5954	VALVE, PRIORITY FLOW CONTROL	6687	CONNECTOR/CABLE ASSY - HANDY
5978	BTMACSELFT #6 320.25Z5 Y	6688	KLIPTING 2" SHAFT
5979	SWITCH	6701	RETAINING RING - 2" SHAFT
5991	TERMINAL BLOCK-REQ (1) 7817	6712	COUNTER BALANCE VALVE
5995	HYDRAULIC HOSE	6714	FILTER HEAD,HM REQ (2) 6752
6011	CABLE CLAMP	6715	LIMIT SWITCH
6029	SCREW, THRD. ROLL. 1/4-20X1.50	6724	H.P. SAE ADAPTER 90 DEG ELBOW
6063	CLAMP	6727	90DEG BRASS ELBOW-5/16" BAYONET
6064	CLAMP	6748	BTCAPHEX 0.375 163.50Z5 2AN
6070	DIODE ASSY	6749	SPRING - EXTENSION 4" LONG
6110	NUT, WING, 1/4-20, ZN PLT	6751	LYNCH PIN - 1/4"
6121	TRIM - .250	6752	REDUCER - FITTING 3/4X1/2 NPTF
6156	OIL FILTER CARTRIDGE	6823	CAPLUG 1 1/4" SQ. TUBING
6208	BATTERY JUMPER	6839	DECAL - AWP LOGO
6211	BTCAPHEX 0.500 131.25Z5 2AN	6853	ENGINE-GAS/LPG-HM-SHIP(1)6306
6241	DIODE ASSY	6854	HOUR METER
6247	BTSFPSOCKET0.500 131.50B8 2AN	6857	HOUR METER
6248	NUT, HEX JAM 1/2-13 BO	6859	PROPANE TANK
6281	NUT,HEX, 2 WAY LOCK 3/8-16 ZN	6860	MOUNTING BRKTS - LPG TANK
6314	COUPLER (J.S BARNES PUMP)	6861	BULKHEAD FILTER
6316	ADJ RELIEF VALVE	6863	ELBOW - MALE 1/8" BRASS
6337	INTERNAL RETAINING RING	6864	ADAPTER, PUMP 3/4 X 5/8 STEEL
6338	NUT, HEX TOP LOCK 1/2-20	6865	ELBOW 3/4 NPT BRASS
6342	TUBING END PLUG	6868	QUICK DISCONNECT
6343	FITTING EXT, 1/4 X 1/4 H.P	6870	COIL 12 V 1 SPADE ASY W/DIODE
6349	LOCKNUT - 2 WAY 1/2-13 ZINC	6877	PULLEY 4" 1 1/8" BORE
6431	WASHER, FLAT 1/4" ZINC	6878	PULLEY 4 1/2" 1" BORE
6432	BTCAPHEXFG0.375 160.75Z5 2AN	6880	IDLER PULLEY
6433	BTCAPHEXFG0.375 161.00Z5 2AN	6881	CONTROL CORD OUTLET

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
6882	CONTROL CORD	7051	HOSE ASSEMBLY
6883	REGULATOR - LP	7052	BTCAPHEX 0.500 133.50Z5 2AN
6884	VAPORIZOR - REGULATOR - LPG	7081	TRIM LOCK SEAL
6885	ENGINE ADAPTER KIT - LP GAS	7115	PLUG, PRY OUT HOLE
6886	GASOLINE SHUTOFF VALVE	7137	CYL. ASSY. HVD. OUTRIGGER
6887	OIL PRESSURE SWITCH	7139	TAB ADAPTER MALE
6888	FRONT PULLEY ENGINE MOUNT	7147	CYLINDER - AXLE LOCKING
6889	POWER RELAY 12 VOLT DC 25 AMP	7153	PLATFORM GATE SPRING
6890	HOSE ASSEMBLY	7156	FRONT DECAL
6894	MALE ELBOW FITTING	7164	HOSE CLAMP 5/16 I.D. HOSE
6895	MALE 45 DEG ELBOW FITTING	7172	TERMINAL INSULATOR BOOT(BLACK)
6896	STRAIGHT FITTING	7173	TERMINAL INSULATOR BOOT (RED)
6905	TOGGLE SWITCH	7196	BEARING 22DU28 1-3/8ID X 1-3/4
6906	INDICATOR LIGHT	7231	BTMACSTHEX #6 321.25Z5 2AN
6910	KEY 1/4" x 1/4" X 1 1/4"	7235	CIRCUIT BREAKER-15 AMP MANUAL
6913	DECAL-ENGINE CONTROL	7269	HARNESS - SLOW SPEED LIMIT-DYN
6919	SHUT OFF VALVE - GAS LINE	7273	RELAY BOARD, SOLID STATE
6922	ALARM BUZZER 12 VOLT	7292	BEARING, SLEEVE BRONZE
6923	STREET ELBOW BRASS	7293	ROD END BALL JOINT
6924	HEX NIPPLE BRASS 1/4	7297	QUICK DISCONNECT - MALE
6926	BAYONET FIT	7300	HYD WHEEL MOTOR 45 3/IN
6927	BAYONET FITTING 1/2 X 3/8	7300P	HYD.WHEEL MOTOR-PAINTED
6929	ELBOW 45 DEG MALE 1/4 BRASS	7305	NIPPLE,HEX REDUCING 1/4 X 3/8
6938	RELIEF VALVE L.P GAS	7312	BTCAPHEX 0.500 134.50Z5 2AN
6939	HOSE-AIR INTAKE	7314	PLG,O-RING SOCKET HX STL ZINK
6940	OIL FILTER CARTRIDGE	7326	BTCAPHEX 0.625 114.00Y5 2AN
6941	MUFFLER (KOHLEER ENGINE)	7355	SPRING, BRAKE
6942	AIR FILTER (KOHLEER ENGINE)	7355P	BRAKE SPRING (PAINTED)
6946	DUAL DIODE ASSY	7362	36 HYD. TUBE ASSY.
6947	TERMINAL STRIP - REQ (1) 7970	7364	#39 HYD. TUBE ASSY.
6960	HOSE CLAMP 3/4" HYD. HOSE	7365	#40 HYD. TUBE ASSY.
6964	CABLE CLAMP 1"	7370	SPRING, BRAKE ADJUSTER
6972	HOSE - L.P. GAS	7371	PINS, HOLD DOWN
6973	VALVE N.C. POPPET 2 WAY	7372	CUP, HOLD DOWN (OUTER)
6974	VALVE NO POPPET 2/W-REQ 1-6983	7373	CUP, HOLD DOWN (INNER)
6975	VALVE N.O. SPOOL 2 WAY	7374	SPRING, HOLD DOWN
6976	VALVE 3 WAY 2 POSITION	7377	ADJUSTING SCREW (BRAKE)
6979	SOLENOID, START	7381	HOSE, AXLE CYLINDER
6982	SOLENOID, IDLE	7382	HOSE, WHEEL MOTOR DRAIN
6986	NUT - DRIVE MOTOR - ZINC	7383	HOSE, STEERING CYLINDER
7032	NUT RETAINER 5/16-18	7384	HOSE, DRIVE & PUMP
7038	CLAMP, EMERGENCY DOWN TUBE	7385	FITTING 90 DEGREE
7041	CABLE CLAMP, DBL TUBE W/VINYL	7386	FITTING, ADAPTER SAE O RING
7042	CABLE CLAMP, STEEL W/VINYL 1"	7387	FITTING OR 7/8-14 X 3/4-16 STL

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
7388	FITTING 45 DEG. ELBOW	7601	FITTING, ELBOW
7389	FITTING OR, 3/4-16XJIC 9/16-18	7620	DECAL,UPPER CONT.BOX-EE SERIES
7393	ROLLER,EXT. PLATFORM 1 1/2 X 4	7621	DECAL-CONT.BOX SIDE-EE SERIES
7396	CLEVIS PIN 1/2 X 3 LG.	7622	SWITCH GUARD-EMERGENCY STOP
7399	BTCAPSCKFT0.312 180.50Z8 2AN	7633	SWITCH, TOGGLE (EE SERIES)
7400	BTCAPHEX 0.375 164.00Z5 2AY	7656	WIRE HARNESS-UPPER CONTROL DM
7406	HOSE ASSEMBLE - L.P.GAS	7657	HARNESS-CONTROL BOX - DM
7408	SPRING, DECK LOCK	7658	WIRE SET-CONTROL BOX-HT-DM
7414	KNOB POTENTIOMETER	7671	DECAL - BASE CONTROL HM
7433	FLOOR BOARD, PLATFORM	7674	COIL, 48 DOUBLE SPADE EQ
7435	ALARM, TIP OVER	7676	DECAL - CONTROL BOX TOP - DF
7438	FITTING, 9/16X18OR-9/16-18 JIC	7677	DECAL - CONTROL BOX SIDE DF
7440	BEARING 32DU24	7679	LIGHT, INDICATOR YELLOW
7441	BTCAPSOCKET0.500 135.00B8 2AN	7681	LAMP, DIALIGHT
7442	BTSFPSOCKET0.375 161.00B8 2AN	7684	BTMACHEX #6 321.50Z2 2AN
7445	VALVE, PILOT OPER. BALL CHECK	7688	CONTACTOR 48 VOLT DC
7461	WIRE HARNESS-SCISSORS	7689	CHARGER 48V DC 110V AC - 60HZ
7466	HOSE ASSEMBLY, LIFT	7695	FUEL GAGE, BATTERY 48V D.C.
7468	BTCAPHEX 0.438 141.00Z5 2AN	7697	LATCH, DOOR T-HANDLE
7478	BRAKE HOSE ASSEMBLY	7712	FILTER, SUCTION 1-1/4 NPT
7479	MOTOR - 48 VOLT D. C.	7714	BEARING,TAPERED ROLL. 1.5" ID
7488	LIMIT SWITCH	7715	BEARING,TAPERED ROLL.1.25"ID
7489	FITTING, ADAPTER 1/2 X 3/8	7716	RACE, BEARING TAPERED
7491	VALUE, MANUAL RELEASE	7717	RACE, BEARING TAPERED
7492	TERMINAL BLOCK	7719	CAP, GREASE
7495	JUNCTION BOX	7722	TUBING - 2WD - #1
7508	FITTING,BRASS 5/16 X 1/8	7723	TUBING - 2WD - #2
7509	FITTING, BRASS 1/8 HEX NIPPLE	7724	TUBING - 2 WD - #3
7510	SPRING, WIRE PROTECTOR	7725	TUBING - 2 WD - #4
7518	CABLE ASSEMBLY-BRAKE RELEASE	7726	TUBING - 2WD - #5
7519	DOWN, WIRE HARNESS	7727	TUBING - 2WD - #6
7521	TUBING ASS'Y - RETURN LINE	7728	TUBING - 2WD - #7
7526	110 AC KIT - QUAD. 33 FT.	7729	TUBING - 2WD - #8
7528	WIRE HARNESS-WARNING HORN	7730	TUBING - 2WD - #9
7529	OPERATING MANUAL - QUADREX	7731	TUBING - 2ND - #10
7552	LVL. SEN.4-1/2 DEG.-1 SEC.DEL.	7732	TUBING - 2WD - #11
7553	ALARM, TIP OVER	7733	TUBING - 2WD #12
7555	WIRE HARNESS 25 FT	7742	HARNESS BATTERY 2WD - ELECTRIC
7556	VOLTAGE REGULATOR ASS'Y	7749	HOSE ASSY. PUMP TO MANIFOLD
7558	COUPLER LOVEJOY GENERATOR	7751	WIRE HARNESS - MANIFOLD-ELECT
7561	BTMACSTTRS #6 320.75Z5 2AN	7753	HARNESS CABINET CROSSOVER
7576	REPAIR KIT, LIFT CYL.	7754	HARNESS LOW CONT PANEL-ELEC
7579	PLUG, PLASTIC (TOGGLE HOLE)	7755	HARNESS 2WD-33' GAS ELECTRIC
7593	PIN, SAFETY SNAP	7756	HARNESS 2WD 33' GAS-ELECTRIC

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
7757	HARNESS 2WD 33' GAS-ELECTRIC	7901	O-RING
7758	HARNESS 2WD 33' (GAS)	7903	DECAL, SWITCH SERV QUAD-SRT
7759	HARNESS 2WD 25' ELEC-GAS	7906	HARNESS-CIRC. BRD.-KHLR DF-SRT
7760	HARNESS 2WD 25' ELEC-GAS	7907	WIRE HARNESS, CROSSOVER-SRT-DF
7761	HARNESS 2WD 25' ELEC-GAS	7908	WIRE HARNESS-BASE CONTROLS-SRT
7763	HOSE HYD. LOW PRESS	7909	HOUR METER 24-48 VOLT DC
7764	FIT, BRASS MALE (S.22) 1/2X3.8	7911	HARNESS-MANIFOLD-KOHLER DF-SRT
7765	PLUG, CAVITY 2 WAY	7915	WIRE HARNESS, WARNING ALARM-SRT
7768	FITTING NIPPLE 3/4" NPT X 2"	7916	WIRE HARNESS, LIM. SWT. & LEV. SRT
7771	FITTING 1/2X1/2 STEEL ELBOW	7918	PIN - COILED SPRING
7772	TUBING - 2WD - #14	7919	HARNESS WIRE 25' SRT
7773	TUBING - 2WD - # 15	7920	HARNESS WIRE - 33' SRT
7778	BTCAPFLTPH0.250 201.25Z2 2AN	7921	WIRE HARNESS JS-COVER
7779	ELBOW, JIC TO O-RING 1/2 X 3/8	7922	WIRE HARN.#1-UPP.CONT.BOX-SRT
7780	FITTING, JIC TO O RING TEE 3/8	7926	WIRE HARNESS JS-HT
7784	FUSE - 225 AMP	7929	FITTING, 1/2X1/2 JIC-JIC 90 DEG
7785	FUSE HOLDER	7931	BEARING, TAPERED R 1" BORE
7786	FLOW CONTROL	7932	BEARING, TAPERED R 1 1/16" BORE
7788	CLAMP, HOSE	7933	RACE, BEARING TAPERED
7806	LIGHT, INDICATOR	7934	HOSE ASSEMBLY STEERING
7815	TORSION SPRING (JOY STICK)	7938	BTCAPHEX 0.625 113.00Z5 2AN
7817	STRIP-BACKING-15 PST	7945	HOSE, .75" ID LOW PRESS - 51.5
7818	BEARING, BRONZE FLANGED	7946	CAP, BATTERY SINGLE CELL
7819	BEARING, BRONZE FLANGED	7961	NUT, LUG 1/2 - 20 90 DEGREE
7820	SPRING - TORSION - BRAKE LOCK	7970	STRIP MARKER 1-22
7826	WIRE HARNESS	7976	VALVE, DOI 4 WAY 3 POS TANDEM
7827	DECAL - WARNING LIGHT-QUADREX	7978	PUMP, HYD. GEAR
7828	DECAL - DIRECTIONS - JOYSTICK	7984	HOSE ASS'Y. PUMP TO MANIFOLD
7829	HARNESS - 16' - DYNA-6,12-15	7997	HOLD DOWN - BATTERY
7831	CIRCUIT BOARD - JS -	8000	DECAL CONTROL BOX-OUTRIGGER
7834	SWITCH LIMIT MICRO	8005	CONNECTOR, CORD 90 DEG
7835	RELAY, 24 VOLT	8006	NUT, CONNECTOR 1/2" CONDUIT
7865	TERMINAL, COUPLER 1/4" SPADE	8007	PIN, CLEVIS 5/8 X 4 1/2 ZINC
7875	GASKET - JOYSTICK	8012	WIRE HARNESS OUTF CONTROL BOX
7878	FITTING S116J F.TOM 90 DEG	8022	DECAL
7881	WASHER-SPRING	8044	SWITCH-MOTION OUTRIGGER
7882	O-RING 7/8 ID X 1.125 OD	8053	WIRE HARNESS ELEC. OUTRIGGER
7883	SUPPORT, CIRCUIT BOARD - JS	8054	WIRE HARNESS AUX TO MANIFOLD
7884	BTMACSTRND #4 401.00Z5 2AN	8055	CIRCUIT BOARD
7885	BTMACSTRND #4 400.25Z5 2AN	8056	WIRE HARNESS AUX TO OUTRIGGER
7887	BTCAPSOCKET #6 320.50Z8 2AN	8068	ROCKER-SWITCH LEVER
7888	BTCAPPHTRS #10 320.50Z2 2AN	8069	SWITCH-SNAP
7895	DECAL, LIFT DIRECTIONS, JOYSTICK	8070	BOOT-ROCKER
7900	HUB ASSY.	8071	BTMACSTPAN M30.5030.0Z 4g6gN

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
8073	BTMACSTPAN M30.5010.0Z 4g6gN	10264	ROLLER AXLE WELDMENT
8075	SWITCH, SELECTOR 3 POS.	10267	ROLLER AXLE WELDMENT
8076	BASE-MOUNTING W/2 CONTACT BLKS	10270	AXLE - REAR WELDMENT
8082	BLOCK - CONTACT N.O.	10278	MANIFOLD - AXLE CONTROL
8135	BOOT, TERMIANL INS BLACK	10283	REAR AXLE BASE WELDMENT
8136	BOOT, TERMINAL INS. RED	10324	MOUNTING BLOCK SCISSORS
8199	MAINT LOCK WELDMT (WAS 10377)	10329	ATV STEERING CYLINDER ASSEMBLY
8220	RELAY, 48 VOLT	10335	TUBE INNER OUTRIGGER - ATV
8221	CLIP, SPRING	10339	OUTRIGGER COVER
8236	KING PIN FRONT AXLE (WAS 10819)	10340	OUTRIGGER - FOOT WELDMENT
8305	BTCAPHEX 0.312 181.75Y8 2AN	10343	TUBE WELDMENT - OUTRIGGER
8348	ROLLER SHAFT EXT.TUBE-REP 3608	10350	LOCK CHANNEL
8437	AMMETER 48 VOLT CHARGER	10354	CYLINDER PIN - LOWER
8438	CAPACITOR 48 VOLT CHARGER	10355	CYLINDER PIN - UPPER
8439	CIRCUIT BREAKER 48 VOLT CHARGER	10417	MTG. BRKT. WELD. - RH PLATFORM
8440	DIODE 48 VOLT CHARGER	10423	PIVOT PIN WELDMENT
8441	POWER TRANSFORMER 48VOLT CHRGR	10424	AXLE GUIDE - NYLON - ATV
8442	VARISTOR 48 VOLT CHARGER	10425	MTG. BRKT. WELD. - LH PLATFORM
10012	BASE WELDMENT - ATV	10426	BRAKE CHANNEL - WELDMENT
10013	CYLINDER PIN - REP 8335	10428	BRK'T BRAKE CYL. WELD -QUAD
10015	CYL. PIN LOCK PLATE	10445	BRAKE BUSHING
10018	MTG. PIVOT PIN - REP 8338	10450	BRAKE ROD WELDMENT
10019	BEAM WELD - OUTER - 1/4 X 3X8	10451	RAILING HINGE WELDMENT-R.H.
10020	BEAM - WELD - OUTER - .187X3X8	10454	PIN ADJUSTING PLATFORM
10021	BEAM WELD - OUTER - .187 X 3X6	10469	TUBING SUPPORT
10025	INNER BEAM WELD-CYL.MTG LOWER	10476	LOCK LEVER
10026	INNER BEAM WELD CYL.MTG-UPPER	10479	COVER-CABLE TRAY - LH FRONT
10027	INNER BEAM WELD-CENTER	10480	COVER-CABLE TRAY - RH FRONT
10028	INNER BEAM WELD-UPPER	10481	COVER-CABLE TRAY (REAR)
10041	CYLINDER ROD	10485	ADJUSTING PIN SHAFT
10043	STEP WELDMENT - REAR	10493	RAILING HINGE WELDMENT-L.H.
10048	CYLINDER WELDMENT - STEERING	10504	BEAM, LIMIT BLOCK
10090	INSERT - BRAKES	10505	TOP RAILING SUPPORT
10093	BRAKE PAD WELDMENT	10506	RAILING SUPPORT SIDE
10096	BRAKE CAM	10507	BRACKET - LIMIT SWITCH
10097	BRAKE PLATE WELDMENT	10511	UPPER LIMIT - SWITCH PLATE
10128	PLATFORM WELDMENT - ATV	10512	RAIL WELDM'T REAR-DROP DOWN
10148	HINGE LOCK WELDMENT	10513	WELDMENT FRONT DROP DOWN
10156	PIN ROLLER-PLATFORM (REP 8340)	10514	DROP DOWN RAIL MOUNT
10157	PIN ROLLER-PLATFORM (REP 8340)	10520	EMERGENCY DOWN ASS'Y QUAD.
10207	EXT PLATFORM ROLLER WELDM'T LH	10525	PLATFORM ROLLER STOP PLATE
10214	EXT PLATFORM ROLLER WELDM'T RH	10526	ORFICE-BRAKE 1/8 NPTF
10231	GATE WELDMENT - REAR	10530	ROLLER CHANNEL WELDMENT
10255	EXT.PLTFM RAIL FRONT WELDM'T	10537	EXT. PLATFORM RAILING LH

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
10538	EXT. PLATFORM RAILING RH	10778	SUPPORT WELDM'T R.H.-EUROPE
10549	CONTROL CORD GUARD-SHORT	10780	BATTERY TRAY WELDMENT
10550	CONTROL CORD GUARD-LONG	10788	MOTOR PLATE QUAD-SRT
10552	RAILING CAP WELDMENT L.H.	10791	IDLER BELT GUARD WELDMENT-SRT
10553	RAILING CAP WELDMENT R.H.	10792	IDLER ARM-SRT
10561	LATCH PIN, REAR GATE	10795	TOP COVER WELDMENT-SRT
10574	COVER, CONNECTOR	10797	BULKHEAD, REAR/BACK WELD.-SRT
10577	**MANIFOLD ASY - AXLE CONTROL	10798	FRONT BULKHEAD WELDMENT-SRT
10587	**LOCK ASS'Y LH - ROLLOUT-Q	10804	MTG PLATE WELD FUEL TR-SRT
10588	**LOCK ASSY-RH - ROLLOUT-Q	10806	BRAKE ROD WELDMENT
10595	STEP REAR WELDMENT - SHORT	10808	REAR AXLE WELDMENT
10599	BRKT. R.H. MTG. (ELEC)	10809	STEERING ARM - ELE - SRT
10600	BRKT. L.H. MTG. (ELEC)	10818	WASHER BEARING SUPPORT
10632	TRAY CABLE - ELECTRIC	10821	GENERATOR PKG. - SRT
10633	BRACKET MTG.(CABLE TRAY)-ELECT	10822	PLATE-BUZZER-SRT
10641	DOOR WELDMENT CABINET - ELECT	10823	STRAP-BUZZER-SRT
10654	BRACKET - TUBE SUPPORT	10824	BRACKET ENGINE SWITCH-SRT
10670	COVER WELDMENT - BATTERY TRAY	10829	HEAT SHIELD-SRT
10671	MTG. BLOCK - UPPER TERM.	10832	BELT GUIDE - GEN - SRT
10692	BRACKET-BATTERY HARNESS-ELECT	10836	FRONT AXLE WELDM'T-ELECT-SRT
10707	LIMIT SWITCH ASS'Y - Q.ELEC	10837	KING PIN HOUSING WELDMENT RH
10708	METERING PLUG-ELECTRIC	10838	KING PIN HOUSING WELDMENT LH
10719	RAIL WELD, FRONT, STD.	10839	MTG. BRKT SHROUD - LEFT - SRT
10720	KICK PANEL WELDMENT	10840	WELDMENT-ENG. SHROUD R.H.-SRT
10722	**BOX CTRL-UPPER HT-QUADELEC	10841	GUARD-WELD EXHAUST-SRT QUAD
10726	PLATE MTG. TILT ALARM	10842	COVER WELD-FRONT-SRT QUAD
10727	HANDLE - PUSH /PULL WELDMENT	10843	COVER-ACCESS-GEN-SRT QUAD
10731	CLIP, HANDLE	10844	SHROUD,ENGINE LEFT-SRT QUAD
10732	LOWER LIMIT SWITCH ASS'Y	10845	COVER WELD-ACCESS (NO GEN) SRT
10739	TRAY WELDMENT R.H	10846	PLATE JUNCTION - SRT
10740	TRAY WELDMENT L.H	10847	HUB ASS'Y - REAR - QE
10744	TUBE SUPPORT TRAY-EUR	10849	**CONT. BOX ASS'Y - UPPER-SRT
10745	CABINET ELECT-EUR	10852	FITTING, BLEEDER
10748	COVER WELDMENT-EUR	10853	BLEEDER
10750	INSTRUMENT TRAY WELDMENT-EURO	10856	BRAKE DRUM 11 3/8 O.D.
10755	RESERVOIR WELDMENT-EURO	10862	BOX CONTROL REAR-OUTRIGGER
10757	WELDMENT - CAB. SIDE-QE-EUROPE	10863	BOX CONTROL-OUTRIGGER-FRT
10759	COVER WELDMENT-EURO	10864	HOLD DOWN BRACKET (CHARGER)
10761	BACK & SIDE WELDMENT	10877	COVER CONTROL BOX-OR
10764	DOOR WELDMENT-EURO	10889	BASE WELDMENT - TKD
10768	BATTERY TRAY WRAPPER - EUROPE	10890	CONTROL BOX WELDMENT-ORIGINAL
10772	TOP BATTERY TRAY WELDM'T-EURO	10906	BOLT - OUTRIGGER ACTUATOR
10774	SUPPORT WELDM'T L.H.-EUROPE	10907	WASHER, ACTUATOR OUTRIGGER
10775	**SUB-ASS'Y TIP ALARM	10912	**CONTROL BOX ASSEMBLY

Figure 15-3. Numerical Part Number Index - Continued

Part No.	Description	Part No.	Description
10915	PLUG	100623B	CAM ROLLER
10925	CYL-LIFT-QUAD-W/BEARING	1008289	BTMACSELF T #10 320.31Y2 2AY
11177	ROLLER WASHER		

Limited Owner Warranty

Mayville Engineering Company, Inc. (MEC) warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered.

MEC further warrants the structural weldments of the main frame and elevating system as defined in MEC's current Warranty Policy & Procedures, to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered.


Warranty claims within such warranty period shall be limited to repair or replacement, at MEC's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC's then current flat rate, provided the defective part in question is shipped prepaid to MEC and is found upon inspection by MEC to be defective in material and/or workmanship.

Mayville Engineering Company, Inc. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty.

The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded.

No Dealer, Sales Representative, or other person purporting to act on behalf of MEC is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC any liability or obligation which exceeds MEC's obligations under this warranty.





Aerial Work Platforms

Mayville Engineering Company, Inc.

An Employee Owned Company
210 Corporate Drive • P.O. Box 990 • Beaver Dam, WI 53916-0990 USA
PH: 920-887-2518 • FX: 920-887-2480
E-mail: awp@mayvl.com • Web: www.mayvl.com