## **EZ-Cal Scan Tools**

The EZ-Cal Scan Tools interface with the machine's control system to provide system information and to allow adjustment. The EZ-Cal receives its power from the GP400 or GP440. The system must be powered up by closing the battery disconnect switch and pulling out both Emergency Stop Switches. You must also select Base or Platform depending on the station from which you will operate.

EZ-Cal

#### **Onboard EZ-Cal Option -- Lower Controls Box**

To use and operate the onboard EZ-Cal, set the Base/Platform Key switch to Base, then open the door to the Lower Controls Box. The onboard EZ-Cal scan tool provides the same functionality as the hand-held unit.

### Handheld EZ-Cal -- Upper Controls Box

The handheld EZ-Cal is not provided with the machine and is available from the MEC Parts Department (part #90888).

To use and operate the handheld EZ-Cal at the upper controls station:

- Set the Base/Platform Key Switch to Platform
- Open the lid to the Upper Controls Box
- Plug the EZ-Cal into port P9 of the GP440 module. This plug is on the right side of the module, facing down.

#### Using The EZ-Cal Scan Tool

- Once, powered up, the EZ-Cal display will illuminate and read "HELP: PRESS ENTER". From this point, use the right and left arrows to scroll through the base menus.
- Once the desired base menu is obtained (i.e. ADJUSTMENTS) press ENTER to access sub menus.
- Use the RIGHT and LEFT arrows to scroll through sub menus, then press ENTER again to choose a sub menu.
- The UP/DOWN arrows are used to change settings only.
- Press ESC to back up one level.







# Using the EZ-Cal with the Flow Charts

Use the EZ-Cal Flow Charts as a guide to locate diagnostic information and make adjustments. Each box in the flow chart will have 3 bits of information.



**The IDENTIFIER (5C2):** Used to locate this specific personality in the informational charts. Here you can obtain specific information on the individual personalities.

The PERSONALITY (UP MAX): Identifies the individual personalities.

**The DEFAULT SETTING:** The factory setting. If adjustments are made, they must be returned to default setting.



ACCESS LEVEL 1 PROVIDES ACCESS TO CHANGE PERSONALITIES NORMALLY PRESET AT THE FACTORY TO PROVIDE PROPER MACHINE MOVEMENT AT SAFE SPEEDS. PERSONALITIES MUST NOT BE CHANGED WITHOUT PRIOR AUTHORIZATION FROM MEC AND MAY ONLY BE RETURNED TO FACTORY SPECIFICATION AS LISTED IN THE FOLLOWING TABLES.

#### Error Messages

To obtain error messages from the EZ-Cal, access the EZ-Cal as mentioned above. The display will read, "HELP:PRESS ENTER". Press ENTER to display the current error message. If an error message is present, use the following list of error messages to better understand the fault. If an error message is not present, the display will show the last operation performed.

Pressing ENTER twice will provide a log of previous errors and operations that may have occurred within recent operation. The first message will be the most recent.

#### Flash Codes

Flash Codes, provided from the GP400 red LED, will also assist in the event an EZ-Cal is not available. However, the EZ-Cal yields considerably more relevant information. Refer to "EZ-Cal Messages" on page 101 for flash coded error messages.









Page 100



## **EZ-Cal Messages**

"Help Messages" will appear on the EZ-Cal scan tool as a means of explaining operating and nonoperating function(s) and system errors or interruptions that are accompanied by flash codes. It can also be used for verifying system operation. Refer to the EZ-Cal Instruction page for additional help with EZ-Cal operation.

To access messages, power the system up, (it is not necessary to have the engine running) the EZ-Cal display will illuminate and read "HELP - PRESS ENTER". Press ENTER to view current message. Press ENTER a second time then use RIGHT and LEFT arrow buttons to access up to 30 logged messages from the memory. Many messages simply detail operations being performed by the GP400; other messages detail occurrences that also take place during operation either normal or may be symptomatic of a malfunction.

#### **Operational Messages**

The following messages appear as result of normal operation and usually do not represent a problem.

#### EVERYTHING OK Flash Code: None

All circuits performing properly, no current operation performed.

# GROUND MODE ACTIVE Flash Code: None

Base/Platform selector switch set to base control station.

#### STARTUP Flash Code: None GP400 performing start up procedure, normally a short sequence.

## MOVING FRAME Flash Code: None

Chassis level in progress.

#### MOVING PLATFORM Flash Code: None

Platform level in progress •

#### TELESCOPING Flash Code: None

Boom extend/retract (telescope) in progress

#### LIFTING Flash Code: None

Boom lift up in progress

# 

Boom Lower down in progress

## DRIVING

• Drive forward or reverse in progress

#### VEHICLE TILTED

#### Flash Code: None

Flash Code: None

Flash Code: None

• Chassis is tilted beyond pre-set maximum. Use auto-level feature to level chassis or re-position the machine.



## **Can Bus Related Messages**

CAN bus communication system is the network by which the control modules and CAN Tilt modules communicate with the GP400.

## NO DATA FROM CAN TILT #1\_\_\_\_\_ Flash Code: None

CAN Tilt module mounted to front of main boom (located behind panel, Left Module) has • malfunctioned or wiring is damaged.

#### NO DATA FROM CAN TILT #2\_

CAN Tilt module mounted to Front axle has malfunctioned or wiring is damaged.

#### NO DATA FROM CAN TILT #3

CAN Tilt module mounted to front of main boom (located behind panel, Right Module) has malfunctioned or wiring is damaged.

#### NO DATA FROM CAN TILT #4

• CAN Tilt module mounted to Rear axle has malfunctioned or wiring is damaged.

#### FAULT: CAN BUS!

LT: CAN BUS!\_\_\_\_\_ Flash Code: 6/6 The CAN bus cable may be damaged or disconnected from one or more of the modules. All • modules must be connected to the CAN bus for machine operation.



# Flash Code: None

Flash Code: None

## Flash Code: None

Flash Code: 6/6

## **Calibration Related Messages**

The following messages appear when the GP400 microprocessor has not been calibrated or was improperly calibrated.

#### FACTORY OVERRIDE

 GP400 is shipped in this condition to allow temporary operation of the machine without interruption from the safety system so that calibration procedures can be performed. The GP400 must be prepared for the machine to which it will be installed, including calibration and Customer/ model selection. See "GP400 Setup" for instructions. Once Calibrated, Factory Override is gone forever.



#### ALL SAFETY SETTINGS ARE INACTIVE WHEN THE GP400 IS IN FACTORY OVERRIDE, NEVER OPERATE MACHINE IN FACTORY OVERRIDE EXCEPT TO CALIBRATE THE GP400.

#### NOT CALIBRATED\_

• The GP 400 microprocessor has not been calibrated. Operation will be restricted until calibration is completed. Refer to "GP400 Calibration Procedure" for calibration information and instructions.

#### **HEIGHT NOT CALIBRATED**

 The Height portion of the calibration has not been completed. Operation will be restricted until calibration is completed. Refer to "GP400 Calibration Procedure" for calibration information and instructions.

#### FUNCTIONS LOCKED - NOT CALIBRATED\_\_\_\_\_ Flash Code: 1/1

 The GP 400 microprocessor has not been calibrated. Operation will be restricted until calibration is completed. Refer to "GP400 Calibration Procedure" for calibration information and instructions.

#### FAULT: CUSTOMER

 Customer vs. Model settings not correct. Using the EZ-Cal, go to SETUPS/CHANGE DEFAULTS/CUSTOMER to correct. Changing customer or model will require access level 1 code. NOTE: all adjustments and settings return to default value when Customer or Model is changed, ensure proper settings and adjustments after changing Customer or Model.



May 2020

# Flash Code: 1/1

Flash Code: 1/1

FAST FLASH

#### Flash Code: 1/1



## **Interlock Messages**

The following messages appear as result of perceived improper operation, machine positioning, or other incorrect operation. Interlock messages may be the result of a part failure if the part in question provides incorrect information to the GP400.

#### FUNCTIONS LOCKED - LIMIT REACHED \_\_\_\_\_ Flash Code: 2/2

Rotating platform not centered; Certain operations require centered platform Rotating platform at extreme CW or CCW; no further rotation possible in that direction

#### FUNCTIONS LOCKED - TEST MODE SELECTED Flash Code: 2/2

• Calibration in progress or internal test mode active. Cycle EMS to clear.

#### FUNCTIONS LOCKED - OUTRIGGERS

• Stabilizers must be set before operation is allowed.

#### FUNCTIONS LOCKED - OVERLOADED

• Platform overloaded - reduce weight in platform until alarms stop (Overload option only)

#### FUNCTIONS LOCKED - UNDERLOADED

Overload system detects less then normal lift cylinder pressure. Platform resting atop a fixed • object, possible pressure switch failure or not calibrated correctly.

#### FUNCTIONS LOCKED - TILTED

Platform sensors indicate platform out of level; level platform or chassis until alarm stops or reposition machine

#### FUNCTIONS LOCKED - AUTO PLATFORM LEVEL Flash Code: 2/2

Auto Platform Level operation running, wait until completed to operate other functions.

#### FUNCTIONS LOCKED - TOO HIGH

Elevation sensor indicating elevation beyond 98%. Height Calibration performed incorrectly; Angle Transducer loose or remounted incorrectly or extend proximity switch/s failure. Use EZCal in conjunction with EZ-Cal Flow Charts to identify GP400 or GP440 for sensor's inputs to check sensor readings.

#### FUNCTIONS LOCKED - EXTERNAL SHUTDOWN Flash Code: 2/2

Boom not retracted or axle/s off level. Boom must be retracted to allow frame level, drive or outrigger operation. Axles must be centered before drive is allowed when the platform is elevated. Also, drive will be interrupted if Stabilizer pressure sensor output is below 0.2 volts (possible sensor failure or sensor wiring issue).

#### CHECK DRIVE/STEER SWITCHES

Drive joystick output without enable or during power up. Check drive joystick analog output and steer switch digital output using the EZ-Cal.

#### CHECK LIFT SWITCHES

Lift joystick or toggle switch movement without enable or during power up. Check joystick analog output using the EZ-Cal.

#### Flash Code: 2/2

#### Flash Code: 2/2

#### Flash Code: 2/2



## CHECK PLATFORM SWITCHES

• Platform Rotate/slide joystick or toggle switch movement without enable or during power up. Check joystick analog output and switch digital outputs using the EZ-Cal.

#### CHECK TELE SWITCHES

• Telescope joystick or toggle switch movement without enable or during power up. Check joystick analog output and switch digital output using the EZ-Cal.

### RELEASE ENABLE SWITCH

• One or more enable switches activated for extended period of time without corresponding function or during start up. Check enable switches digital outputs using the EZ-Cal.



#### May 2020

#### Flash Code 2/2

Flash Code 2/2

Flash Code 2/2

## **Other Messages**

The following messages are the result of various possible failures or occurrences which may result in machine interruption.

#### FUNCTIONS LOCKED - NO VALVE SUPPLY! Flash Code 2/3

• GP400 detects no power on P7-1 of the GP400. Check wiring to plug connection; possible GP400 internal failure.

#### FAULT: ENERGIZED VALVE

Power on valve output wire at GP400 plugs P4, P5 or P6. Unplug these connectors and cycle estop switch to clear code. Plug in one-at-a-time until code reappears then isolate the circuit (with voltage) within that plug. If code does not clear, possible GP400 failure.

#### FAULT: VALVE FEEDBACK HIGH! Flash Code: 3/2

On start-up GP400 p-5 pin voltage incorrect, check P5-X wiring for voltage feed back. Possible GP400 internal fault

### FAULT: BAD INTERNAL SAFETY SWITCH! Flash Code: 3/4

At startup, internal feedback of output incorrect, possibly failed output driver; check wiring to P6-12/13/14/15; possible GP400 internal failure

#### FAULT: LOW OIL PRESSURE!

\_\_\_\_\_ Flash Code: 4/1 Oil pressure switch opened during operation or time out. Check oil pressure, pressure switch, • wiring. Message will appear if engine stops running for reasons other then normal shut down.

#### FAULT: BAD INTERNAL SLAVE!

Malfunction within the GP400 possibly caused by a short circuit in the wiring or high voltage surge. Replace GP400

## FAULT: BAD INTERNAL 5 VOLTS!\_\_\_\_\_\_ Flash Code: 4/2

• 5 volt circuit that provides voltage to sensors had failed. Possible short in the wiring or high voltage surge on supply.

#### FAULT: BATTERY VOLTAGE TOO LOW! Flash Code: 4/4

Charge battery and battery connections, check charging system and voltage source connections

#### FAULT: BATTERY VOLTAGE TOO HIGH! Flash Code: 4/4

GP400 input voltage should be 12 volts. Check battery and battery connections, alternator • output.

## FAULT: CHECK HEIGHT 2 SENSOR!

Height 2 sensor output over 4.5 volts or under .5 volts. Check height 2 sensor output using the EZ-Cal (height 2 sensor on CE option only). Possible sensor failure or wire connection failure.

## FAULT: CHECK HEIGHT 1 SENSOR!

Height 1 sensor output over 4.5 volts or under .5 volts. Check height 1 sensor output using the • EZ-Cal. Possible sensor failure or wire connection failure.

## May 2020

## \_\_\_\_\_ Flash Code 6/1

Flash Code 6/1

Flash Code: 4/2



#### Flash Code: 3/2

• Voltage from Height sensors out of range, should be .5 volts to 4.5 volts

### FAULT: CHECK PRESSURE SENSOR!\_\_\_\_\_

• Voltage from Pressure sensor out of range, should be .5 to 4.5 volts (Overload option only).

#### FAULT: CHECK ELEVATION SWITCH! Flash Code 6/3

• Check for incorrect GP 400 part.

#### FAULT: LOW OIL PRESSURE!\_\_\_\_\_

- Engine Start was pushed but engine did not start or oil pressure switch did not close.
- Engine Oil Pressure is low. Check oil level.

#### FAULT: SOME BIG BAD PROBLEM!\_\_\_\_\_

• A failure happened that has no message associated with it. This should never occur.

#### \_\_\_\_ Flash Code 7/7

Flash Code 6/1

\_\_\_\_\_ Flash Code 6/2

\_ Flash Code 9/9

## **Troubleshooting Chart**

The following chart describes the possible causes for inoperable functions of this machine. The Causes and Solutions columns list various points of references that can be found in the Hydraulic, Electrical, Schematics and Troubleshooting sections of this manual.

The majority of electrical troubleshooting on this model will require the use of the onboard EZ-Cal scan tool, located inside the lower control box door. Please refer to "EZ-Cal Scan Tools" on page 97 for further instructions on the use of the EZ-Cal scan tool.

Perform a full assessment of machine operations prior to troubleshooting this model and using this chart. This model is operated by a Microprocessor Control System equipped with a variety of builtin safety interlocks to prevent continued operation in the event of a failure or misoperation. Some interlocks may only be detected through the use of the EZ-Cal.

Problem	Possible Cause	Remedy/Solution	
General Power Issue	General Power Issue		
	Emergency stop switch pushed in, or ignition switch turned off, or faulty switches	Lower e-stop switch and ignition switch will cut all power. Upper e-stop will cut only upper power as will the ignition switch in platform control box.	
No operation from upper	Battery discharged or faulty cables	Will receive 4-4 or 7-7 flash on GP400. Clean, service and charge battery. Repair cables.	
or lower control station. No LEDs on modules.	Circuit breaker tripped	Located in lower control box. Look for short circuit and/or damage in wiring or high amperage draw at valve coils or engine actuators.	
	Faulty Terminal Block Module (TBM)	Located inside the lower control box. Initiates all power when signaled by the key switch. Check for loose terminals. Terminal 4 is Common power from Circuit breaker. Terminals 1 and 2 are signals to close the relay.	
No operation from upper or lower control station	Flash codes are the GP400's indication of a fault in the system.	Refer to flash code designation in this section of the manual or plug in an EZ-Cal scan for more relevant information relating to the failure. See EZ-Cal Instructions for more information.	
flashing	Starter Relay or Starter failure	Test for signal and Common power to Starter Relay. Check fuse for Common power to relay. Test Starter.	
Operates from lower controls but not from upper controls. No LEDs when in Upper control position.	Base/Platform select switch not in Platform position or switch malfunction	Ensure that the switch is in the Platform position. Check switch function.	
	Damaged or loose harness connections to upper control box	Check for power inside the upper control box on e-stop switch and at Buss Module. Check for presence of ground on the Ground Buss Module. Repair connections.	
	Malfunctioning GP440 Module (Module inside the upper control box)	Check help messages using the EZ-Cal tool. Also check for joystick inputs (see 2C2 and 2D2 Diagnostic Chart for inputs from GP440).	
	System interlock	Check EZ-Cal HELP messages for interlock	

Problem	Possible Cause	Remedy/Solution
Engine Related Issues		
Starter will not crank from upper or lower stations	Battery discharged or faulty cables	Will receive 4-4 flash on GP400. Clean, service and charge battery. Repair cables.
	Malfunctioning start relay or fuse	Test/replace relay located on left hand side of engine and fuse located near starter
	Malfunctioning starter	Test/replace starter
	Faulty start switch either location	Test/replace as necessary
	Starter interrupt system initiated	Check for red "Start Disable" light on lower panel. Starter may be operated for 10 seconds before a 30 second "cool down" is initiated.



#### Section 19 - Troubleshooting

Problem	Possible Cause	Remedy/Solution	
Engine Related Issues	Engine Related Issues		
7-7 Flash code on GP400	Indicates an attempt to start was sent by the GP400 but the oil pressure switch did not close.	Check all the above	
	Low fuel reservoir	Check/fill fuel reservoir. Fuel system requires air purge after loss of fuel.	
	Air trapped in the fuel system	Purge air from the fuel system (See Section 18 - Mechanical Components for instructions). Check fuel reservoir level or for leaks in the fuel hoses.	
	Restriction in the fuel system	Replace fuel filter. Check fuel supply hoses	
Starter cranks but engine	Malfunctioning fuel solenoid	Check/replace fuel solenoid located on the top of the injection pump.	
will not start	Malfunctioning glow plugs (cold climates)	Test/ replace grid heater relay, fuse and grid heater	
	Obstructed air filter	Clean/replace air filter.	
	Contaminated fuel	Test/replace fuel	
	Other engine issues	See engine manufacturers troubleshooting guide	
No high throttle	Malfunctioning throttle controller, solenoid or blown fuse	Test/replace throttle controller and/or throttle solenoid and fuse	
	Restriction in the fuel system	Replace fuel filter. Check fuel supply hoses	
	Obstructed air filter	Clean/replace air filter.	
	Other engine issues	See engine manufacturers troubleshooting guide	

Problem	Possible Cause	Remedy/Solution	
Boom Lift/Lower			
	Excessive weight on platform	Reduce weight to within platform capacity	
	Machine out of level (platform elevated above 10')	Indicator light will be illuminated and alarm will sound off. Reposition machine to level ground.	
	Main relief valve (6) out of adjustment	Adjust main relief valve (6) to rated platform capacity located on function manifold - See Section 10 - Hydraulic System.	
	Lift valve (8.1) not energized	Check wiring to lift valve. Check for EZ-Cal message or flash code	
	Lift valve (8.1) not shifting	Clean debris. Check for damage/replace.	
Platform will not raise	Solenoid valve (18) dump valve not energized	Check wiring to valve. Check EZ-Cal ref. P4-14 for output.	
	Solenoid Valve (18) load sense dump not shifting	Clean debris. Check for damage/replace.	
	Main system pressure inadequate	Check pump output flow and pressure	
		Check Joystick output using EZ-Cal ref. 2D-2	
		P7-1 for analog joystick output signal	
	Battery discharged - no charge output	Check battery voltage, alternator output (14.5 volts) Check GP400 for 4-4 flash code.	
	System interlock	Check EZ-Cal HELP messages for interlock	
	Lowering valve SV3 not energized	Check wiring to lowering valve located inside control module - See Section 10 - Hydraulic System for location.	
Platform will not lower or	Lowering valve (8.2) not shifting	Clean debris. Check for damage/replace.	
lowers slowly	System interlock	Check EZ-Cal HELP messages for interlock	
	Main system pressure inadequate	Check pump output flow and pressure	
Emergency lowering not working	Battery discharged, not charging	Check/charge battery. Check charge Isolator relay and fuse. Check alternator output (14.5 volts)	
	Auxiliary power unit malfunction	Check APU located beside lower control box	
	Emergency Down switch failure	Check/replace switch.	
	Lowering valve (8.2) not shifting	See "Platform will not lower or lowers slowly"	
	Counterbalance valve (on lift cylinder) not adjusted correctly	Contact Factory Technical Support for instructions for counterbalance valve adjustment	
	System interlock	Check EZ-Cal HELP messages for interlock	



Problem	Possible Cause	Remedy/Solution	
Boom Extend/Retract			
	Excessive weight on platform	Reduce weight to within platform capacity	
	Level sensor out of level (platform elevated above 10')	Indicator light will be illuminated and alarm will sound off. Reposition machine to level ground	
	Main relief valve (6) out of adjustment	Adjust main relief valve (6) to rated platform capacity located on function manifold - See Section 10 - Hydraulic System.	
	Solenoid valve (18) (dump valve) not energized	Check wiring to valve. Check EZ-Cal ref. P4-14 for output	
No boom extension	Ext/Retract valve (8.2) not energized	Check wiring to lift valve. Check for EZ-Cal message or flash code.	
	Extend/Retract valve (8.2) not shifting	Clean debris. Check for damage/replace.	
	Ext/Retract joystick inoperative	Check joystick output using EZ-Cal ref. 2D-2, P14-1 & P14-2 for upper control analog output signal	
	Battery discharged - no charge output	Check battery voltage, alternator output (14.5 volts). Check GP400 for 4-4 flash code.	
	System interlock	Check EZ-Cal HELP messages for interlock	
	Excessive weight on Platform	Reduce weight to rated platform capacity	
Room ovtende/retracte	Main relief valve (6) out of adjustment	Adjust extend relief valve (See Section 10 - Hydraulic System) located on function manifold.	
Boom extends/retracts slow	Extend/Retract valve (8.2) not shifting completely	Clean debris. Check for damage/replace.	
	Extend Speed adjustment reduced in GP400 Module	Use the EZ-Cal and check/adjust setting. See ADJUSTMENTS/TELESCOPE OUT MAX	
	Main relief valve (6) out of adjustment	Adjust main relief valve (6) to rated platform capacity located on function manifold - See Section 10 - Hydraulic System.	
	Foreign debris stuck in boom slide pads	Inspect/ clean slide pads.	
No boom retract	Solenoid valve (18) (dump valve) not energized	Check wiring to valve. Check EZ-Cal ref. P4-14 for output.	
	Ext/Retract valve (8.2) not energized	Check wiring to lift valve. Check for EZ-Cal message or flash code.	
	Extend/Retract valve (8.2) not shifting	Clean debris. Check for damage/replace.	
	Ext/Retract joystick inoperative	Check joystick output using EZ-Cal ref. 2D-2, P14-1 & P14-2 for upper control analog output signal.	
	Battery discharged - no charge output	Check battery voltage, alternator output (14.5 volts). Check GP400 for 4-4 flash code.	
	System interlock	Check EZ-Cal HELP messages for interlock	

Problem	Possible Cause	Remedy/Solution
Platform Auto-Level		
Platform will not remain level while elevating or	Platform Level solenoid (19) valve not energized	Check wiring to valve. Check output from VCCM P-1.
	Platform Level solenoid valve (19) sticking	Remove valve and inspect for debris or damage. Replace valve located up on the side of the boom.
cylinder not moving at all)	Counterbalance valve faulty	Valve must not be tampered with. Replace valve.
, , ,	Flow Compensator valve (20) not shifting	Clean debris. Check for damage/replace.
Platform will not remain level while elevating or lowering platform (level cylinder moving too slow or fast)	Excessive weight on platform	Reduce weight to within platform capacity
	Main relief valve (16) out of adjustment	Adjust main relief valve (See Section 10 - Hydraulic System) located on function manifold.
	Platform level solenoid valve (19) not shifting completely	Clean debris. Check for damage/replace.



Problem	Possible Cause	Remedy/Solution
Platform Auto-Level		
Platform will not remain level while elevating or lowering platform (level cylinder moving too slow or fast)	Flow compensator valve (22) not shifting completely	Clean debris. Check for damage/replace.
	Adjustments in GP400 incorrect	Refer to Adjustments Flow Chart column 4F for settings that will allow leveling to be close then make slight changes until operating correctly. Contact MEC Technical Support for assistance if needed.
	Pump faulty	Test/replace pump

Problem	Possible Cause	Remedy/Solution
Platform Manual Level		
Platform level operates automatically but not manually	Platform level toggle switch inoperative	Check output from toggle using EZ-Cal. See I.D.# 2C-1, P15-3 (up) P15-6 (down) for lower control operation or 2c-2, P14-11 (up) or P14-12 (down) from upper controls.
	System Interlock	Check EZ-Cal HELP message for interlock

Problem	Possible Cause	Remedy/Solution
Turntable Rotate		
	Turntable rotate joystick inoperative	Check joystick output using EZ-Cal. See 2D2 P7-2 for signal.
Turntable will not rotate either direction	Rotate valve (11) not energizing.	Check wiring to valve Check GP400 output using EZ-Cal. See 2E1 P4-7 (left) and P4-8 (right).
	Rotate valve (11) not shifting.	Clean debris. Check for damage/replace.
	Internal damage or failure of rotator	Inspect/clean/repair
	System interlock	Check EZ-Cal HELP messages for interlock
Turntable will rotate in one direction only	Rotate valve (11) not energizing	Check wiring to valve
	Rotate valve (11) not shifting	Clean debris. Check for damage/replace.
	Mechanical interference in rotator	Inspect, clean or repair
	System interlock	Check EZ-Cal HELP messages for interlock

Problem	Possible Cause	Remedy/Solution
Platform Rotate		
Platform will not rotate	Platform rotate joystick inoperative	Check joystick output using EZ-Cal. See 2D2 P6-2 for signal.
	Rotate valve (20-1) not energizing	Check wiring to valve Check GP400 output using EZ-Cal. See 2E1 P5-1 (left) and P5-4 (right)
	Rotate valve (20-1) not shifting	Clean debris. Check for damage/replace.
	Internal damage or failure of rotator	Inspect, clean or repair
	Flow Compensator valve (22) not shifting	Clean debris. Check for damage/replace.
	System interlock	Check EZ-Cal HELP messages for interlock
Platform will rotate in one direction only	Rotate valve (20-1) not energizing	Check wiring to valve
	Rotate valve (20-1) not shifting	Clean debris. Check for damage/replace.
	Mechanical interference in rotator	Inspect, clean or repair
	System interlock	Check EZ-Cal HELP messages for interlock

Problem	Possible Cause	Remedy/Solution
Drive		
No drive operation	Planetary hub bypass engaged	Check bypass plates located in the center of each planetary hub. Should be convex. Turn over if not.
	System interlock	Check EZ-Cal HELP messages for interlock
	Hydraulic oil incorrect for severe low temperatures	Use hydraulic tank warmer if equipped. Operate drive continuously until drive begins to operate.



Problem	Possible Cause	Remedy/Solution	
Drive			
	Drive Valve (on drive pump) not energized	Check Drive output from VCCM Module VP5 and VP6. Check for power at valve coils located on top of the drive pump.	
	Drive Valve (on drive pump) not shifting	Check drive valve for contamination	
No drive exerction	Brakes not releasing (system under pressure when drive attempted)	Check brake valve and brake pressure. See hydraulic diagram for location.	
	Drive joystick output failure	Check drive joystick output from GP400 (see 2d2, P10-1) check joystick enable trigger operation, Check wire connections.	
	Low pump stand-by pressure	Check at main manifold port GCP (see hydraulic Diagram). Adjust stand-by pressure to 300 PSI (21 bar).	
	Incorrectly adjusted or worn hydraulic drive pump	See Section 10 - Hydraulic System for pump adjustment. Inspect or replace pump.	
	Unit out of level	Lower boom and operate on more level surfaces.	
	FWD MIN, REV MIN setting incorrect	Reset drive speeds using EZ-Cal	
No drive with platform elevated	Hydraulic oil incorrect for severe low temperatures	Use hydraulic tank warmer if equipped. Operate drive continuously until drive begins to operate.	
	Low pump stand-by pressure	Check at main manifold port GCP (see hydraulic Diagram). Adjust stand-by pressure to 300 PSI (21 bar).	
	System interlock	Check EZ-Cal HELP messages for interlock	
**CE rated models	Axles not parallel	Reposition machine on flat ground	
	Slow speed enabled	Check speed switch in platform box. Check 2-speed valve located on the main manifold (see hydraulic diagram).	
	Hydraulic oil incorrect for severe low temperatures	Use hydraulic tank warmer if equipped. Operate drive continuously until drive begins to operate.	
Slow drive with platform in	Boom Retract proximity switch failure	Check for power ground & signal output to Proximity Switch located inside the rear of boom. Also check EZ-Cal 2C1, P14-10 for input.	
retracted	Low pump stand-by pressure	Check at main manifold port GCP (see hydraulic Diagram). Adjust stand-by pressure to 300 PSI (21 bar).	
	FWD MAX, REV MAX setting incorrect	Reset drive speeds using EZ-Cal	
	Wheel motor not functioning correctly	Inspect wheel motors for damage or wear.	
	High Speed enabled	Check Speed Switch	
	Wheel motor not functioning correctly	Inspect wheel motors for excessive bypass or shift not working properly	
Poor grade-ability or drive performance	Hydraulic oil incorrect for severe low temperatures	Use hydraulic tank warmer if equipped. Operate drive continuously until drive begins to operate.	
	Planetary hub bypass engaged	Check bypass plates located in the center of each planetary hub. Should be convex. Turn over if not.	
	Low pump stand-by pressure	Check at Brake/Axle manifold, should be 300psi (21 bar). Adjust stand-by pressure to 300 PSI (21 bar).	
	Incorrectly adjusted or worn hydraulic drive pump	See Section 10 - Hydraulic System for pump adjustment. Inspect or replace pump.	
Drive in one direction only	Drive valve not energizing in one direction	Check 12 volts to coil. Check coil. Check valve function (located on top of drive pump).	
	No output from VCCM Module	Check output from VCCM VP5 and VP6	
	Drive joystick output failure	Check drive joystick output from GP400 (see 2d2, P10-1)	
	Speed selector switch inoperative	Check continuity through speed select switch with wires disconnected	
No High Speed	2-speed valve SV9 not functioning	Check for 12 volts and ground to valve. Check for faulty valve spool. Check switch position output from GP400 (See EZ-Cal ID# 2E1, P5-9).	
	Boom Retract proximity switch failure	Check for power ground & signal output to Proximity Switch located inside the rear of boom. Also check EZ-Cal 2C1, P14-10 for input	



Problem	Possible Cause	Remedy/Solution
Steer		
No steer in either direction	Joystick rocker switch inoperative	Check continuity through micro-switch inside joystick handle using wires outside the handle. Check output (see EZ-Cal 2C2, P10-7 and P7-8).
	Steering valve 5 inoperative	Check steering valve for power. Check for damage and contamination. Check output from GP400 (see EZ-Cal ID # 2E1 P5-2 and P5-3). Inspect/ replace steering valve.
	Hoses connected incorrectly	See Section 10 - Hydraulic System for correct connection.
	Steer cross-port relief valve(s) 3-1 and 3-2 set too low	Set steer relief valves to 1500 PSI (103 bar). See hydraulic diagram for relief valves location.
	System interlock	Check EZ-Cal HELP messages for interlock
Steer in one direction only	Joystick rocker switch inoperative	Check continuity through micro-switch inside joystick handle using wires outside the handle. Check output (see EZ-Cal 2C2, P10-7 and P7-8).
	Steering valve 5 inoperative	Check steering valve for power. Check for damage and contamination. Check output from GP400 (see EZ-Cal ID # 2E1 P5-2 and P5-3). Inspect/ replace steering valve.
	No power to steering coil	Check for power and ground in both directions. Repair wiring. Check output from GP400 (see EZ-Cal I.D. #s 2F-11 right & 2F-12 left).
	System interlock	Check EZ-Cal HELP messages for interlock
Will steer but not fully or slow steering	One or both steering cylinder internal seal failure	Check/replace steering cylinder seals.
	Steer cross-port relief valve(s) 3-1 and 3-2 set too low	Set steer relief valves to 1500 PSI (103 bar). See hydraulic diagram for relief valves location.
	King pin/s seizing in the bore	Disassemble and inspect. Replace bushings.



















#### Section 20 - Schematics

	MICROPROCESSOR		LOAD CI CONNEC
	LAOD CELL FOR CE AND 750 LBS OPTIONS ONLY	P1-1 <	
	CHANNEL 1 S-	P1-3 K	
	CHANNEL 2 S+		>> 4
	LAOD CELL FOR CE AND 750 LBS OPTIONS ONLY P+	P2-1 K← P2-2 K←	
	CHANNEL 2 S-		
	P4 RED LAMP-OVERLOAD INDICATOR	P4-1	UPPER CON BOX CONNE
			(1) J11
	ALARM TILT/OVERLOAD	P5-2 $(417)$ $(417)^{  }_{a}$ ALARM TLT $(W)$	(1) >>> B
	12 V SUPPLY RED LAMP-TILT INDICATOR	P5-3 < < < / >	515) >> C
	750 LED OK INDICATOR	P5-5 < <207) UU	$(15) \rightarrow D$ $(15) \rightarrow F$
		JIB PROPORTIONAL (CONTROL HANDLE	115) >> F
			(1) (97) >> G
F	6 JIB UP/DOWN SIGNAL PLATFORM ROTATE L/R SIGNAL	P6-1 (402) (BLUE)	J
	JIB/ROTATE ENABLE	$P6-3 \leftarrow (276) \qquad (BLACK) \qquad \qquad$	к
	PLATFORM HALL EFFECT SUPPLY PLATFORM JOYSTICK ENABLE SUPPLY	P6-4 (< (30) (ORANGE) P6-5 (< (277) (RED)	414) L
	PLATFORM HALL EFFECT GROUND		113) ->> N
6	~~		P
	BOOM UP/DOWN SIGNAL SWING LEFT/RIGHT SIGNAL	P7-1 < <li>P7-2 &lt;&lt; (399) (GREY)</li>	
			->> w
	BOOM HALL EFFECT SUFFLY		→>> x
	BOOM HALL EFFECT GROUND	P7-6K	TO CON CABL (SEE PA)
L			
	P10 FWD & REV SIGNAL DRIVE HALL EFFECT SUPPLY		
	DRIVE HALL EFFECT GROUND		
	STEER LEFT STEER RIGHT	P10-7 (C) (REY)	
	DRIVE ENABLE SWITCH	P10-11 (3) (GREV) P10-12 (30) (RED) P30 12 (4) (30) (RED)	
		DRIVE PROPORTIONAL CONTROL HANDLE	
- II	P14 TELESCOPE OUT	P14-1 🔆	
			(1) 10
	EMERGENCY STOP SWITCH		(1) <b>1</b> 11
	750 LBS		• 12
	MANUAL PLATFORM LEVEL DOWN	0000 0 (515) 14-12 << (395) AUXILIARY 0 0 0 (515) 0 0 0 (515) 0 0 0 (515)	BUS
	AUXILLIARY POWER SIGNAL GENERATOR SIGNAL		(NEGATIV
L			(15) 1 (15) 1
6	P15 START	P15-1 << (450)	(15) 4
			(15) 5 (15)
	GLOW PLUG/CHOKE	P10-3 (24) P15-4 (24) Level enable	
	HIGH SPEED DRIVING LIGHTS	P15-5K<	L
	AUX HYDRAULIC POWER		
	HORN JIB SLOW DOWN	P15-8 (< <u>(97)</u> P15-9 (< <u>(97)</u>	
Ľ			
[	P12 CAN BUS HI		
L	CAN BUS LO		
L			

